

Princeton Tec AXIS Rechargeable LED Head Lamp User Guide

Home » Princeton Tec » Princeton Tec AXIS Rechargeable LED Head Lamp User Guide 🖺





AXIS ®RECHARGEABLE LED HEADLAMP Operating and Maintenance Instructions



Contents

- 1 Battery Charging
- 2 Switch Operation
- 3 Troubleshooting
- 4 USA- International 5-Year Warranty
- **5 Return Policy**
- 6 Documents / Resources
- 7 Related Posts

Battery Charging

Supplied with headlamp: Self-contained lithium rechargeable battery, micro-USB charging cable.

Princeton Tec suggests using a charger with an output of 5V, 1A. This charger will fully charge the battery pack in 3 to 4 hours. Slower charging will be achieved with a charger rated with lower amperage. Some computer USB ports may not have sufficient output to charge this or any USB rechargeable product. Under normal usage, the supplied lithium-ion battery pack will last for approximately 1,000 charge/discharge cycles.



- Red battery charge level LEDs indicate battery state. Red LEDs pulse when charging is in progress.
- Charging has completed when both LEDs are illuminated.
- Low Battery Indication: When the battery level reaches 25% the light will blink once indicating the charge is low.

Once the battery level drops below 20% the light will blink twice and drop to the lowest setting in the current model. Dial functionality will be disabled to provide the maximum amount of time before the battery is completely drained and the light shuts off.




WARNING!


Do not disassemble; no user-serviceable parts.

General Care and Warnings

- Properly charge the battery to maximize its lifespan. Lithium-ion batteries do not suffer from a "memory effect," and for battery longevity, it is preferable to charge more frequently if possible, rather than to fully deplete the battery's charge.
- To avoid damaging your lighting system, use only chargers that meet the approved specifications.
- Axis Rechargeable is not submersible. Submerging in water will damage the lighting system and void the warranty.
- To keep your lighting system looking new, use a mild soap and water solution with a rag or sponge to periodically wipe off the dirt.

Switch Operation






- A single press activates red mode at 70% output.
- Double press activates white spot mode at 70% output.
- Triple press activates white flood mode at 70% output.
- In any mode, the dial is used for dimming.
 - Clockwise dims to 10% output. Once the minimum is achieved, the further rotation will not do anything.
 - Counterclockwise brightens to 100% output. Once the maximum is achieved, the further rotation will not do anything.
 - Counterclockwise from flood mode activates dual-beam mode.
- A single press occurring more than two seconds after the previous button press will turn the light off.
- Lockout Mode to prevent accidental activation: Can only be activated during OFF mode.
 To enter Lockout mode, press and hold the button for three seconds. To indicate success, two red LEDs will flash according to the battery voltage chart (see figure 2).

Troubleshooting

If the Axis Rechargeable fails to light:

- Check the charge state of the battery by either 1. Locking out the light by holding down the power button, or 2. Plugging light into a power source and observing battery charge level LEDs.
- To reset the headlamp if there are any functional errors, press and hold the button for 20 seconds.



(ANSI FL-1 Standard)

Runtime is defined as the duration of time from the initial light output value—defined as 30 seconds after the point the device is first turned on—using fresh batteries until the light output reaches 10% of the initial value. Reserve time is the duration of time from 10% of the initial light output value down to 0.25 lux

WARRANTY – Princeton Tec warrants this product to be free from defects in workmanship and materials under normal use for 5 years. This warranty covers all of the component parts of the product except batteries. This warranty does not cover deterioration due to normal wear or damage due to misuse, alteration, negligence, accidents, or unauthorized repair. Princeton Tec will repair or replace parts which are defective in workmanship or materials

Your authorized Princeton Tec Dealer and Princeton Tec are the only facilities authorized to repair the product. After (3) unsuccessful attempts (within the warranty period) to repair the product, you have the right to elect replacement of the product or a refund of the purchase price less allowance for use of the product. NO INCIDENTAL OR CONSEQUENTIAL DAMAGES ARE INCLUDED IN THIS WARRANTY. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Princeton Tec reserves the right to change product specifications without notice.

FOR CALIFORNIA RESIDENTS:

WARNING: This product contains Bisphenol A (BPA) a chemical is known to the State of California to cause birth defects or other reproductive harm.

Return Policy

If your light fails to operate, follow these simple steps:

- 1. To send your light in for repair or replacement, first, contact Princeton Tec customer service at 1-800-257-9080 to request an RMA number. Please have your light model, date of purchase and a brief description of the fault you are experiencing. No warranty repairs will be accepted without an RMA number.
- 2. Return the light to:
 - Princeton Tec, PO Box 8057 Trenton NJ 08650.
 - Postage due and freight collect items will not be accepted.
- 3. Upon receipt, your light will be processed in about two weeks. Please allow additional time for return transportation from NJ.



Princeton Tec PO Box 8057, Trenton, NJ 08650 Phone: 609-298-9331 Fax: 609-298-9601

princetontec.com© 2020 Princeton Tec

Documents / Resources



<u>Princeton Tec AXIS Rechargeable LED Head Lamp</u> [pdf] User Guide AXIS, Rechargeable LED Head Lamp

Manuals+,