

protoArc XKM01 Portable Keyboard Mouse Combo User Manual

Home » ProtoArc » protoArc XKM01 Portable Keyboard Mouse Combo User Manual

Contents

- 1 protoArc XKM01 Portable Keyboard Mouse Combo
- **2 Product Usage Instructions**
- 3 Packing List
- **4 Keyboard Features**
- **5 Mouse Features**
- 6 2.4G Connection
- 7 Keyboard Bluetooth Connection
- **8 Mouse Bluetooth Connection**
- 9 Mode Switch Method
- 10 Laptop Stand User Guide
- 11 Charging Guide
- 12 Multimedia Function Keys
- **13 Product Parameters**
- 14 Sleep Mode
- 15 Safety Warning
- 16 More Info
- **17 FAQ**
- 18 Documents / Resources
 - 18.1 References



protoArc XKM01 Portable Keyboard Mouse Combo



Specifications

- Product Name: XKM01 CaseUp
- Type: Foldable Keyboard and Mouse Combo with Laptop Stand
- Keyboard Features: Multifunction Button, Type-C Charging Port, Caps Lock, 2.4G Indicator, Bluetooth Indicators
- Mouse Features: Left and Right Buttons, Scroll Wheel Button, Charging/Low Battery Indicator, DPI Switch Button, Type-C Charging Port, Channel Switch Button, Power Switch

Product Usage Instructions

2.4G Connection

- 1. Turn the power switch to ON.
- 2. Unfold the keyboard automatically turns on.
- 3. Press the channel switch button until the light is on, indicating the mouse enters into 2.4G USB channel.
- 4. Take out the USB receiver and plug it into the computer USB port. Note that the keyboard and mouse share only ONE USB receiver.

Keyboard Bluetooth Connection

- 1. Unfold the keyboard automatically turns on.
- 2. Turn on the Bluetooth settings on your device.
- 3. Select XKM01 CaseUp for Bluetooth pairing until the connection is completed.

Mouse Bluetooth Connection

- 1. Turn the power switch to ON.
- 2. Press the channel switch button until the indicator light is on, indicating the mouse enters the Bluetooth channel.
- 3. Long press the channel switch button for 3-5 seconds to enter Bluetooth pairing mode.

Mode Switch Method

- Mouse: Short press Mode Switch Button on the bottom of the mouse to switch between multiple devices.
- **Keyboard:** Short press the channel key on the keyboard to switch between multiple devices.


Laptop Stand User Guide

- 1. Take out the stand.
- 2. Extend the stand to the required width.
- 3. Pull up the spring-loaded support feet on both sides and adjust to a comfortable angle, then lock in place.
- 4. Pull up the anti-slip small baffle.
- 5. Place your laptop on the stand.

Charging Guide

- 1. If the low battery indicator light flashes rapidly, indicating low power, connect the Type-C port to the mouse or keyboard and the USB-A port to the computer for charging. The red light stays on while charging.
- 2. The indicator light turns green when fully charged.

Packing List





User


Manual* 1

Type-C Charging Cable* 1 Foldable Laptop Stand* 1


Keyboard Features








Mouse Features





- A. Left Button
- B. Right Button
- C. Scroll Wheel Button
- D. DPI Switch Button
- E. Charging/Low Battery Indicator


• Fully Charged: Green Light

• Low Battery: Red Light Flashing


- F. Type-C Charging Port
- G. BT2 Indicator
- H. BT1 Indicator
- I. 2.4G Indicator
- J. Channel Switch Button
- K. Power Switch
- L. USB Receiver

2.4G Connection

Step 1




• Turn the power switch to ON.




• Unfold the keyboard automatically turns on.

Step 2




• Press the channel switch button until the light is on, the mouse enters into 2.4G USB channel.




• Single press Channel button, and the indicator light flashes slowly, enter into 2.4G USB channel.

Step 3



• Take out the USB receiver.


Step 4



• Plug into the computer USB port. Keyboard and mouse share only ONE USB receiver.


Keyboard Bluetooth Connection

Step 1




• Unfold the keyboard automatically turns on.

Step 2




- Single press (1) / (2) channel button, and the indicator light flashes once to enter the Bluetooth channel.
- Long press this Bluetooth channel button for 3–5 seconds again, the indicator light flashes quickly, then the keyboard enters into the Bluetooth pairing mode.



• Turn on the Bluetooth settings on your device, search or select "XKM01 CaseUp" and start Bluetooth pairing until the connection is completed.


Mouse Bluetooth Connection

Step 1




• Turn the power switch to ON.

Step 2



- Press the channel switch button until the \displant 1 / \displant 2 indicator light is on, the mouse enters the Bluetooth channel.
- Long press the channel switch button for 3-5 seconds again, until the №1 / №2 light flashes quickly, then the mouse enters the Bluetooth pairing mode.


Step 3



• Turn on the Bluetooth settings on your device, search or select "XKM01 CaseUp" and start Bluetooth pairing until the connection is completed.


Mode Switch Method

Mouse




ⓐ 1 №2 After are connected, short press Mode Switch Button on the bottom of the mouse, easily switch between multiple devices.

Keyboard




Laptop Stand User Guide

Step 1




• Take out the stand.

Step 2



• Extend the stand into required width.

Step 3




- Pull up the spring-loaded support feet on both sides, adjust to a comfortable angle, and lock in place.
- Pull up the anti slip small baffle.

Step 4



• Place your laptop on the stand.



(Note: 6 adjustable angles, from 10° to 40°)

Charging Guide

- 1. When the battery is low, the low battery indicator light on the keyboard or mouse will rapidly flash to indicate low power.
- 2. Insert the Type-C port into the mouse or keyboard and port into the computer to charge, the red light stays on
- 3. The indicator light turns in green when fully charged.



Notice

If the mouse or keyboard is low battery, there will be delays, freezes and other problems. Please connect to the power supply for charging in a timely manner to ensure that the mouse or keyboard has sufficient battery power to get normal performance.

Multimedia Function Keys

Keys	Windows OS	Android OS	ios	Mac OS
*	Light -	Light -	Light -	Light -
፠	Light +	Light +	Light +	Light +
밂	Window Switch	Window Switch	1	Window Switch
888	Application Switch	Application Switch	Open latest Window	Open latest Window
	Display Desktop	Go Home	Go Home	Go Home
Q	Search	Search	Search	1
Ø	Previous Track	Previous Track	Previous Track	Previous Track
DII	Play & Pause	Play & Pause	Play & Pause	Play & Pause
DI	Next Track	Next Track	Next Track	Next Track
d×	Mute	Mute	Mute	Mute
(۲)	Volume -	Volume -	Volume -	Volume -
d»)	Volume +	Volume +	Volume +	Volume +
٥	Setup	1	1	1
<u>_</u>	Lock Screen	Lock Screen	Lock Screen	1
<u></u>	Screenshot	Screenshot	Screenshot	Screenshot
₽	FN+ESC (FN lock) button to turn on or turn off the FN function			

Note: The FN function is a cyclic mode (F1-F12 and multimedia functions are cyclically used).

Product Parameters

Keyboard Parameters

Battery Capacity	210 mAh
Working Current	≤ 3.5 mA
Sleep Current	31 uA
Charging Current	190 mA (±20mA)
Standby Current	≤ 0.3 mA
Input	5V 250mA
Standby Time	≥ 150 Days
Charging Time	< 2 Hours
Wake Up Way	Press any key
Weight	297 g
Keyboard Dimension	386.4×119.7×12.4mm(Unfolded) 215.5×119.7×20.9mm(Folded)

Mouse Parameters

Engine	Optics
DPI	1000/1600/2400 DPI
Mouse Button Life	More than 3 million times
Input	5V 250mA
Battery Capacity	300mAh
Battery Life	1000 times charge and discharge cycles
Standby Time	200 Days
Continuous Working Time	50 hours
Mouse Dimensions	107.9*59.1*20.1mm

Laptop Stand Specifications

Material	Aluminum alloy
Compatible Laptop Size	13-17.3 inch
Product Dimensions (Folded)	256 * 55 * 8mm
Adjustment Angles Range	10°/ 20°/ 25°/ 30°/ 35°/ 40°

2.4G Transmission Parameters

Transmission Distance	10m
Working Voltage	3.7V
Working Current	<5mA
Polling Rate	250Hz
System Requirements	An available USB port Windows XP, Windows 7, Windows 8, Windows 10 or highe r version

Bluetooth Transmission Parameters

Transmission Distance	10m
Working Voltage	3.7V
Working Current	<5mA
Polling Rate	125Hz
System Requirements	Bluetooth receiving device Windows 8, Windows 10 or high er version Mac OS X 10.10 or higher version Android 4.3 or higher version

Tips

- 1. If Bluetooth connection is not working properly, fold the keyboard to turn off its power, then unfold the keyboard again to restart the device's Bluetooth and attempt to reconnect. Or delete the extra Bluetooth option name in the Bluetooth connection list of the device and reconnect.
- 2. To switch to a successfully connected channel, press the channel button and wait for 3 seconds before continuing to use.
- 3. The keyboard and mouse have a memory function. When they are connected on a specific channel, turn off the keyboard and mouse and turn on again, they will automatically connect to the default channel and this channel indicator is on.

Sleep Mode

- 1. When the keyboard is not used for more than 30 minutes, it will automatically enter the sleep mode and the indicator light will be off.
- 2. When you use the keyboard again, you only need to press any key, and the keyboard will wake up within 3 seconds. The indicator will light up again and starts to work.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

Charging Safely: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.

Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.

Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.

A

Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.

Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.

Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.

Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.

Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.

Emergency Contact: +1 866-287-6188 (United States)

EU Declaration of Conformity

• Declared Object: Foldable Keyboard and Mouse Combo with Laptop Stand

• Model: XKM01 CaseUp

Rating: 3.7V 10mA

• Input: 5V 250mA

• Place of Production: Made in China

• Manufacturer: Shenzhen Hangshi Electronic Technology Co., LTD

Email: chen.zhao@bow.cn

- Address: Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104
- European Representative:

• Business name: g.L.L. GmbH

• Business address: Bauernvogtkoppel, 55c, 22393, Hamburg, Germany

• Email: g.L.L.DE@outlook.com

• Tel: +49 162 3305764

UK REP

• Business name: AMANTO INTERNATIONAL TRADE LIMITED

Business address: The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2
 5NA

Email: <u>AmantoUK@outlook.com</u>

• Tel: +44 7921 801 942

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

• Position: Managing Director

• Signature: ZHAO CHEN

• Date of Sign: 2022.1.5

• EU agent name: Tong Jria

• Date of Sign: 2022.1.5

More Info

www.protoarc.com

US

- support@protoarc.com
- (+1) <u>866-287-6188</u>

Monday-Friday: 10am-1pm, 2pm-7pm (Eastern Time)

*Closed during Holidays

UK


support-uk@protoarc.com

FAQ

Q: What should I do if my mouse or keyboard has low battery?

 A: If the low battery indicator is flashing rapidly, connect to a power supply for charging promptly to ensure normal performance.

Documents / Resources



References

- ProtoArc® The Wellness Workspace: adapt for excellence
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.