

PYLE PLMR24 Weather Proof Mini Box Speaker System



PYLE PLMR24 Weather Proof Mini Box Speaker System User Guide

[Home](#) » [Pyle](#) » PYLE PLMR24 Weather Proof Mini Box Speaker System User Guide 

Contents

- [1 PYLE PLMR24 Weather Proof Mini Box Speaker System](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Features](#)
- [6 Installation](#)
- [7 FINAL ADJUSTMENTS](#)
- [8 Connecting Your Speakers](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

PYLE

PYLE PLMR24 Weather Proof Mini Box Speaker System



Product Specifications

- **Model:** 3.5 200 Watt 3-Way Weather Proof Mini Box Speaker System
- **Power Output:** 200 Watts
- **Speaker Type:** 3-Way
- **Weather Proof**

Product Usage Instructions

1. Remove the bracket knobs and the bracket from the speaker.
2. Hold the bracket up to the mounting surface. It can be mounted horizontally or vertically. Ensure the speaker wire fits through the wire hole in the bracket.
3. Align the bracket square with the surroundings and use a level for accuracy.
4. Mark the locations of the three shaped screw holes and drill pilot holes into the mounting surface.
5. Gently pull the speaker wire through the wire hole in the center of the mounting bracket and align the bracket so that all holes line up.
6. Attach the bracket to the mounting surface using appropriate hardware.
7. Ensure the speaker is in phase and working correctly before angling it for the best sound.
8. Hand-tighten the bracket knobs only to avoid over-tightening with power tools which may strip the threads of the insert.
9. Check that the entire installation is safe and secure.

Follow the provided user guide for detailed instructions on connecting your speakers to your audio system.

WARNING: This product contains chemicals known to the state of California to cause cancer, birth defects, and other reproductive harm. Do not ingest. For more information, visit www.P65warnings.ca.gov.

FAQ

Q: How do I know if my speaker is in phase?

A: To check if your speaker is in phase, play a test tone and listen for a balanced sound. You can also use a phase tester to ensure correct polarity.

Q: Can I mount the speaker outdoors?

A: Yes, this speaker system is weatherproof and suitable for outdoor mounting.

Q: What is the power output of the speaker system?

A: The speaker system has a power output of 200 Watts.

Q: How should I clean the speakers?

A: Use a soft, dry cloth to gently wipe down the speakers. Avoid using any harsh chemicals or abrasive materials.

Features


- Excellent for Use On Boats/Marine/
- Decks/patios/Poolside/Outdoors
- Completely Weather Proof
- 3.5" Aluminum Injection Cone Woofer
- 24 Oz. Magnet Structure
- 1.75" Wide Dispersion Cone Midrange
- 1" Super Dome Tweeter
- Capacitor Crossover Network
- Bass Reflex Vent for Added Bass Response
- Heavy Duty ABS Construction
- Quick Connect/Disconnect Speaker Terminals
- Removable Rustproof Mesh Grills
- Power: 100Watts RMS/200Watts Peak
- Frequency Response: 70-21K Hz
- Impedance: 4 Ohms
- Complete Mounting Kit Wires
- Dimensions: 5.25"(W)x3.75"(H)x3.75"(D)

Installation

MOUNTING THE BRACKET

1. Remove the bracket knobs and the bracket from the speaker.
2. Hold the bracket up to the mounting surface.
“PYLE” can be mounted either horizontally or vertically. Hold the bracket so that the speaker wire fits through the large, circular wire hole in the bracket. Align the bracket to be square with the surroundings. (Use a level for accuracy)
3. Mark the locations of the three shaped screw holes.
Use all of the holes.
4. Drill pilot holes into the mounting surface.
5. Gently pull the speaker wire through the wire hole in the center of the mounting bracket.
Align the bracket so that the holes all line up.
6. Use your hardware to attach the bracket to the mounting surface.

MOUNTING




FINAL ADJUSTMENTS

1. After checking that the speaker is in phase and works correctly, angle the speaker for the best sound.
2. Hand-tighten the bracket knobs only. Power tools may over-tighten the knob and strip the threads of the insert.
3. Check that the entire installation is safe and secure.

Connecting Your Speakers

Connecting the speakers to your amplifier or receiver

- First, turn your amplifier off to avoid damage that may result from accidental shorting of the speaker leads.
- Correct phase polarity is critical for proper stereo imaging and bass performance.
- The red (+) terminal on your amplifier or receiver must be connected to the red (+) terminal on your speaker; the same applies to the black (-) terminal.
- Connect one loudspeaker at a time to ensure proper connection of left and right channels. Make sure all wires are fairly fastened.
- If you notice a high level of bass or central image focus, double-check your connections for proper polarity.



California Prop 65 Warning

WARNING

- This product can expose you to chemicals, which are known to the state of California to cause cancer birth

defects, and other reproductive harm. Do not ingest.

- For more info go to: www.P65warnings.ca.gov.

Questions or Comments?

- We are here to help! Phone: 1.718.535.1800 PyleUSA.com/ContactUs.
- www.PyleUSA.com
- PyleUSA.com



Documents / Resources



[PYLE PLMR24 Weather Proof Mini Box Speaker System](#) [pdf] User Guide
PLMR24, PLMR24B, PLMR24S, PLMR24 Weather Proof Mini Box Speaker System, Weather Proof Mini Box Speaker System, Proof Mini Box Speaker System, Mini Box Speaker System, Speaker System, System

References

- P65warnings.ca.gov
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.