



Home » RadioShack » radioshack 2604796 Wireless Numeric Keyboard Owner's Manual

Contents [hide]

- 1 Radioshack 2604796 Wireless Numeric Keyboard
- 2 Product Specifications
- 3 Product Usage Instructions
- 4 Features
- 5 Installation
- 6 Usage
- 7 FCC Rules
- 8 FAQs
- 9 Documents / Resources
 - 9.1 References

RadioShack_®

Radioshack 2604796 Wireless Numeric Keyboard



• Wireless technology: 2.4GHz

Wireless distance: 10m

Size: 145*90*25mm

Operating Voltage: 1.5VOperating Current: 10mA

Key Life: 3,000,000 times

Power supply:1*AAA(Alkaline batteries are recommended)

Product Usage Instructions

Plug and Play Simplicity. Just plug in the tiny USB-A receiver and start working in seconds with a strong, reliable connection to your wireless computer mouse up to 10 m

Features

- Advanced 2.4GHz wireless technology for a working distance of up to 10 meters.
- Simple and beautiful appearance with a comfortable hand feel and switch-free design.
- Professional numeric keypad suitable for finance/accounting/business/securities/banking offices.
- Easily identifiable keys that are not prone to fading.
- Plug-and-play installation for quick setup.
- Compatible with Windows
 2000/XP/Vista/Windows7/Windows8/Windows10/Linux/Mac systems.

Installation

- 1. Insert the AAA battery into the keyboard.
- 2. Insert the USB-A receiver into your computer's USB port.
- 3. The keyboard is now ready to use.

Usage

- Place the keyboard within 10 meters of the computer for optimal wireless connectivity.
- Type on the numeric keypad for efficient data entry in various office environments.
- Ensure the keyboard is compatible with your operating system before use.

FCC Rules

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the eqequipmentff and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

FAQs

Q: What type of battery is recommended for this wireless numeric keyboard?

A: Alkaline AAA batteries are recommended for optimal performance.

Q: Is the keyboard compatible with Mac operating systems?

A: Yes, the keyboard is compatible with Mac systems, along with Windows and Linux.

Documents / Resources



radioshack 2604796 Wireless Numeric Keyboard [pdf] Owner's Manual 2BDUR-2604796, 2BDUR2604796, 2604796 Wireless Numeric Keyboard, 2604796, Wireless Numeric Keyboard, Numeric Keyboard, Keyboard

References

- User Manual
- RadioShack
- ◆ 2604796, 2604796 Wireless Numeric Keyboard, 2BDUR-2604796, 2BDUR2604796, Keyboard, Numeric Keyboard, RadioShack, Wireless Numeric Keyboard

Leave a comment

Your email address will not be published. Required fields are marked*

Comment*

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.