

RAZER MAG Series LCD Monitor User Guide

Home » Razer » RAZER MAG Series LCD Monitor User Guide 12

Contents

- 1 RAZER MAG Series LCD Monitor
- 2 Getting Started
- 3 Package Contents
- 4 Installing the Monitor Stan
- **5 Adjusting the Monitor**
- **6 Monitor Overview**
- 7 Connecting the Monitor to PC
- 8 OSD Setup
- 9 OSD Menus
- 10 Gaming
- 11 Settings
- 12 Specifications
- 13 Preset Display Modes
- 14 Troubleshooting
- 15 Safety Instructions
- **16 Regulatory Notices**
- 17 FCC-B Radio Frequency Interference

Statement

- **18 WEEE Statement**
- 19 Green Product Features
- **20 Technical Support**
- 21 Documents / Resources
 - 21.1 References
- **22 Related Posts**



RAZER MAG Series LCD Monitor



Specifications

• Product Name: MAG Series LCD Monitor

• Model: MAG 274QRFW (3CC2)

• Revision: V1.0, 2023/11

Getting Started

This chapter provides you with information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

- Monitor
- Documentation Accessories
- · Cables:
 - MAG 274QRFW Quick Start Guide
 - Stand with Screw(s)
 - Stand Base with Screw(s)
 - Screw(s) for Wall Mount Bracket(s)
 - External Power Supply
 - Power Cord
 - Premium High-Speed HDMITM Cable (Optional)
 - DisplayPort Cable (Optional)

Important:

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- · Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

- 1. Leave the monitor in its protective foam packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- 3. Connect the base to the stand and tighten the base screw to secure the base.
- 4. Make sure the stand assembly is properly installed before setting the monitor upright.

Important:

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for a proper wall-mount kit.
- This product comes with NO protective film to be removed by the user! Any mechanical damages to the product including removal of the polarizing film may affect the warranty!

Adjusting the Monitor

This monitor is designed to maximize your viewing comfort with its adjustment capabilities.

Important:

- Avoid touching the display panel when adjusting the monitor.
- Please slightly tilt the monitor before pivoting it.

Monitor Overview

- 1. Power Button & Navi Key
- 2. Power LED: Lit in white after the monitor is turned on. If no signal is input, the LED will turn orange. Lit in orange when the monitor is in Stand-by mode.
- 3. Cable Routing Hole
- 4. Kensington Lock
- 5. Power Jack
- Headphone Jack
- 7. HDMITM Connector: Supports HDMITM CEC, 2560×1440@144Hz as specified in HDMITM 2.0b.
- 8. HDMITM Connector: Supports 2560×1440@144Hz as specified in HDMITM 2.0b.
- 9. DisplayPort: Supports 2560×1440@180Hz as specified in DisplayPort 1.4a.

Connecting the Monitor to the PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- 3. Assemble the external power supply & power cord. (Figure A)
- 4. Connect the external power supply to the monitor power jack. (Figure B)
- 5. Plug the power cord into the electrical outlet. (Figure C)
- 6. Turn on the monitor. (Figure D)

7. Power on the computer and the monitor will auto-detect the signal source.

FAQ

- Q: What should I do if any of the package contents are missing or damaged?
 - A: Contact your place of purchase or local distributor for assistance.
- Q: Can I use the included power cord with other products?
 - A: No, the included power cord is exclusively for this monitor and should not be used with other products.
- Q: Can I remove the protective film from the display panel?
 - A: No, this product does not come with a protective film to be removed by the user. Removing any mechanical damages to the product, including removal of the polarizing film, may affect the warranty.

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents


Monitor	MAG 274QRFW		
Documentation	Quick Start Guide		
	Stand with Screw(s)		
	Stand Base with Screw(s)		
Accessories	Screw(s) for Wall Mount Bracket(s)		
	External Power Supply		
	Power Cord		
Cables	Premium High Speed HDMI™ Cable (Optional)		
Capies	DisplayPort Cable (Optional)		

Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stan

- 1. Leave the monitor in its protective foam packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- 3. Connect the base to the stand and tighten the base screw to secure the base.
- 4. Make sure the stand assembly is properly installed before setting the monitor upright.



Important

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for a proper wall-mount kit.
- This product comes with NO protective film to be removed by the user! Any mechanical damages to the product including removal of the polarizing film may affect the warranty!




Adjusting the Monitor


This monitor is designed to maximize your viewing comfort with its adjustment capabilities.

Important

- Avoid touching the display panel when adjusting the monitor.
- Please slightly tilt the monitor backward before pivoting it.




Monitor Overview



1	Power Button & Navi Key
2	Power LED Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange w hen the monitor is in Stand-by mode.
3	Cable Routing Hole
4	Kensington Lock
5	Power Jack
6	Headphone Jack
7	HDMI™ Connector HIGH-DEFINITION MULTIMEDIA INTERFACE Supports HDMI™ CEC, 2560×1440@144Hz as specified in HDMI™ 2.0b.
8	HDMI™ Connector HIGH-DEFINITION MULTIMEDIA INTERFACE Supports 2560×1440@144Hz as specified in HDMI™ 2.0b.
9	DisplayPort Supports 2560×1440@180Hz as specified in DisplayPort 1.4a.

Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- 3. Assemble the external power supply & power cord. (Figure A)
- 4. Connect the external power supply to the monitor power jack. (Figure B)
- 5. Plug the power cord into the electrical outlet. (Figure C)
- 6. Turn on the monitor. (Figure D)
- 7. Power on the computer and the monitor will auto-detect the signal source.



OSD Setup


This chapter provides you with essential information on OSD Setup.

Important

All information is subject to change without prior notice.

Navi Key

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Up/Down/Left/Right:

- selecting function menus and items
- · adjusting function values
- entering into/exiting from function menus


Press (OK):

- launching the On-Screen Display (OSD)
- entering submenus
- confirming a selection or setting

Hot Key

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

OSD Menus



Important

The following settings will be grayed out when HDR signals are received:

- Night Vision
- MPRT
- Low Blue Light
- HDCR
- Brightness
- Contrast
- Color Temperature
- PIP/PBP
- A.I. Vision

Gaming

1st Level Menu	2nd/3rd Level Menu	Description
	User	
	FPS	· Use Up or Down Button to select and preview mode effects.
Game Mode	Racing	· Press the OK Button to confirm and apply your mod
	RTS	e type.
	RPG	
	OFF	
	Normal	
Night Vision	Strong	This function optimizes background brightness and i s recommended for FPS games.
	Strongest	
	A.I.	
	OFF	· A.I. Vision enhances image quality by optimizing the
		contrast of images and background brightness.
		Activating A.I. Vision will affect: Affected Function Function Status
A.I. Vision		» Night Vision
	ON	» HDCR Unable to select
		» Brightness
		» MPRT Set to 0FF
	Normal	
Response Time	Fast	Setting to Fastest will reach the shortest response ti me and help improve blurred images when playing ve
	Fastest	ry fast games.
	OFF	• MPRT is available when the refresh rate is over 85H z.
		· Activating MPRT will affect:
		Affected Function Function Status
MPRT		» Response Time Unable to select
	ON	» Brightness
		» Adaptive-Sync
		» HDCR Set to 0FF
		» PIP/PBP
		» Screen Size 1:1 Set to Auto

1st Level Menu	2nd/3rd Level Menu		Description
		Left Top	
		Right Top	· Location is adjustable in OSD Menu. Press the OK Button to confirm and apply your Refresh Rate Locati
	Location	Left Bottom	
Refresh Rate		Right Bottom	On.
		Customize	This monitor follows and works at the Operating System's preset Screen Refresh Rate.
	OFF		
	ON		
		Left Top	
		Right Top	
	Location	Left Bottom	
		Right Bottom	· After setting the time, press the OK Button to activat
Alarm Clock		Customize	e the timer.
Alailli Glock	OFF		· Users have to manually restore their preset Alarm CI ock after any AC power loss and reconnection.
	15:00		ock after any 700 power loss and reconnection.
	30:00	00:01 ~ 99:59	
	45:00		
	60:00		
	None		
Screen Assistance	Icon	# # * * * * * * * * *	· Users can adjust Screen Assistance in any mode.
	Position	1	
	Reset		
	OFF		· Adaptive-Sync prevents screen tearing.
Adaptive-Sync	ON		· Activating Adaptive-Sync will affect:

Professional

1st Level Menu	2nd Level Menu	Description			
	Eco	· Use Up or Down Button to select and preview mode effects.			
	User	Press the OK Button to confirm and apply your mode type.			
Pro Mode	Anti-Blue	· Activating sRGB will affect:			
PTO Mode	Movie	Affected Function Function Status			
	Office	» Color Temperature Unable to select			
	sRGB	" Low blue Light			
	OFF	Low Blue Light protects your eyes against blue light. When enabled, Low Blue Light adjusts the screen color			
Low Blue Light	ON	temperature to a more yellow glow. · When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light. · This monitor is a Low Blue Light backlight monitor, it would decrease the blue light emitted without adjusting OSD function.			
	OFF	HDCR enhances image quality by increasing the contrast of images.			
HDCR	ON	Activating HDCR will affect: Affected Function Function Status Brightness Unable to select MPRT Set to OFF			
	OFF	· MPRT is available when the refresh rate is over 85Hz.			
		· Activating MPRT will affect:			
		Affected Function Function Status			
MPRT		» Response Time» BrightnessUnable to select			
	ON	» Adaptive-Sync» HDCR» PIP/PBP			
		» Screen Size 1:1 Set to Auto			
	OFF				
	OFF Weak				
Image Enhancement		· Image Enhancement enhances image edges to improve the ir acutance.			
Image Enhancement	Weak				

1st Level Menu	2nd/3rd Level Menu		Description	
Brightness	0-100		· Properly adjust Brighti surrounding lighting.	ness according to the
Contrast	0-100		· Properly adjust Contra	ast to relax your eyes.
Sharpness	0-5	0-5		clarity and details of images.
	Cool			
	Normal	Normal		on to select and preview mode
Calar Taran aratum	Warm		effects.	
Color Temperature		R (0-100)	Press the OK Button to confirm and apply you e type.	
	Customization	G (0-100)		
	B (0-100)			
	Auto	Auto		en Size in any mode, any reso
	4:3		lution and any screen re	
	16:9		· Activating Screen Size	
Screen Size			Affected Function	Function Status
	1:1		» MPRT » Adaptive-Sync » PIP/PBP	Set to OFF

Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		
HDMI™ 2		· Users can adjust Input Source in any mode.
DP		
	OFF	· Users can use the Navi Key to select Input Source at below s tatus:
Auto Scan	ON	While "Auto Scan" is set to "OFF" with the monitor at power saving mode;
		While "No Signal" message box is shown on the monitor.

PIP/PBP

1st Level Menu	2nd/3rd Le	2nd/3rd Level Menu		cription			
OFF							
		HDMI™ 1					
	Source	HDMI™ 2					
		DP		· PIP (Picture in Picture) allows users to simultaneously display multiple video source			
		Small		ne screen. One progra			
	PIP Size	Medium		ull screen at the same time as one or more othe programs are displayed in inset windows. • PBP (Picture by Picture) is a similar feature that t displays two input sources side-by-side on the			
PIP		Large					
FIF		Left Top	scre	• •	es side-by-side on	uie	
	Location	Right Top	I	Display Switch allows users to switch between primary and secondary input sources. If there is only one signal input, the Display Swi			
	Location	Left Bottom	'				
		Right Bottom		here is only one signa and Audio Switch will l	• • • •	Swi	
	Display Switch		· Ac	tivating PIP/PBP will a	ffect:		
Audio Switch		:h		Affected Function	Function Status		
		HDMI™ 1		» Response Time Unable to se » MPRT » Adaptive-Sync	Unable to select		
	Source 1	HDMI™ 2			Set to OFF		
PBP		DP		» HDMI™ CEC	Set to OFF & unable to select		
		HDMI™ 1			Set to Auto &		
	Source 2	HDMI™ 2		» PBP: Screen Size	unable to select]	
		DP					
	Display Swi	tch					
	Audio Switch						

Navi Key

1st Level Menu	2nd Level Menu	Description
	OFF	
	Brightness	
	Game Mode	
Up Down Left Right	Screen Assistance	
	Alarm Clock	· All Navi Key items can be adjusted via OSD Menus.
	Input Source	All Navi Rey items can be adjusted via OSD iviends.
	PIP/PBP Mode	
	Refresh Rate	
	Info. On Screen	
	Night Vision	

Settings

1st Level Menu	2nd Level Menu	Description
Language	English Français Deutsch Italiano Español Русский Português Bahasa Indonesia Türkçe (More languages coming soon)	Users have to press the OK Button to confirm and apply the Language setting. Language is an independent setting. Users' own languag e setting will override the factory default. When users set Reset to Yes, Language will not be changed.
Transparency	0~5	· Users can adjust Transparency in any mode.
OSD Time Out	5~30s	· Users can adjust OSD Time Out in any mode.

1st Level Menu	2nd Level Menu	Description
	Red	
	Green	
	Blue	
RGB LED	White	· RGB LED offers unique lighting effects for your monitor.
HOD LLD	Breathing	That LLD offers unique lighting effects for your monitor.
	Marquee	
	Rainbow	
	OFF	
Power Button	OFF	· When set to OFF, users can press the power button to tu rn off the monitor.
	Standby	When set to Standby, users can press the power button t o turn off the panel and backlight.
	OFF	· The information of the monitor status will be shown on th
Info. On Screen	ON	e right side of the screen.
	OFF	· HDMI™ CEC (Consumer Electronics Control) supports S
	ON	ony PlayStation®, Nintendo® Switch™, Xbox Series X S consoles and various audio-visual devices that are CEC-c apable.
		· If HDMI™ CEC is set to ON:
HDMI™ CEC		The monitor will automatically power on when the CEC device is turned on.
		The CEC device will enter power-saving mode when the monitor is turned off.
		When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro M ode will be automatically set to default modes and can be adjusted to users' preferred modes later.
Reset	YES	· Users can Reset and restore settings to the original OSD
Reset	NO	Default in any mode.

Specifications

Monitor	MAG 274QRFW
Size	27 inch
Curvature	Flat
Panel Type	Rapid IPS
Resolution	2560×1440 (WQHD)

Aspect Ratio		16:9		
		· Typical SDR: 400 nits		
Brightness		· Peak HDR: 400 nits		
Contrast Ratio		1000:1		
Refresh Rate		180Hz		
		· 1ms (MPRT)		
Response Time		· 1ms (GTG)		
		· Headphone Jack x 1		
I/O		· HDMI™ Connector x 2		
		· DisplayPort x 1		
View Angles		178°(H) , 178°(V)		
DCI-P3*/ sRGB		95%/123%		
Surface Treatment		Anti-glare		
Display Colors		1.07B (8 bits + FRC)		
Monitor Power Options		19V 2.58A		
External Power Supply		49W, 19V		
		100~240Vac, 50~60Hz		
Power Input Power Output		19V 2.58A		
Adjustment (Heigh	t)	0 ~ 130mm		
Adjustment (Tilt)		-5° ~ 20°		
Adjustment (Swivel)		-45° ~ 45°		
Adjustment (Pivot)		-90° ~ 90°		
Kensington Lock		Yes		
VESA Mounting		Plate Type: 75 x 75 mm		
Dimension (W x H x D)		613.5 x 402.1 x 196.5 mm		
Weight	Net	6.00 Kg		
	Gross	7.98 Kg		

Monitor		MAG 274QRFW	
Environment	Operating	 Temperature: 0°C to 40°C Humidity: 20% to 90%, non-condensing Altitude: 0 ~ 5000m 	
	Storage	· Temperature: -20°C to 60°C · Humidity: 10% to 90%, non-condensing	

^{*} Based on CIE1976 test standards.

Preset Display Modes

Important

All information is subject to change without prior notice.

Standard	Resolution		НОМІ™	DP
Full HD	1920×1080	@60Hz	V	V
		@60Hz	V	V
		@85Hz	V	V
QHD	2560×1440	@120Hz	V	V
QHD	2500×1440	@144Hz	V	
		@165Hz		V
		@180Hz		V
	720P		V	V
	1080P	@60Hz	V	V
	1000F	@120Hz	V	V
Video Timing Resolution	2160P	@30Hz	V	
	2100F	@60Hz	V	
	2560x1080P	@60Hz	V	
	2300X1000F	@120Hz	V	
PBP Mode	1280×1440 @60Hz		V	V

Troubleshooting

The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image.

- · Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centered.

• Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play.

- Check if the monitor power cable is properly connected.
- · Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- · Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- · Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- · Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated

120/240V, 20A (maximum).

- Always disconnect the power cord or switch the wall socket off if the device is left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI-provided AC adapter approved for use with this device.

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazards, keep this device away from humidity and high temperatures.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial
 chemicals to clean the device. Never pour any liquid into the opening; that could damage the device or cause
 electric shock.
- Always keep strong magnetic or electrical objects away from the device.
- If any of the following situations arise, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - · Liquid has penetrated the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and is damaged.
 - The device has obvious signs of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.

- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

TÜV Rheinland Flicker Free Certification



- TÜV Rheinland has tested this product ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.
- TÜV Rheinland has defined a catalog of tests, which sets out minimum standards at various frequency ranges. The test catalog is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 3000 Hz under various brightness settings.
- The display will not support Flicker-Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by product.)

Regulatory Notices

CE Conformity



This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of the Official Journal of the European Union.

FCC-B Radio Frequency Interference Statement



This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used to comply with the emission limits. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp. 901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828 www.msi.com

WEEE Statement



Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.

Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006. https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits the use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with the requirements of the Technical Regulation, approved by the Resolution of Cabinet of the Ministry of Ukraine as of 10 March 2017, № 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS

As of December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for many hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- · Limited use of substances harmful to the environment and health
- · Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy



- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.
- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice

Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.

Documents / Resources



RAZER MAG Series LCD Monitor [pdf] User Guide MAG Series, MAG Series LCD Monitor, LCD Monitor, Monitor

MAG Serie LCO Monitor NAO 2712899 (NCC2)

References

- ® MSI Redirect
- 🖁 <u>csr</u>
- 🖁 <u>csr</u>
- Support | MSI Global
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.