RC Willey KP-564 LED Wireless Speaker User Manual

RC Willey KP-564 LED Wireless Speaker

Contents

Parameter

Wireless version: BT 5.1
Transmission range:10m
Signal to noise ratio:>90dB
Battery Specifications: 800 mAh
Normal volume playback: 3H – 4H
Frequency response range: 120Hz-20KHz

Function keys

1. Long press on/off:
2. Mode conversion key: Short press to switch to BT/ USB/AUX/FM mode;
3. Play/Pause button:
4. Tap the previous track and long press the volume button to reduce
5. Click on the next song: Press and hold the volume to add;

   6.USB port

   7.TYPE-C port

   8.TF card jack

   9.AUX jack

Instructions for use

1. Connect the device
    1. Turn on the device to default wireless mode.
    2. Turn on the wireless device , search for the model KP-564, connect the device, and play music when the connection is successful.
2. Wireless technology, wireless adapter, wireless player used in various mobile phones.
3. Voice prompt
    1. Voice prompt when starting/shutting down.
    2. Low power consumption 3.4V, voice signal 15S off, no charging state.
    3. When there is a voice prompt, press the maximum volume, and there is no voice prompt at the minimum volume.
4. Mode change Wireless mode, USB mode, TFmode-FMmode-AUXmode
5. Click on/Off button to switch lights.Step.
6. Volume The default volume of the speaker at startup is 70%.
7. Charge and use

   This machine built-in overcharge protection circuit, can be connected to the computer or charger for a long time, About four hours to fully charge. The playback time of each battery will be different due to the size of the volume used.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Documents / Resources

	RC Willey KP-564 LED Wireless Speaker [pdf] User Manual 2BCPD-KP-564, 2BCPDKP564, kp 564, KP-564 LED Wireless Speaker, KP-564, LED Wireless Speaker, Wireless Speaker, Speaker

References

- User Manual