



REDRAGON BK-7094 Wireless Mouse and Keyboard Combo User Manual

[Home](#) » [REDRAGON](#) » REDRAGON BK-7094 Wireless Mouse and Keyboard Combo User Manual 


REDRAGON BK-7094 Wireless Mouse and Keyboard Combo



Contents

- [1 Dear user](#)
- [2 Function Overview](#)
- [3 Product Features](#)
- [4 Keyboard](#)
- [5 FAQ](#)
- [6 FCC Statement](#)
- [7 BATTERY SAFETY GUIDELINES](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)


Dear user

Thank you for choosing  product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

Function Overview

1. Left button.
2. Right button.
3. Scroll wheel& Middle button.
4. DPI button.
5. Optical sensor.
6. Battery slot.
7. SB receiver storage slot.
8. Shortcut keys.
9. Indicator LED.



O.S. Support: Win XP/Win 7/Win 8/Win 10/Win 11/ MAC 0.5.

Connection

2.4GHz wireless connection, install 1*AA battery into mouse battery slot, install 1 *AAA battery into keyboard battery slot, plug USB receiver into computer USB port, the computer will connect mouse and keyboard automatically.

Tip: If the computer didn't connect successfully, plug out USB receiver from computer USB port, take out batteries from mouse and keyboard, repeat above operation to connect the computer.

Product Features

Mouse

DPI switching: Press [DPI] button to cycling switch DPI in 800/1200/1600/2400/4000 DPI

Polling Rate: 250Hz.

Power save mode: The mouse will enter power save mode when it is out of operation over 1 minute, move or click any button to wake it up, when the mouse is out of operation over 10 minutes, the mouse will enter deep power save mode, click any button to wake it up.

Low battery warning: when mouse battery is low, the LED below the scroll wheel will twinkle, to remind change the battery.

Keyboard

Shortcut keys:

Internet browser homepage	E-mail
Play/Pause	Stop play
Previous track	Next track
Mute	Volume+
Volume-	

Low battery warning: when battery is low, the  LED will twinkle, to remind change the battery.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including , but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
DO NOT impact, bend, alter, disassemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.



CAUTION:

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

This device contains licence-exempt transmitter (s) /receiver (s) that comply with Innovation, Science and Economic Development Canada’s licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference,including interference that may cause undesired operation of the device.



Documents / Resources

	<p>REDRAGON BK-7094 Wireless Mouse and Keyboard Combo [pdf] User Manual ET7049, TUVET-7049, TUVET7049, BK-7094 Wireless Mouse and Keyboard Combo, BK-7094, Wireless Mouse and Keyboard Combo, Mouse and Keyboard Combo, Combo, Mouse, Keyboard</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.