



REDRAGON MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard Instruction Manual

[Home](#) » [REDRAGON](#) » REDRAGON MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard Instruction Manual 



MAGIC-WAND MINI PRO 3 MODES PORTABLE MECHANICAL KEYBOARD Mechanical Gaming Keyboard Operating Instructions

Contents

- [1 MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard](#)
- [2 Bluetooth Connection](#)
- [3 Function Introduction](#)
- [4 FAQ](#)
- [5 FCC Statement](#)
- [6 Documents / Resources](#)

MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

OS Support

WinXP/Nista/Win7/Win8/Win10 /Win11/Mac OS

How to connect the keyboard with multi-pie devices Wired Connection

1. Slide the ON/OFF switch on left side of the keyboard to OFF.
2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer, Press FN+T(USB) key, the LED marked with "M" twinkle in 5 times indicated the connecting successful.
3. The computer will recognize and configure the keyboard automatically.
4. Once the keyboard is powered up, charging begins. The LED marked with "M" lights on red. It will turn to white when keyboard is fully recharged.

2.4G Wireless Connection

1. Slide the OWOFF switch on left side of keyboard to ON.
2. press FN+ R(2.4G) for about 3 seconds, the LED marked with "M" flashes quickly in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically.
3. The indicator will flash on Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with "F" will be light on Red while charging, it turn to Green when charging completed(In 2.4G connecting mode).

Bluetooth Connection

1. Slide the ON/OFF switch on left side of keyboard to ON.
2. Press FN+Q/W/E (BT1/BT2/873), the LED marked with "IA" flashes in blue/Cyan/Magenta.
3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "873.0Keyboard or 875.0 KB" device. Select one of them to get connected with it automatically.
4. The indicator will flash in Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with "W" will be light on Red while charging, it turn to cyan/magenta when charging completed(In Bluetooth connecting mode) Keyboard sleep mode and power safe function In 2.4Ghz and Bluetooth connecting, to save power, there are two conditions that keyboard get into sleep mode, all LEDs and backlight turn OFF, please click any key to wake up the keyboard(Not including scroll button).
Condition #1: 3 minutes out of working.
Condition #2: 30 minutes out of working.

Function Introduction

1. With standard USB and 2.4G/13T connections, the keyboard can be used on computer without any software or

driver installation. Please noted that the software for keyboard is only available with wired connecting mode.

2. Commands of key combinations with (FN1) key

[FN1]+[Win]: Disable or enable the [Win] key. [FN1]+I(2): Select Bluetooth device one (for Bluetooth connection).

IFNINW]: Select Bluetooth device two (for Bluetooth connection).

IFN1)+IE): Select Bluetooth device three (for Bluetooth connection).

[FN1]+[R]: Change to 2.4G wireless connection. Press and hold the [FN]+(4) for 3 seconds to pair the keyboard with Its receiver.

[FN1)+[1]: Switch to Wired connection


IFN1)+1: F1 [FN1)+2: F2 [FN1)+3: F3 [FN1)+4: F4 [FN1)+5: F5 (FN1)+6: F6 fFN11+7: F7 [FN 11+8: F8

[FN11+9: F9 [FN1)+0: F10 [FN11+(-_1: F11 (FNI)+(=+): F12 IFN11111(): PRTSC [FNI)+(Q)): INSERT [FN1)+(:): HOME IFN11+r): END

Commands of key combinations with [FP42] key [FN21+(I):

Change backlight mode. There are 20 backlight effects. [FN2) + (<—): Slow down the running speed of backlight. [FN2J + (—): Add up the running speed of backlight. (FN2)+[1]: M1 (FN2)+(2): M2 [FN2M31: M3 [FN2J+(4): M4 IFN2H-(9): Browser IFN2)+[01: Search (FN21+(-_1: Calculator [FN2)+(=+): My Email [FN2NESC]: Back to default setting and delete all macro setting

Scroll button function

Scroll button  is place on right upcorner of keyboard for volume adjustment and keyboard backlight brightness adjustment function. Backlight brightness adjustment: Press I c))/ *1 key, it is light on White color, Scroll button can switch in different brightness level.

Shortcut key function



sop



Previous track



Next track



Play Pause

Macro recording function

There are 4 profiles keys from M1 to M4, each profile can assign with 4 macro keys fom 110 G4, total 20 group macro recording

1. Press FNH(F1-F4) key to seta profile aroup the key lights ON.
2. Press MR key (MR key lights ON), then press G key (1/G2/G3/G4) the key lights ON.
3. Record the desired keys.
4. Press MR key to complete recording (MR key lights OFF) For example: FN+F1—> MR — G1— ABC— MR

How to play Macro

1. Choose the profile group by press M key from M1 to M4
2. Press the Macro key from G1 to G4 For example: M1 —G1(ABC)

How to delete Macro

1. Choose the profile group by press M key from M1 to M4 (The key lights ON).
2. Press MR key (MR key lights ON)

3. Double press G keys from G1 to G4 (The key lights OFF).
4. Press MR key to save(MR key lights OFF).

How to recharge the keyboard

Find the USB A to USB type C cable in the packaging ,plug the keyboard and connect it with computer for charging, the LED indicator(M) of keyboard will be turn to red. Remark: The LED indicator (M) will turn to red when keyboard is out of battery.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable i correctly inserted into the corresponding USB port on the computer, o try another USB port on the computer.
2. If you spill quid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard s dried naturally before the next use




This device contains licence-exempt transmitter(s)/receiver(s) that comply with Imation, Science and Economic Development Canada's licence-kempt RSS(s). Operation i subject to the Soloing o conditions: (1) This device may not cause nterference. (2) This device must accept any interference, including interference that may cause undesired operation of the device

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


California Proposition 65

 **WARNING:** Risk of Cancer from (Name of one or more chemicals known to cause cancer] And Reproductive Harm From (Name of one or more chemicals known to cause reproductive toxicity) Exposure –



**REDRAGON
MAGIC-WAND MINI PRO
3 MODES PORTABLE MECHANICAL KEYBOARD
Mechanical Gaming Keyboard Operating Instructions**

Documents / Resources

	<p>REDRAGON MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard [pdf]] Instruction Manual TUVET-8844A, TUVET8844A, et 8844a, ET-8844A, MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard, MAGIC-WAND Mini Pro, 3 Modes Portable Mechanical Gaming Keyboard, Portable Mechanical Gaming Keyboard, Mechanical Gaming Keyboard, Gaming Keyboard, TUVET-8844A, TUVET8844A, et 8844a, ET-8844A, MAGIC-WAND Mini Pro 3 Modes Portable Mechanical Gaming Keyboard, MAGIC-WAND Mini Pro, 3 Modes Portable Mechanical Gaming Keyboard, Portable Mechanical Gaming Keyboard, Mechanical Gaming Keyboard, Gaming Keyboard, Keyboard</p>
---	---