

RefStuff RefScorer Digital Watch v2.021 User Guide

Home » RefStuff » RefStuff RefScorer Digital Watch v2.021 User Guide Ta

Contents

- 1 RefStuff RefScorer Digital Watch v2.021
- **2 NEW FEATURES**
- 3 Old School Classic with New Cool Tech
- 4 The 6 Watch Face Modes/Features
- 5 SETTING AND SELECTING VIBRATION AND BEEP ALERTS
- **6 REFSCORER MATCH DAY SCORE MODE/SCREEN**
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts



RefStuff RefScorer Digital Watch v2.021



NEW FEATURES

The Incredible Interchangeable Different

Coloured Top Rings/Bezels!! – personalise and pair your watch to match the colour of your Referee shirt or outfit that you are wearing for your match!

Count Continue Mode in the Match Day Score Screen for the referee who wants their timer to continue counting to 90 mins after half time! This is in addition to the already fantastic choices of Count Up or Count Down Match Day Timers.

New User Set Time you choose your own match length. If your match length is 17mins 30 secs then you can now program any time yourself!

Additional Pre Set Match Day Timers 3,60 and 90 minutes added to the existing ones of 5,10,12,15,20,25,30,35,40 and 45 mins. Team Kick Off Reminder easily set on the Match Day Score Screen.

Interval Training Timer Feature/Mode for HIIT training, sprints and counting reps with 1,2,3,4,5 and 10 minute pre set timer options programmed in, plus the option to choose your own User Set Time too.

Vibrate& Beep Alets for the Match Day now operational from Normal Time Screen for easier access Steps, Distance and Calorie Tracking with the NEW additional Pedometer Feature/Mode!!!

Daily Activity Goal – count and record your steps each day and have it stored in memory for a week!

Amazing new watch pouch case – use it again and again to store your watch, or whistles and coins and anything else you choose!

Team Kick Off Reminder – easily set on the Match Day Score Screen. RefStuff- Your PERFECT PARTNER for Refereeing. Technology That You Can Count On.

DON'T FORGET... all this is in addition to being able to select Home and Away team colours AND Record the Score of the Game! – the WORLDS FIRST and only digital watch to do this!!Already packed with many referee-specific features like preset match timers for 3, 5, 10, 12, 15, 20, 25, 30, 35, 40, 45, 60 and 90 minutes, your choice of Count-Up or Count-Down time in RefScorer Mode, auto-elapsing extra/added time for when the regulation time is over as well as your optional choice of vibration, beep or both at the same time! 1/100 Second Stop Watch, Daily Alarm Timer, 12/24 Hour Formats, Current/Actual time, (Date, Day, Month, Year), Backlight, Water Resistant to 50m, Long Lasting Battery, 1 Year Warranty. With its all-weather construction and groundbreaking, gamechanging features, this is by far the most innovative watch available to all referees around the world!

RefScorer Digital is an absolute groundbreaking game changer in referee watches and now comes packed
with even more incredible features. In addition to it being the worlds first and only digital watch that allows you
to select home and away team colours AND record the score throughout the match!

The INCREDIBLE Interchangeable Different Coloured Top Rings/Bezels!!! – personalise and pair your watch to match the colour of your Referee shirt or outfit that

• you are wearing for your match! The RefScorer Digital Watch v2.021 will come supplied with the Silver & Black Top Ring/Bezel as seen in the pictures. Additional Colours will be available to purchase in packs of 5.



SPECIAL GOLD TOP RING/BEZEL! – will you be the lucky recipient of one of only 100 Special GOLD Top Ring/Bezels hidden inside the watch pouch cases?!!?



• Find one and take a picture, tag us on all social media @refscorer and you'll be sent a one time huge discount code to be used in our store!

The 6 Watch Face Modes/Features





SETTING AND SELECTING VIBRATION AND BEEP ALERTS

Choice of vibration and/or beep for the match day sounds can now be easily activated on the normal time screen by simply pressing the adjust and the select button



- Vibrate & Beep Alerts for Match Day use are easily selected from the Normal Time Mode/Screen. Single press of the SELECT button turns the Vibrate function on/off.
- Single press of the ADJUST button turns the Beep function on/off.
- You can also operate the Vibrate & Beep Alerts from the Alarm Time Mode/Screen. Hold the ADJUST button for 3 seconds and then the screen will flash. Scroll through
- the features pressing the MODE button. Here you can set an alarm, and also toggle the Vibrate & Beep Alerts on/off. *Press the Start/Stop button to toggle the Alarm on/off.



NORMAL TIME MODE/SCREEN



The Normal Time Mode/Screen allows you to set the Time – Date, Day, Month, Year, choose 12/24 Hour Format, and even have an hourly chime alert or toggle the button sound on/off. Hold the ADJUST button for 3 seconds and then the screen will flash. Scroll through the features pressing the MODE button and press SELECT and RESET to change the values.

REFSCORER MATCH DAY SCORE MODE/SCREEN



Team Kick Off Reminder – Select the Home or Away Team, smartly indicated with the whistle icon for whichever Team wins the Kick Off of the match, simply by pressing ADJUST for the Home Team or SELECT for the Away Team. Easy!

Count-Down, Count-Up or Count Continue Timers – Select your choice by simply pressing the RESET button.



NEW User Set Time – YOU choose your own match length. If your match length is 17mins 30 secs then you can now program ANY TIME yourself! Scrolling through the Preset Timers, you will see one that says USER. Select this option and program your time! Press the SELECT button to increase the minutes and the RESET button to decrease the minutes. Press the MODE button to switch across to the seconds and repeat the process.

Selecting Home and Away team colours – Hold the ADJUST button for 3 seconds and then the screen will flash with the 'H' letter, allowing you to select the Home Team colour. Press the SELECT button to switch across to the Away Team and the screen will flash with the 'A' letter allowing you to select the Away Team colour. Press the MODE button and the Preset Colour Choices will flash. Press the SELECT or RESET buttons to scroll through them until you find your choice. Press the ADJUST button to lock in your choice and return to the Match Day Score Mode/Screen.



When you scroll through the Preset Colour Choices, you will also see the 'USER' option. This smart feature allows you to personalise the letters for your own choice; maybe program it for team names like MAN v LIV or countries like ENG v USA or even people's names like KEV v JAS if you're using the feature for some friendly fun competition! When 'USER' is flashing, press the START/STOP button and the first digit/letter will flash. Press the SELECT or RESET buttons to scroll through until you find your letter of choice. Press the MODE button to switch across to the next letter and repeat the process. Press the ADJUST button to lock in your choice and return to the Match Day Score Mode/Screen.

Count Continue Mode in the Match Day Score Screen



for the referee who wants their timer to continue counting to 90 mins after half time! This is in addition to the already fantastic choices of Count Up or Count Down Match Day Timers.

time! Select your match time from the extensive choice of Preset Timers, or program your own with the NEW User Set Time Feature. Whether you choose the conventional 45 minutes timer, or 5 minutes, or even program it yourself to 17 minutes and 30 seconds, at the end of the half, the timer will pause, and upon restart for the second half, the timer will continue counting UP the same amount of minutes chosen, so to 90, 10 and 35 using the three examples listed above!

SCORING OF THE MATCHES/GAMES IN THE REFSCORER MATCH DAY SCORE MODE/SCREEN



When all the pre match information that you need has been programmed into the RefScorer Digital Watch, and the Team Kick Off Reminder has been set just before you blow your whistle to start the match/game, you're now in RefScorer Match Day Mode – The Timer has started and the match/game is in play! When a goal/point is scored, simply press the ADJUST button to add a goal/point for the Home Team and press the SELECT button to add a goal/point for the Away Team. If you make a mistake, you can correct this and delete/erase a goal/point by pressing the MODE button for the Home Team and the RESET button for the Away Team. At Half Time, the timer will pause and the score stays on the screen. A short gentle press of the RESET button resets the timer ready for the second half, but a long press and hold of the RESET button will erase the score and time and reset the screen. (do this after Full Time!)

INTERVAL TRAINING TIMER MODE/SCREEN



This Mode/Feature can be used by Fitness Coaches and Personal Trainers for HIIT training, sprints and counting reps on squats, lifts, pull ups or push ups etc. 1,2,3,4,5 and 10 minute preset timer options are programmed in, plus you have the option to choose your own User Set Time too. Hold the SELECT button for 3 seconds and then the screen will flash. Scroll through the Preset Timers by pressing the START/STOP button until you find your choice. Press the ADJUST button to lock in your choice and return to the Interval Training Mode/Screen. User Set Time – YOU choose your own training time. Scroll through the Preset Timers and you will see one that says USER. Select this option and program your time! Press the SELECT button to increase the minutes and the RESET button to decrease the minutes. Press the MODE button to switch across to the seconds and repeat the process. Press the ADJUST button to lock in your choice and return to the Interval Training Mode/Screen. Count-Down or Count-Up Timer – Select your choice by simply pressing the RESET button. Press the START/STOP button to START the timer and press the SELECT button to count the reps done.

When the timer runs out, the watch will beep and/or vibrate, and a short press of the RESET button will prepare the timer to start again, keeping the score/reps recorded on the screen. To clear the screen and start again, hold down the RESET button for a long press of around 3 seconds and this will erase the score/reps recorded.

PEDOMETER MODE/SCREEN

Measure Your Steps, Distance and Calorie Tracking! Daily Activity Goal – count and record your steps each
day and have it stored in memory for a week! To START the Pedometer Mode/Feature, press the START/STOP
button ensuring that the screen displays PDM RUN. If the screen reads PDM STP then the watch will not
record any data.



Programming the watch for your own Weight, Height and Stride.

Ensure the screen reads PDM STP and then hold the ADJUST button for 3 seconds and the the screen will flash. First program your WEIGHT, measured in KG. Press the SELECT button to increase the weight and the RESET button to decrease the weight. Press the START/STOP button to switch across past the decimal point and repeat the process. Press the MODE button to now program your HEIGHT, measured in CM. Press the MODE button to now program your STRIDE, measured in CM. To measure your Stride (or Step Length), we suggest that you take 10 steps, measure the distance from start to finish, and divide by 10. The result is your Stride Length. *To program HEIGHT and STRIDE, repeat the steps above detailed when describing how to program your WEIGHT. Press the MODE button one more time to now program your GOAL for Daily Steps. Press the SELECT button to increase the steps in increments of 1000 and press the RESET button to decrease the steps chosen. Press the ADJUST button to lock in your programmed selections and return to the Pedometer Mode/Screen. Then remember to START the Pedometer Mode/Feature, press the START/STOP button ensuring that the screen displays PDM RUN. *With the screen displaying PDM RUN, press and hold the ADJUST button for 1-2 seconds, and the screen will now show you the Recorded Daily Data. Press the SELECT button to scroll through the Steps, Distance and Calorie Records for 'd1' (day 1). Press the RESET button to switch to 'd2' (day 2) and scroll through the Records again with the SELECT button. Repeat these steps to view the information stored for each day. Press the ADJUST button once more to return to the Pedometer Mode/Screen.

STOPWATCH TIMER MODE/SCREEN



- Measured in 1/100 Second. Press the START/STOP button to start the Stopwatch. Press the START/STOP button to pause the Stopwatch. To clear the screen and start again, hold down the RESET button for a long press of around 3 seconds and this will erase the stopwatch timer screen. TO DOWNLOAD A MORE
- COMPREHENSIVE USER INSTRUCTION INFORMATION MANUAL, AND ALSO VIEW OUR EASY TO FOLLOW DEMONSTRATION VIDEOS ON OUR RefStuff YouTube CHANNEL. PLEASE GO TO OUR WEBSITE:
- WE HOPE THAT YOU ENJOY USING THE RefScorer Digital Watch v2.021 WE THANK YOU FOR YOUR SUPPORT USING OUR PRODUCTS. PLEASE
- LEAVE US A REVIEW ON OUR WEBSITE OR ON AMAZON IF YOU PURCHASED FROM THERE, AND PLEASE CHECK OUT OUR OTHER PRODUCTS AVAILABLE IN THE RefStuff RANGE.



#groundbreaking #gamechanging #gamechanger<u>www.RefScorer.com</u> RefStuff Products are Carefully Designed, By a Referee, For Referees, Paying Fine Attention to Detail. RefStuff – Your PERFECT PARTNER for Refereeing. Technology That You Can Count On.

Documents / Resources



RefStuff RefScorer Digital Watch v2.021 [pdf] User Guide
RefScorer, Digital Watch v2.021, RefScorer Digital Watch v2.021, RefScorer Digital Watch, Digital Watch

References

• 9 Home | RefStuff

Manuals+