

renkforce 2621178 9 In 1 USB-C Multiport Hub User Manual

Home » renkforce » renkforce 2621178 9 In 1 USB-C Multiport Hub User Manual



Contents

- 1 renkforce 2621178 9 In 1 USB-C Multiport Hub
- 2 Intended use
- 3 Delivery contents
- 4 Latest product information
 - 4.1 Description of symbols
- **5 Safety instructions**
 - 5.1 General
- 6 Operating environmen
- 7 Operation
- 8 Cleaning and care
- 9 Technical data
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

renkforce 2621178 9 In 1 USB-C Multiport Hub



Intended use

- The product is a USB-C® multiport hub.
- The product is intended for indoor use only. Do not use it outdoors.
- Contact with moisture must be avoided under all circumstances.
- If you use the product for purposes other than those described, the product may be damaged. Improper use can result in short circuits, fires, or other hazards.
- The product complies with the statutory national and European requirements.
- For safety and approval purposes, you must not rebuild and/or modify the product.
- Read the operating instructions carefully and store them in a safe place. Make this product available to third parties only together with the operating instructions.
- All company names and product names are trademarks of their respective owners. All rights reserved. The terms HDMI, HDMI High-Definition Multimedia Interface,
- HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.
- USB4®, USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

Delivery contents

- Product
- · Operating instructions

Latest product information

Download the latest product information at www.conrad.com/downloads or scan the QR code shown. Follow the instructions on the website.

Description of symbols

• The symbol warns of hazards that can lead to personal injury.

• Read the operating instructions carefully.

Safety instructions

Read the operating instructions carefully and especially observe the safety information. If you do not follow the safety instructions and information on proper handling, we assume no liability for any resulting personal injury or damage to property. Such cases will invalidate the warranty/guarantee.

General

- The product is not a toy. Keep it out of the reach of children and pets.
- Do not leave packaging material lying around carelessly. This may become dangerous playing materials for children.
- If you have questions that remain unanswered by this information product, contact our technical support service or other technical personnel.
- Maintenance, modifications and repairs must only be completed by a technician or an authorized repair center.

Handling

Handle the product carefully. Jolts, impacts or a fall even from a low height can damage the product.

Operating environmen

- Do not place the product under any mechanical stress.
- Protect the appliance from extreme temperatures, strong jolts, flammable gases, steam and solvents.
- Protect the product from high humidity and moisture.
- Protect the product from direct sunlight.

Operation

- Consult an expert when in doubt about the operation, safety or connection of the product.
- If it is no longer possible to operate the product safely, take it out of operation and protect it from any accidental use.
- DO NOT attempt to repair the product yourself. Safe operation can no longer be guaranteed if the product:
 - · is visibly damaged,
 - is no longer working properly,
 - has been stored for extended periods in poor ambient conditions or
 - has been subjected to any serious transport-related stresses.

Connected devices Also observe the safety and operating instructions of any other devices which are connected to the product.

Cleaning and care

Important:

- Do not use aggressive cleaning agents, rubbing alcohol, or other chemical solutions. They damage the housing and can cause the product to malfunction.
- Do not immerse the product in water.
- Disconnect the product from the power supply.
- Clean the product with a dry, fiber-free cloth.

Disposal This symbol must appear on any electrical and electronic equipment placed on the EU market. This symbol indicates that this device should not be disposed of as unsorted municipal waste at the end of its service life.

Owners of WEEE (Waste from Electrical and Electronic Equipment) shall dispose of it separately from unsorted municipal waste. Spent batteries and accumulators, which are not enclosed by the WEEE, as well as lamps that can be removed from the WEEE in a non-de-structive manner, must be removed by end users from the WEEE in a non-destructive manner before it is handed over to a collection point.

Distributors of electrical and electronic equipment are legally obliged to provide free take-back of waste.

Conrad provides the following return options free of charge (more details on our website):

- · in our Conrad offices
- · at the Conrad collection points
- at the collection points of public waste management authorities or the collection points set up by manufacturers or distributors within the meaning of the ElektroG

End users are responsible for deleting personal data from the WEEE to be disposed of. It should be noted that different obligations about the return or recycling of WEEE may apply in countries outside of Germany.

Technical data

- Host computer interface: USB-C® Input: 5 V/DC, 3A (15 W)
- 1x USB-C® (PD 3.0) port: Input: max. 100 W, 20 V/DC, 5 A Output: max. 87 W upstream charging to host device
- 1x USB-A 3.0 port: max. 5 Gbps, 900 mA
- 2x USB-A 2.0 ports: max. 480 Mbps, 500 mA
- 1x Ethernet port: RJ45 10/100 Mbps
- 1 x HDMI port: 4 K (3840 x 2160) @ 30 Hz,
- 1x SD card slot: max. 512 GB, read/write max. 480 Mbps
- 1x microSD card slot: max. 512 GB, read/write max. 480 Mbps
- 1x Audio jack: 3.5 mm audio out
- Supported OS* (or above): Windows® 7, MacOS 10.8, Liniux 4.0, iPadOS 13, Android 7.0
- Operating condition: 0 to +45 °C, 10 85 % RH (non-condensing)
- Storage conditions: -20 to +70 °C, 10 85 % RH (non-condensing)
- Dimensions (W x H x D): approx. 40 x 121.5 x 14 mm
- · Weight: approx. 74 g

This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com). All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing. Copyright by Conrad Electronic SE.

Documents / Resources



<u>renkforce 2621178 9 In 1 USB-C Multiport Hub</u> [pdf] User Manual 2621178, 2621178 USB-C Hub, 2621178 9 In 1 USB-C Multiport Hub, 9 In 1 USB-C Multiport Hub, USB-C Multiport Hub

References

- Conrad Electronic » Your Sourcing Platform
- © Document

Manuals+,