Home » renkforce » renkforce RF-DKS-904 USB C Multiport Hub Instruction Manual



renkforce RF-DKS-904 USB C Multiport Hub Instruction Manual

Contents

- 1 RF-DKS-904 USB C Multiport Hub
 - 1.1 1 Intended use
 - 1.2 2 Delivery contents
 - 1.3 3 Operating Instructions for download
 - 1.4 4 Description of symbols
 - 1.5 5 Safety instructions
 - 1.6 5.1 General
 - 1.7 5.2 Handling
 - 1.8 5.3 Operating environment
 - 1.9 5.4 Operation
 - 1.10 5.5 Connected devices
 - 1.11 6 Cleaning and care
 - 1.12 7 Disposal
 - 1.13 8 Technical data
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**

RF-DKS-904 USB C Multiport Hub



Operating Instructions USB-C© Multiport Hub (9-in-1)

Item no: 2999018

1 Intended use

The product is a USB-C® multiport hub.

The product is intended for indoor use only. Do not use it outdoors.

Contact with moisture must be avoided under all circumstances.

If you use the product for purposes other than those described, the product may be damaged.

Improper use can result in short circuits, fires, or other hazards.

The product complies with the statutory national and European requirements.

For safety and approval purposes, you must not rebuild and/or modify the product.

Read the operating instructions carefully and store them in a safe place. Make this product available to third parties only together with the operating instructions.

All company names and product names are trademarks of their respective owners. All rights reserved.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

USB4®, USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

2 Delivery contents

- Product
- Operating instructions

3 Operating Instructions for download

Use the link www.conrad.com/downloads (alternatively scan the QR code) to download the complete operating instructions (or new/current versions if available). Follow the instructions on the web page.

4 Description of symbols

The symbol warns of hazards that can lead to personal injury.

Read the operating instructions carefully.

5 Safety instructions

Read the operating instructions carefully and especially observe the safety information. If you do not follow the safety instructions and information on proper handling, we assume no liability for any resulting personal injury or damage to property. Such cases will invalidate the warranty/guarantee.

5.1 General

- The product is not a toy. Keep it out of the reach of children and pets.
- Do not leave packaging material lying around carelessly. This may become dangerous playing material for children.
- If you have questions which remain unanswered by this information product, contact our technical support service or other technical personnel.
- Maintenance, modifications and repairs must only be completed by a technician or an authorised repair centre.

5.2 Handling

■ Handle the product carefully. Jolts, impacts or a fall even from a low height can damage the product.

5.3 Operating environment

- Do not place the product under any mechanical stress.
- Protect the appliance from extreme temperatures, strong jolts, flammable gases, steam and solvents.
- Protect the product from high humidity and moisture.
- Protect the product from direct sunlight.

5.4 Operation

- Consult an expert when in doubt about the operation, safety or connection of the product.
- If it is no longer possible to operate the product safely, take it out of operation and protect it from any accidental use. DO NOT attempt to repair the product yourself. Safe operation can no longer be guaranteed if the product:
- is visibly damaged,
- is no longer working properly,
- has been stored for extended periods in poor ambient conditions or

- has been subjected to any serious transport-related stresses.

5.5 Connected devices

■ Also observe the safety and operating instructions of any other devices which are connected to the product.

6 Cleaning and care

Important:

- Do not use aggressive cleaning agents, rubbing alcohol or other chemical solutions. They damage the housing and can cause the product to malfunction.
- Do not immerse the product in water.
- 1. Disconnect the product from the power supply.
- 2. Clean the product with a dry, fibre-free cloth.

7 Disposal

This symbol must appear on any electrical and electronic equipment placed on the EU market.

This symbol indicates that this device should not be disposed of as unsorted municipal waste at the end of its service life.

Owners of WEEE (Waste from Electrical and Electronic Equipment) shall dispose of it separately from unsorted municipal waste. Spent batteries and accumulators, which are not enclosed by the WEEE, as well as lamps that can be removed from the WEEE in a non-destructive manner, must be removed by end users from the WEEE in a non-destructive manner before it is handed over to a collection point.

Distributors of electrical and electronic equipment are legally obliged to provide free take-back of waste. Conrad provides the following return options free of charge (more details on our website):

- in our Conrad offices
- at the Conrad collection points
- at the collection points of public waste management authorities or the collection points set up by manufacturers or distributors within the meaning of the ElektroG

End users are responsible for deleting personal data from the WEEE to be disposed of. It should be noted that different obligations about the return or recycling of WEEE may apply in countries outside of Germany.

8 Technical data

Host computer interface	USB-C® max. 5Gbps
Input: 5 V/DC, 3A (15 W)	
1x USB-C® (PD 3.0) port	. Input: max. 100 W, 20 V/DC, 5 A
Output: max. 87 W upstream charging to host device	
3x USB-A 3.0 port (blue)	max. 5 Gbps, 900 mA
1x Ethernet port	RJ45 10/100/1000 Mbps
1 x HDMI port	4 K (3840 x 2160) @ 60 Hz
1x SD card slot	max. 512 GB, read/write max. 480 Mbps
1x microSD card slot	max. 512 GB, read/write max. 480 Mbps
1x Audio jack	3.5 mm audio out
Supported OS* (or above)	. Windows® 7, MacOS 10.8, Liniux 4.0, iPadOS 13, Android 7.0
Operating conditions	0 to +45 °C, 10 – 85 % RH (non-condensing)
Storage conditions	20 to +70 °C, 10 – 85 % RH (non-condensing)

Dimensions (W x H x D) approx. 45 x 130.1 x 14 mm Weight approx. 76.5 g

This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com). All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in

electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited.

This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

*2999018_V1_0124_dh_mh_en 9007200425360139-2 I2/O1 en

Documents / Resources



renkforce RF-DKS-904 USB C Multiport Hub [pdf] Instruction Manual RF-DKS-904 USB C Multiport Hub, RF-DKS-904, USB C Multiport Hub, Hub

References

- Conrad Electronic » All parts of success
- C Download center
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.