



# RETEVIS RB39 Bluetooth Two Way Radio User Manual

[Home](#) » [RETEVIS](#) » [RETEVIS RB39 Bluetooth Two Way Radio User Manual](#) 

## Contents

- [1 RETEVIS RB39 Bluetooth Two Way Radio](#)
- [2 Warning](#)
- [3 LED indicators](#)
- [4 Optional Functions](#)
- [5 Technical Specifications](#)
- [6 Factory default settings](#)
- [7 RF ENERGY EXPOSURE AND PRODUCT SAFETY GUIDE FOR TWO-WAY RADIOS](#)
- [8 FCC Requirements](#)
- [9 RF Exposure Compliance and Control Guidelines and Operating Instructions](#)
- [10 Safety Operation](#)
- [11 Guarantee](#)
- [12 Documents / Resources](#)
  - [12.1 References](#)
- [13 Related Posts](#)



**RETEVIS RB39 Bluetooth Two Way Radio**



## Warning

Please read this manual carefully before using this walkie-talkie.

- Please do not charge this walkie-talkie in areas that are flammable, explosive and where radio communication is prohibited (e.g. petrol stations, gas stations, airports, etc.).
- Please do not operate this walkie-talkie without a licence in areas where it is prohibited by government law.
- Please make sure that the walkie-talkie is protected from sunlight and avoid placing it near any heating device.
- Please make sure this radio avoids any dusty, humid and water splashed place, and also avoids to put it near any heating device
- If the walkie-talkie smells or smokes, please remove the battery pack from the walkie-talkie immediately, and then contact your nearest dealer.
- The repair of this walkie-talkie is the responsibility of a professional technician and is not be dismantled by yourself.


## Charging precautions

- The charging port is a Type-C USB port.
- When charging the whole walkie-talkie, it is recommended to switch off the walkie-talkie.
- For optimum battery performance use, please charge the battery for at least 5 hours for the first time.
- Please do not charge the battery for a long time as this will shorten the life of the battery. When the battery is

fully charged, please stop charging promptly.

- This charger will only charge the battery of this walkie-talkie, please do not charge other batteries as this will damage the charger and the battery.
- The battery pack should be stored in a cool, dry place after it has been fully charged. Please do not place the battery near fire or in the sun as this is a safety hazard.
- It is not recommended to transmit the walkie-talkie while the it is being charged.
- It is normal for the battery to heat up slightly during the charging process.

## Function Operations



1. Antenna
2. Transmit button (PTT)
3. Menu button/programmable button
4. + button: short press for channel increase/long press for scanning function
5. – button: short press for channel decrease/long press for alarm function
6. Charging base contact point
7. Speaker
8. Microphone
9. Type-C USB charging port
10. Headphone/programming jack (Jianwu double-pin jack)
11. Power button /LED light

## LED indicators

LED indicator	Walkie-talkie working status
Green light flashes slowly (5sec)	Standby status
Green light flashes slowly (200ms)	Scan Status
Red light is always on	Being transmitted
Green light is always on	Being received
Red light flashes quickly	Programming software is being operated to read data from the radio
Green light flashes quickly	Programming software is being operated to write data to the radio
Red light flashes quickly	One-touch frequency transmit mode
Green light flashes quickly	One-touch frequency receive mode
Red and green lights flash alternately	Being charged
Green light double flashing	Fully charged
Red light double flashing	Low power condition

## Optional Functions

### 1. Power on / off

- In the off state, press and hold the power button for 3 seconds to turn on the radio and broadcast the current channel number and the current battery level.
- In the on state, press and hold the power button for 3 seconds to switch off the radio and sound the off tone.

### 2. Volume adjustment

When the walkie-talkie is in standby or receiving state, short press the power button to adjust the volume of the radio, and at the same time broadcast the current volume level. The volume can be cyclically adjusted to 0-5 levels

**Note:** when the volume level is 0, at this time the walkie-talkie reception for the mute mode.

### 3. Transmitting/receiving

- When the walkie-talkie is in standby, press and hold the transmit button (PTT) to transmit the signal of the current channel and the LED lights up red.
- Release the transmit button (PTT) to receive the signal from the same channel, the speaker sounds the call and the LED lights up green.

**Note:**

- When the walkie-talkie is transmitting, please keep the walkie-talkie in a vertical position and keep the microphone at a distance of 2.5-5 cm from the mouth. When transmitting, please keep the walkie-talkie at least 2.5 cm from your head or body.
- During the use of the walkie-talkie, there is no need to perform multiple switch-on and switch-off

actions while adjusting the volume to a level suitable for your hearing.

**Before talking on the walkie-talkie:**

- Please set the transmitter and receiver to the same frequency point.
- Please set the transmitter and receiver to the same CTCSS/DCS for the channel you want to talk to.

**4. Channel selection**

When the walkie-talkie is in standby mode, short press the [+] or [-] button to select the channel and broadcast the current channel number.

**5. CTCSS/DCS**

This radio supports a total of 260 CTCSS/DCS. It can be set 50 CTCSS and 105\*2 DCS (N and I phases) in the programming software (CPS).

**6. High / Low power**

The user can set the power level of each channel to high or low. High power enables communication with radios at relatively long distances; and the low power enables communication with radios at close distances.

- The power level of the channel can be set to high or low by the programming software (CPS).
- The power level of the channel can also be set to high or low by using the menu keys.

**Steps:**

- short press the menu button to cycle, select the power menu Secondly, the transmit power is switched between high (2W) or low (0.5W) by short pressing the [+] or [-] button.
- short press the transmit button (PTT) to exit the setting and enter standby mode.

**Note:** Channels 8-14 power levels are set to low and cannot be changed.

**7. Call Tone**

This radio supports the Call Tone function. When the radio is in standby, double-clicking the [PTT] button will send a call tone. During the sending process, the local speaker can hear the call tone, and other radio on the same channel can receive the call tone.

**Step:**

- Short press the menu button to cycle, select the call tone menu
- Short press the [+] or [-] button to select the call tone, there are 1-5 types to choose from.
- Short press on the transmit button (PTT) to exit the setting and enter standby mode.

**8. Roger Beep**

This radio supports the Roger Beep function, which sends an audible signal to the other party that the transmission has ended. When this function is set to on, the Roger Beep can be heard on the loudspeaker when the radio is finished.

1. Short press the menu button to cycle and select the end sound menu;
2. Short press the [+] or [-] button to set the transmission end tone on or off
3. Short press the transmit button (PTT) to exit the setting and enter standby mode.

**9. Key Beep**

This radio supports the Key Beep function. When this function is set to on, a key beep will be emitted when the radio key is operated to indicate whether the user's operation is valid.

- Short press the menu button to cycle, select the button beep menu
- Short press the [+] or [-] button to set the key tone on or off.
- Short press the transmit button (PTT) to exit the setting and enter standby mode.

**10. Channel Lock**

- Press and hold the [+] and [-] keys at the same time, the loudspeaker will send two beeps and the

channel lock will be on, and then the channel cannot be adjusted.

- Press and hold the [+] and [-] keys at the same time again, the speaker will send one beep and the channel lock will be turned off, then the channel can be adjusted.

**Note:** The above tones are valid when the key tone is on.

#### 11. Keylock function

- Press and hold the menu key and the [-] key of the radio at the same time, the speaker will send a key lock tone and the key lock function will be turned on. At this time, except for the [PTT] key, all other keys cannot be operated. A “beep” key failure tone will sound when pressed
- Press and hold the menu key and or [-] key of the radio at the same time again, the speaker will sound the unlock tone and the lock key function will be turned off, all the keys on the radio can be operated normally.

**Note:** The above tones are valid when the key tone is on.

#### 12. Channel Scan (Carrier Scan)

1. In standby mode, press and hold the [+] key for more than 3 seconds to activate the channel scan function. When a valid signal is scanned and reception stops, press the [+] key again to continue scanning.
2. Press and hold the [+] key again for more than 3 seconds to turn off the channel scanning function.

#### 13. VOX

When the vox is switched on, the radio microphone will detect a loud enough sound input and the radio will automatically start transmitting, and will exit the transmitting mode when it stops speaking.

- The vox can be set on/off in the programming software (CPS) (menu ticked as on, default unticked).
- The vox can also be set on/off through the menu keys.

##### Steps:

- Firstly, Short press the menu button to cycle, select the voice-activated menu. Secondly, Short press the [+] or [-] button to set the voice control on (the corresponding voice control level is on) or off.
- Finally, short press the transmit button (PTT) to exit the setting and enter standby mode.

#### 14. VOX Levels

The voice control level can be set to: 0-5, with level 5 being the most sensitive and level 3 being the default.

- The VOX level can be set in the programming software (CPS).
- The VOX level can also be set through the menu keys.

##### Steps:

- Short press the menu button to cycle and select the voice-activated menu.
- Short press the [+] or [-] button to set the voice control level.
- Short press the launch button (PTT) to exit the setting and enter the standby state.:

#### 15. Compandor

- The Compandor function can be set on/off in the programming software (CPS) (menu ticked as always on, default ticked).
- The programmable keys can also be preset to the Compandor function in the programming software (CPS), and Compandor function can be switched on or off by pressing and holding the programmable key.

#### 16. Monitor

- Monitoring can be set on/off via the programming software (CPS) (menu ticked as always on, default unchecked).
- The programmable keys can also be preset to the listening function in the programming software. In

standby mode, press and hold the programmable key to switch on the listening function. In listening mode, a long press on the programmable key will exit the listening function.

#### **17. Time Out Timer(TOT)**

To prevent some users from occupying the same channel for a long period of time, the user can set the transmit time limit function to be enabled. When the user has been transmitting continuously on the current channel for a set amount of time, the radio will stop transmitting and a transmit time limit tone will be sounded. The transmit time limit can be set in the programming software, default 60 seconds.

#### **18. One-touch frequency matching function**

This product can support one key frequency pairing function, which can synchronise the channel information of one radio to other radios by operating one key frequency pairing.

- In standby mode, press and hold the menu key and [+] key at the same time for 3 seconds, and hear a “beep” tone to enter the radio into the one-touch frequency reception mode, the light green flashing rapidly.
- In standby mode, press and hold the menu key and the [+] key for 5 seconds at the same time, hear two “beeps” and the radio enters the one-touch transmit mode, the indicator light flashes red quickly. The transmitter will transmit the channel information to the other radios which have already entered the one-touch receiving mode.
- After the transmitter has successfully transmitted and the receiver has successfully received, all radios will exit the one-touch mode and the channel information will be the same.

#### **19. Busy channel lock**

- Set up in the programming software and set “ On ” or “ Off ” in the channel information busy lock.
- When “On” is selected, if another radio signal is received on that channel, pressing the PTT key will not transmit and a “drop” sound will be emitted.
- When “ Off ” is selected, the above situation does not occur.

#### **20. Battery Save function**

In order to extend the battery life, users can turn on the battery saving mode. When the Battery Save function is switched on, if no valid signal is received or no key operation is performed within 10 seconds, the radio will automatically enter the power saving mode. In the power saving mode, the radio can transmit by pressing the [PTT] key or can receive normally when an radio signal is detected.

#### **21. Low battery alarm function**

- When the battery level is lower than 25%, the walkie-talkie will send out a low battery warning tone, and it will sound once every 30 seconds. Please charge the battery as soon as possible. At this time, the walkie-talkie will prohibit the user from transmitting, and can only be in standby and receiving modes. Please replace the battery with a new one or charge the battery.
- When the battery power falls below 5%, the radio will automatically switch off.

#### **22. Alarm function: local alarm + remote alarm**

Press and hold the [-] button, the local and remote walkie-talkie alarms will sound at the same time: after 8s, the alarm sound ends, and the walkie-talkie speaker is turned on to send information; after 22s, the alarm mode exits.

## **Technical Specifications**

### **GENERAL**

GENERAL	Frequency Range	FRS
	Rated Voltage	3.7V DC
	Memory Channel	22
	Frequency Sensitivity	±0.5ppm
	Antenna Impedance	50Ω
	Operation Temperature Range	-20°C~+55°C

## TRANSMITTER

TRANSMITTER	RF power	≤2W
	Modulation type	FM
	Modulation distortion	<5%
	Adjacent channel power	≥60dB
	Max FR.Deviation	≤±5KHz
	Current	≤1300mA
	Modulation Noise	-40dB
RECEIVER	Receiving sensitivity	≤0.282μV
	Adjacent channel selectivity	≥60dB
	Current	Standby 70mA, working 220mA
	Reference Frequency	26.000MHz
	Inter-modulation	≥60dB
	Spurious	≥55dB
	Audio distortion	<5%
	Audio power	<500mW

## Factory default settings



CH NO.	Frequency MHz	Code(Hz)	Power
1	462.5625	67.0	High
2	462.5875	118.8	High
3	462.6125	127.3	High
4	462.6375	131.8	High
5	462.6625	136.5	High
6	462.6875	141.3	High
7	462.7125	146.2	High
8	467.5625	D243N	Low
9	467.5875	D032N	Low
10	467.6125	D047N	Low
11	467.6375	D051N	Low
12	467.6625	D053N	Low
13	467.6875	D065N	Low
14	467.7125	D116N	Low
15	462.5500	123.0	High
16	462.5750	D743I	High
17	462.6000	D332I	High
18	462.6250	127.3	High
19	462.6500	D243I	High
20	462.6750	D606N	High
21	462.7000	D731I	High

22	462.7250	136.5	High
----	----------	-------	------

## RF ENERGY EXPOSURE AND PRODUCT SAFETY GUIDE FOR TWO-WAY RADIOS

- User instructions should accompany the device when transferred to other users.
- Do not use this device if the operational requirements described herein are not met.

This two-way radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. RF energy, which when used improperly, can cause biological damage.

All Retevis two-way radios are designed, manufactured, and tested to ensure they meet government-established RF exposure levels. In addition, manufacturers also recommend specific operating instructions to users of two-way radios. These instructions are important because they inform users of RF energy exposure and provide simple procedures on how to control it. Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits: <http://www.who.int/en/> When two-way radios are used as a consequence of employment, the Local Government Regulations requires users to be fully aware of and able to control their exposure to meet occupational requirements. Exposure awareness can be facilitated by the use of a product label directing users to specific user awareness information. Your Retevis two-way radio has a RF Exposure Product Label. Also, your Retevis user manual, or separate safety booklet includes information and operating instructions required to control your RF exposure and to satisfy compliance requirements.

### Radio License(only applicable to licensed radio)

Governments keep the radios in classification, business two-way radios operate on radio frequencies that are regulated by the local radio management departments (FCC, ISSED, OFCOM, ANFR, BFTK, Bundesnetzagentur...). To transmit on these frequencies, you are required to have a license issued by them. The detailed classification and the use of your two radios, please contact the local government radio management departments. Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

### Unauthorized modification and adjustment

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority granted by the local government radio management departments to operate this radio and should not be made. To comply with the corresponding requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the local government radio management departments equipment authorization for this radio could violate the rules.

## FCC Requirements

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. (Licensed radios are applicable); This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (Other devices are applicable)

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

### (Only Applicable to GMRS radio station):

A valid individual license is required to operate a GMRS station. To obtain an individual license, an applicant must be eligible and follow the applicable rules and procedures established by FCC. The applicant must pay the

required application and regulatory fees. Each individual license in the GMRS will normally have a term of ten years from the date of grant or renewal, and may be renewed pursuant to the procedures of FCC. To obtain a GMRS operator license, you need FCC Form 605 & 159, we suggest visiting the FCC website at <https://www.fcc.gov/wireless/support/fcc-form-605>, which includes necessary instructions. More questions about the license application, please contact the FCC at 1-888-225-5322 or go to the FCC's website: <http://www.fcc.gov>.

According to FCC rules, any individual who holds an individual license may allow his or her immediate family members to operate his or her GMRS station or stations. Immediate family members are the licensee's spouse, children, grandchildren, stepchildren, parents, grandparents, stepparents, brothers, sisters, aunts, uncles, nieces, nephews, and in-laws.

(Only applicable to industrial environment) This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(Only applicable to home) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **CE Requirements:**

(Simple EU declaration of conformity) Shenzhen Retevis Technology Co., Ltd. declares that the radio equipment type is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and the ROHS Directive 2011/65/EU and the WEEE Directive 2012/19/EU; the full text of the EU declaration of conformity is available at the following internet address: [www.retevis.com](http://www.retevis.com).

#### **Restriction Information**

This product can be used in EU countries and regions, including: Belgium (BE), Bulgaria (BG), Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (EL), Spain (ES), France (FR), Croatia (HR), Italy (IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria (AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE) and United Kingdom (UK). For the warning information of the frequency restriction, please refer to the package.

#### **Disposal**

The crossed-out wheeled bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.

#### **IC Requirements:**

License-exempt radio apparatus

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

## **RF Exposure Compliance and Control Guidelines and Operating Instructions**

- Occupational/Controlled Radio, this radio is designed for and classified as “Occupational/Controlled Use Only”, meaning it must be used only during the course of employment by individuals aware of the hazards, and the ways to minimize such hazards; NOT intended for use in a General population/uncontrolled environment.
- General population/uncontrolled Radio, this radio is designed for and classified as “General population/uncontrolled Use”.

To control your exposure and ensure compliance with the occupational/controlled environment exposure limits, always adhere to the following procedures. When operating in front of the face, worn on the body, always place the radio in a Retevis-approved clip, holder, holster, case, or body harness for this product. Using approved body-worn accessories is important because the use of Non-Retevis approved accessories may result in exposure levels, which exceed the IEEE/ICNIRP RF exposure limits. Transmit no more than the rated duty factor of 50% of the time. To Transmit (Talk), push the Push to Talk (PTT) button. To receive calls (listen), release the PTT button. Transmitting necessary information or less, is important because the radio generates measurable RF energy exposure only when transmitting in terms of measuring for standards compliance.

- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio, and the antenna gain shall not exceed the specified gain by the manufacturer declared.
- DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
- During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so.
- DO NOT operate the transmitter in areas that are sensitive to electromagnetic radiation such as hospitals, aircraft, and blasting sites.
- Portable Device, this transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. RF exposure compliance is limited to the specific belt-clip and accessory configurations as documented in this filing and the separation distance between head and the device or its antenna shall be at least 2.5 cm.
- Mobile Device, during operation, the separation distance between user and the antenna subjects to actual regulations, this separation distance will ensure that there is sufficient distance from a properly installed externally-mounted antenna to satisfy the RF exposure requirements. Transmit only when people outside the vehicle are at least the recommended minimum lateral distance away from a properly installed according to installation instructions, externally mounted antenna.

### **Hand-held Mode(if applicable)**

- Hold the radio in a vertical position with the microphone (and other parts of the radio including the antenna) at least 2.5 cm (one inch) away from the nose or lips. The antenna should be kept away from the eyes. Keeping the radio at a proper distance is important as RF exposure decreases with increasing distance from the

antenna.

### **Phone Mode(if applicable)**

- When placing or receiving a phone call, hold your radio product as you would a wireless telephone. Speak directly into the microphone. Do not use the equipment when you are driving.

### **Electromagnetic Interference/Compatibility**

**NOTE:** Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

### **Avoid Choking Hazard**

Small Parts. Not for children under 3 years.

### **Turn off your radio power in the following conditions:**

- Turn off your radio before removing (installing) a battery or accessory or when charging battery.
- Turn off your radio when you are in a potentially hazardous environment: Near electrical blasting caps, in a blasting area, in explosive atmospheres (flammable gas, dust particles, metallic powders, grain powders, etc.).
- Turn off your radio while taking on fuel or while parked at gasoline service stations. To avoid electromagnetic interference and/or compatibility conflicts
- Turn off your radio in any facility where posted notices instruct you to do so, hospitals or health care facilities (Pacemakers, Hearing Aids and Other Medical Devices) may be using equipment that is sensitive to external RF energy.
- Turn off your radio when on board an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

### **Protect your hearing:**

- Use the lowest volume necessary to do your job.
- Turn up the volume only if you are in noisy surroundings.
- Turn down the volume before adding headset or earpiece.
- Limit the amount of time you use headsets or earpieces at high volume.
- When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear
- Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss

**Note:** Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.

### **Avoid Burns**

- Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a minor burn can result.

Batteries (If appropriate)

- When the conductive material such as jewelry, keys or chains touch exposed terminals of the batteries, may complete an electrical circuit (short circuit the battery) and become hot to cause bodily injury such as burns. Exercise care in handling any battery, particularly when placing it inside a pocket, purse or other container with metal objects
- **BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN**
- Store spare batteries securely
- If the battery compartment (if applicable) does not close securely, stop using the product and keep it away from children
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention
- Dispose of used batteries immediately and safely Long transmission
- When the transceiver is used for long transmissions, the radiator and chassis will become hot.

## Safety Operation

- Do not use charger outdoors or in moist environments, use only in dry locations/conditions.
- Do not disassemble the charger, that may result in risk of electrical shock or fire.
- Do not operate the charger if it has been broken or damaged in any way.
- Do not place a portable radio in the area over an air bag or in the air bag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the air bag inflates.  
To reduce risk
- Pull by the plug rather than the cord when disconnecting the charger.
- Unplug the charger from the AC outlet before attempting any maintenance or cleaning.
- Contact Retevis for assistance regarding repairs and service.
- The adapter shall be installed near the equipment and shall be easily accessible

## Approved Accessories

- This radio meets the RF exposure guidelines when used with the Retevis accessories supplied or designated for the product. Use of other accessories may not ensure compliance with the RF exposure guidelines and may violate regulations.
- For a list of Retevis-approved accessories for your radio model, visit the following website:  
<http://www.Retevis.com>

## Guarantee

- **Model Number:** \_\_\_\_\_
- **Serial Number:** \_\_\_\_\_
- **Purchasing Date:** \_\_\_\_\_
- **Dealer:** \_\_\_\_\_
- **User's Name:** \_\_\_\_\_
- **Country:** \_\_\_\_\_
- **Post Code:** \_\_\_\_\_

## Remarks:

1. This guarantee card should be kept by the user, no replacement if lost.
2. Most new products carry a two-year manufacturer's warranty from the date of purchase. Further details, pls read <http://www.retevis.com/after-sale/>
3. The user can get warranty and after-sales service as below:
  - Contact the seller where you buy.
  - Products Repaired by Our Local Repair Center
4. For warranty service, you will need to provide a receipt proof of purchase from the actual seller for verification

## Exclusions from Warranty Coverage:

1. To any product damaged by accident.
2. In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs.
3. If the serial number has been altered, defaced, or removed.

## Shenzhen Retevis Technology Co.,Ltd.

7/F, 13-C, Zhonghaixin Science&Technology Park, No.12 Ganli 6th Road, Jihua Street, Longgang District, Shenzhen, China


Web: [www.retevis.com](http://www.retevis.com)

E-mail: [kam@retevis.com](mailto:kam@retevis.com)





Facebook: [facebook.com/retevis](https://facebook.com/retevis)

## MADE IN CHINA:

## Documents / Resources

	<a href="#">RETEVIS RB39 Bluetooth Two Way Radio</a> [pdf] User Manual RB39, 2A3OORB39, RB39 Bluetooth Two Way Radio, Bluetooth Two Way Radio, Two Way Radio, Radio
---	--

## References

-  [Federal Communications Commission | The United States of America](#)
-  [Walkie Talkie Home | retevis.com](#)
-  [Retevis.com After-sale service | retevis.com](#)
-  [World Health Organization \(WHO\)](#)