

Rhine Electronics UC7225T3 Ceiling Fan Remote Controller Instructions

Home » RHINE ELECTRONICS » Rhine Electronics UC7225T3 Ceiling Fan Remote Controller Instructions



Contents

- 1 Rhine Electronics UC7225T3 Ceiling Fan Remote Controller
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 FAQ
- **5 INSTRUCTIONS FOR OPERATION**
- **6 GENERAL INFORMATION**
- **7 FCC STATEMENT**
- 8 Documents / Resources
 - 8.1 References

Rhine Electronics

Rhine Electronics UC7225T3 Ceiling Fan Remote Controller



Product Information

Specifications

• Model: UC7225T3

• Power Source: AAA*2PCS. 3 volts battery (not included)

• Code Combinations: 24bit

Product Usage Instructions

- 1. Insert 2 AAA 3-volt batteries into the remote control unit.
- 2. Ensure the battery is removed when the unit is not in use to prevent damage from potential leaks.
- 3. Store the remote control away from excess heat or humidity to maintain optimal performance.
- 4. Make sure the unit is using a 24-bit code combination to avoid interference with other devices.

Operating the Remote Control Unit

The remote control unit features the following operation buttons on the transmitter:

- 3 key For fan High-speed
- 2 key For medium speed
- 1 key For low speed
- Key Fan learning

FAQ

Q: What should I do if the remote control unit stops working?

A: If the remote control unit stops working, try replacing the batteries with new ones and ensure they are inserted correctly. If the issue persists, contact customer support for further assistance.

Q: Can I use rechargeable batteries with this remote control unit?

A: It is recommended to use standard AAA 3-volt batteries with this remote control unit for optimal performance. Rechargeable batteries may not provide sufficient power.

INSTRUCTIONS FOR OPERATION


SETING THE OPERATING CONTROLS

- This unit operates on AAA*2 PCS.; 3 volts battery (not included).
 To prevent possible damage if the battery should leak, be sure to remove the battery when the unit is not in use.
- 2. Store the controller away from excess heat or humidity.
- 3. This remote control unit is required with 24 bit code combinations. To prevent possible interference from or to other remote units such as garage door openers, car alarms or security systems.
- 4. Operation buttons on the panel of the transmitter.
- key For fan speed off.

Model: UC7255T6



- 6 key For fan Maximum speed.
- 5 key For fan high speed.
- 4 key For fan Medium speed.
- 3 key For fan Low speed.
- 2 key For fan Lower speed.
- 1 key For fan Minimum speed.





key – For fan speed Reverse.



Model: UC7225T3

- 3 key For fan High speed
- 2 key For med speed
- 1 key For low speed



GENERAL INFORMATION

This remote controller is designed to separately control your ceiling fan speed and light brightness.

INSTRUCTIONS FOR INSTALLATION AND OPERATION OF FAN SPEED CONTROLLER

Setup for ceiling fan controller

- 1. Turn off the power. (To make sure the electricity is entirely released, please press any button on the controller till no LED display showing)
- 2. Turn on the power
- 3. Press the FAN OFF button for more than 3 sec. The ceiling fan controller will have 2 blinks. It means the setup

is successful. You could start to control the ceiling fan light and fan speed.

NOTICE: The changes or modifications not expressly approved by the party responsible for compliance could void the user s authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user s authority to operate the device.

FCC STATEMENT

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause

Canada, Industry Canada (IC) Notices

This device complies with Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- operation to cappost to the following two containents
- 1. this device may not cause interference, and
- this device must accept any interference, including interference that may cause undesired operation of the device.

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner that the potential for human contact during normal operation is minimized.

This device has also been evaluated and shown compliant with the IC RF Exposure limits under portable exposure conditions.

Documents / Resources



Rhine Electronics UC7225T3 Ceiling Fan Remote Controller [pdf] Instructions UC7225T3 Ceiling Fan Remote Controller, UC7225T3, Ceiling Fan Remote Controller, Remote Controller, Controller

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.