

**ROCKIA
F11 Multi
Function
Wireless
Speaker**



ROCKIA F11 Multi Function Wireless Speaker User Manual

[Home](#) » [ROCKIA](#) » ROCKIA F11 Multi Function Wireless Speaker User Manual 

Contents

- [1 ROCKIA F11 Multi Function Wireless Speaker](#)
- [2 FEATURE](#)
- [3 BUTTON FUNCTION](#)
- [4 Function Detailed](#)
- [5 Indicator Light](#)
- [6 WARNING MESSAGE](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

ROCKIA

ROCKIA F11 Multi Function Wireless Speaker



FEATURE



Wireless
Connection



HiFi Sound




TWS




Handsfree



BUTTON FUNCTION



Charging port
(TYPE-C)



Microphone

-  Press & Hold: Power ON / OFF
-  Press & Hold: TWS(After power on)

Press: Play / Pause



- Press: Volume –

Press&Hold: Previous song



- Press: Volume +

Press&Hold: Next song



- Press: Answer / Hang up

Double-Press: Call-back / Reject incoming calls

Press&Hold: Reject incoming calls

Function Detailed

- Power ON / OFF


Press & Hold '' key: Power ON / OFF.

- Wireless Mode

In BT mode, Open the phone BT function, select the product's pairing code, the speaker is connected after the success of sound.

- Phone Call / Handsfree


When the speaker is in the BT connection status, if the mobile phone has an incoming call, the speaker will

make a ringtone. Press the '' key to answer the call and press it again to hang up. Press & Hold the



' key to reject the call.

- TWS Wireless Couplet Mode

Open two speakers at the same time into BT mode, without BT connection, short press any one of the '' keys to enter the couplet/disconnect couplet. After the couplet, use the phone to search and connect, you can play.

(When TWS couplet mode, the two speakers automatically change to be left and right stereo).

- About Charging

Plug the USB-C cable into the speakers and connect the DC 5V charger or computer USB port to charge the speakers.

Indicator Light

Red Light

In charge, and red light goes out after full charge.

Blue Light

- Fast flashing: BT pairing; Slow flashing: Playing;
- Steady Light: Playing paused.

WARNING MESSAGE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources



[ROCKIA F11 Multi Function Wireless Speaker](#) [pdf] User Manual
F11 Multi Function Wireless Speaker, F11, Multi Function Wireless Speaker, Wireless Speaker, Speaker

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.