



## ROCKVILLE Titan Portable Array Owner's Manual

[Home](#) » [Rockville](#) » ROCKVILLE Titan Portable Array Owner's Manual 

**ROCKVILLE**



**TITAN PORTABLE ARRAY  
OWNER'S MANUAL  
BATTERY POWERED PA SPEAKER SYSTEM w/8- SU BWOOFER**

Thank you for purchasing this Rockville product. Please read this owner's manual carefully for proper use of your Titan Portable Array (TPA). Should you need assistance, please call our technical helpline at 1-646-758-0144, Monday through Friday, 9 am to 5 pm EST.

## Contents

- [1 Include](#)
- [2 How to Avoid irritating Feedback](#)
- [3 Setting Level Controls](#)
- [4 Microphone Presentations](#)
- [5 Wireless Speaker Linking](#)
- [6 AUX Input](#)
- [7 Line Out Balanced Connection](#)
- [8 Functions](#)
- [9 Features](#)
- [10 Troubleshooting](#)
- [11 FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

## Include

- 8" Powered subwoofer with built-in mixer amplifier and rechargeable battery
- (3) Column speakers – 1 column with 4 drivers, and 2 columns are empty and are used to elevate the loaded one
- Travel bag with carrying handles for the subwoofer and column speakers,
- 5 Foot power cable
- Owner's manual
- Warranty card


## IMPORTANT SAFETY INSTRUCTIONS



- To reduce the risk of electric shock, never open the unit. There are no user-serviceable parts; refer service to an authorized Rockville service center.
- Do not expose this unit to any kind of moisture.
- Please ensure that the unit is situated in a properly ventilated area.
- Make sure the unit is placed on a level and stable surface.
- This unit can operate with either 110V or 220V.

## How to Avoid irritating Feedback

The placement of your microphone is critical! in avoiding feedback through your Titan Portable Array. Never set up your microphone in front of the speaker. Always set up your microphone behind the speaker. When approaching the speaker to make any adjustments, approach the speaker from the rear and do not walk directly toward the front of the speaker.



## Setting Level Controls

It is best practice to set your input volume (gains) in this manner:

1. Unplug all inputs except for the one you wish to set the gain for. In this instance, the RCA line inputs.
2. Set the line-level input device volume (smartphone, tablet, MP3 player, etc.) to 60%.
3. Set the MASTER VOLUME to 75%.
4. Slowly turn up the AUX volume control. As soon as the CLIP indicator LEO goes on or you hear any distortion, turn AUX volume down one or two notches.



### PLEASE NOTE

Because mixers feature two volume controls {channel and master}, when connecting one via the XLR line-in port, the procedure is slightly different. The TPA MASTER VOLUME should be set to 50% and the CHANNEL 1 and 2 volume controls should be set to 50%. Set the mixer master volume to 50% and make the adjustments in step 4 on the mixer channel level control. If after making these adjustments the signal still isn't strong enough, you can additionally boost the signal by turning up the CHANNEL 1 and 2 volume controls.

When adjusting the Mic Volume control, you must speak into the microphone and adjust the level control as

needed. This is because adjustments to the mic input are a matter of mic volume in relation to the music volume and not necessarily a clipping issue.

## Microphone Presentations

Your TPA features 2 balanced microphone inputs accessible via combo XLR/1/4" TRS inputs.

1. Switch OFF your TPA.
2. Plug your microphone into either the CHANNEL 1 or CHANNEL 2 XLR input. Make sure to set the MIC/LINE selector to MIC.
3. Switch ON your TPA.
4. Refer to the "Setting Level Controls" section of this manual for instructions on how to

properly adjust the input volume (gains). Always stand behind the TPA when making your microphone adjustments to avoid feedback distortion.

## Line Input

You can connect an additional stereo signal source (such as CD players, DVD music players, MP3 players, guitar, etc.) without the use of a mixer console. Simply plug the device directly into one of the combo XLR/1/4" TRS inputs.

1. Switch OFF your TPA.
2. Connect the input source to either the channel 1 or channel 2 combo XLR/1/4" TRS input using an XLR or 1/4" TRS cable. Make sure the MIC/LINE selector switch is set to LINE. To connect a guitar, use channel 2 and make sure to press the HI-Z button.
3. Switch ON your TPA.
4. Refer to the "Setting Level Controls" section of this manual for instructions on how to properly adjust the input volume (gains).

## Wireless Speaker Linking

The TPA features true wireless stereo (TWS) Bluetooth linking. This means you can link 2 units together to play in stereo wirelessly.

1. Switch ON your TPA and make sure the BT / AUX selector is set to BT.
2. Press and hold the BT/TWS button on one of the units for 2 seconds. The BT indicator LED will flash intermittently. Follow the Bluetooth pairing procedures below. This will be the primary unit.
3. Once the primary unit is paired to your BT device, press the BT/TWS button for 1 second. The BT indicator LED will continue flashing and the primary TPA will automatically pair with the secondary TPA unit. Once paired, the LED will remain lit.
4. All playback functions are controlled by your BT device. You can set the gain or volume on the units independently.
5. To disconnect, press the BT/TWS button on either one of the units.

## Bluetooth Pairing

To connect your iPod, iPhone, MP3 player, Android phone, or any other Bluetooth-capable device, follow the steps listed below.

1. Switch ON your TPA and make sure the BT / AUX selector is set to BT.
2. Turn on the Bluetooth feature on your device and ensure that it is discoverable.
3. Press and hold the BT/TWS button for 2 seconds. The BT indicator LEO will flash intermittently.
4. Look for "TITAN PORTABLE ARRAY" on the list of available devices and select it. The TPA will automatically connect to your device. Once connected, the BT indicator LEO will remain lit.
5. When the unit is in BT mode and the previously paired device is nearby, it will connect to it automatically. To disconnect press and hold the BT/TWS button for 2 seconds. if you have problems pairing your device, please check the troubleshooting section on page 9.


## AUX Input

You can connect a stereo signal source (such as a CD player, DVD music player, MP3 player, etc.) into either the RCA inputs or the 3.5mm jack.


1. Switch OFF your TPA.
2. Connect the music source to the RCA inputs or the 3.5mm jack.
3. Switch ON your TPA and make sure the BT/AUX selector is set to AUX.
4. Refer to the "Setting Level Controls" section of this manual for instructions on how to properly adjust the input volume (gains).


## Line Out Balanced Connection

The MONITOR OUT XLR port allows you to output the amplified signal to a subwoofer, another powered speaker, and an amp or mixer. The output should be connected to the input of the external a device using an XLR-to-XLR or XLR-to-1/4" TRS cable. We recommend you use high-quality cables such as Rockville's RCXFM20E-B XLR-to-XLR cable or the RCXMB20-B XLR-to-1/4" TRS cable.



## Functions





# 1. MIC/LINE input section

## a. TREBLE

b. BASS

c. REVERB: on/off button

d. VOLUME: controls the MIC/LINE level.

e: MIC/LINE selector switch: When connecting a microphone, make sure that The line/Mic button is in the “down” position. When connecting a line-level device, make sure that the specific button is in the “up” position.

f: Hi-Z: press this button when an electric guitar or electric bass with the passive audio pickup is connected to the channel 2 ¼” jack . g: Combo XLR/ ¼” TRS inputs\

## 2. BT/AUX input section

a. BT status indicator LED

b. BT/TWS button

c. VOLUME: controls the BT/AUX level.

d. BT/AUX selector switch

e: L/R RCA auxiliary input

f. 3.5mm auxiliary input

3. POWER/ CLIP LED indicator: Will illuminate green when the unit is receiving power.

Will illuminate red when there is a power overload. This indicates that limiting has taken place to protect and avoid damage to the amplifier or speaker. Continuously overdriving the system will cause distortion and may cause damage to the amplifier and/or the speaker.

4. REVERB level input control

5. SUB volume control

6. MASTER VOLUME

7. MONITOR STEREO/MONO selector button: determines the monitor output signal type.

8. USB 5V/1A charging port

9. XLR monitor output

10. Battery status LED indicators

11. IEC AC input port w/user serviceable fuse

12. Power switch

13. Voltage selector switch—r

## Features

- 1200W Peak power/300W RMS (continuous).
- Completely portable yet it has enough power to fill a room 3K square feet.
- Wireless stereo linking (TWS) of 2 systems to fill larger venues.
- Perfect for outdoor performances, street parties, band practice, small gigs, and more.
- Bluetooth 5.0 chip allows crystal clear music streaming with a 30-foot max range.
- Rechargeable battery lasts 6 hours at high volume, 12 at mid-volume, and 18 at low volume.
- Fast 3 hour charge time.
- Clean balanced sound quality tuned using DSP to be very flat with clear vocals and thumpy deep bass.
- LOWS: 8” Subwoofer (200W RMS power dedicated to the sub).
- Sub has a large 40 Oz magnet and 2” voice coils.
- HIGHS/MIDS: (4) 2.75” drivers(100W RMS power dedicated to the drivers).
- Clean and balanced sound even at high volume levels.
- Wide-angle sound dispersion fills a room with sound.

- Frequency response: 40Hz – 20KHz.
- Input 1: Mic / Line level selectable: XLR / ¼" Combo jack.
- Input 2: Line/Mic/Guitar level selectable: XLR / ¼" Combo jack.
- Input 3: Line level RCA/3.5mm input.
- XLR mix output allows you to connect another speaker or amplifier.
- Limiter allows the speaker to play at extremely high volumes while limiting the frequencies causing clipping.
- USB charger (5V/1A) will charge your phone or another portable device.
- Class D amplifier is extremely efficient with a low current draw and approximately 90% of energy is turned into clean amplifier power.
- Built-in dual carry handles on the subwoofer unit.
- Variable voltage selector (110/230V).
- Weight of Sub: 22.93Lbs.
- Dimensions of sub: 11.02" x 13.38" x 14.76".
- Dimensions of each column: 3.15" x 3.54" x 15.35".

## **Troubleshooting**



PROBLEM	SOLUTION
No power	<ol style="list-style-type: none"> <li>1. Make sure the unit is plugged in and the power switch is in the ON position.</li> <li>2. Check that the power cable is plugged in tightly to the unit.</li> <li>3. Check and replace the fuse if necessary.</li> <li>4. If people or equipment tend to step on and roll over or stretch your power cable, it can get damaged. Always try a second cable to test for shorts in the original cable. Dispose of damaged power cables immediately.</li> </ol>
No sound/ distorted sound	<ol style="list-style-type: none"> <li>1. Check that all appropriate cables are plugged in correctly.</li> <li>2. Check the Levels settings. Refer to the "Setting Level Controls" section on page 4 of this manual for instructions on how to properly adjust the input level controls.</li> <li>3. If you are using the MIC/LINE section inputs, make sure the MIC/LINE button is set to the correct input source.</li> <li>4. Be sure your microphone is on and plugged into the correct input.</li> <li>5. If using a mixing console, make sure fader and balance are set to center positions and levels are increased. Make sure the mixer is plugged into the correct input.</li> <li>6. If channel levels settings are maxed out, turn down the appropriate one, as you may be overdriving the unit.</li> <li>7. Check volume and level settings on all input sources.</li> </ol>
Buzzing sound	Make sure you are using a proper cable. For 1/4 cables, there are three types: instrument, TS (unbalanced), and TRS (balanced). Check the requirements of the connected gear and make sure you are using the appropriate cable.
Mic feedback	Point the mics away from the speaker. Make sure the mics are behind the speaker, not in front of it.
Poor mic sound	Make sure you are using the XLR part of the Mic/Line port
Bluetooth/TWS pairing fails	<ol style="list-style-type: none"> <li>1. Check to see that both devices are turned on and that your Bluetooth device is discoverable.</li> <li>2. Turn both devices off and then on.</li> <li>3. Make sure the BT/AUX selector is set to BT.</li> <li>4. Make sure that the Bluetooth device is within 5 feet of the unit.</li> <li>5. Move both devices away from other Bluetooth devices, microwaves, wireless routers, and other electronics.</li> <li>6. Make sure that the unit is not paired to a previously paired device or to another speaker.</li> </ol> <p>Please refer to page 4 for Bluetooth and TWS pairing procedures.</p>

## FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

Responsible party name: Rockville

**Address:** 600 Bayview Ave,  
Entrance A,  
Inwood, NY 11096

Hereby declares that the product(s) TITAN PORTABLE ARRAY complies with FCC rules as mentioned in the following paragraph:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection levels harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



[RockvilleAudio.com](http://RockvilleAudio.com)

© 2020 ROCKVILLE // Features and specifications are subject to change and/or improvement without notice.

## Documents / Resources

 <p><b>ROCKVILLE</b> <b>TITAN PORTABLE ARRAY</b> <small>OWNER'S MANUAL</small></p> <p><small>BATTERY POWERED PA SYSTEM WITH SUBWOOFER</small></p>	<p><a href="#">ROCKVILLE Titan Portable Array</a> [pdf] Owner's Manual ROCKVILLE, Titan, Portable, Array</p>
--	--