



ROLL-A-SHADE Contract Plus+ 7 Inch Dual Bottom Fascia Installation Guide

[Home](#) » [ROLL-A-SHADE](#) » ROLL-A-SHADE Contract Plus+ 7 Inch Dual Bottom Fascia Installation Guide 

Contents

- [1 ROLL-A-SHADE Contract Plus+ 7 Inch Dual Bottom Fascia](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 HARDWARE INCLUDED](#)
- [5 TOOLS REQUIRED](#)
- [6 FAQ](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



ROLL-A-SHADE Contract Plus+ 7 Inch Dual Bottom Fascia



Product Information

Specifications

- **Product Name:** CONTRACT PLUS+ 7 DUAL BOTTOM FASCIA
- **Manufacturer:** Rollashade.com
- **Contact:** info@rollashade.com | 951.245.5077
- **Hardware Included:**
 - Bracket Covers
 - Motor Bracket
 - Motor Bracket Idler End
 - #14 Screw Screws
 - Shades + Motors
 - Fascia
 - Zip Ties
 - Wire Tie Pads
 - Wall Switch
 - Switch Box
- **Tools Required:**
 - 3/8 Hex Head Phillips Head
 - 1/8 Drill Bit
 - Drill

Product Usage Instructions

- **Inside or Outside Application**

NOTE: ALL SHADES MAY BE PRE-PROGRAMMED TO SENSORS, REMOTES, AND/OR WALL SWITCHES UPON ARRIVAL
- **Mounting Location**


Place your first bracket in its mounting location and mark the screw holes. Place your second bracket in its mounting location and repeat the process.

Rollashade.com


info@rollashade.com

951.245.5077

HARDWARE INCLUDED





TOOLS REQUIRED



INSIDE OR OUTSIDE APPLICATION


****NOTE: ALL SHADES MAY BE PRE-PROGRAMMED TO SENSORS, REMOTES, AND/OR WALL SWITCHES**

UPON ARRIVAL**




MOUNTING LOCATION

Place your first bracket in its mounting location and mark the screw holes. Place your second bracket in its mounting location and repeat the process.




SCREW INSTALLATION

Next, pre-drill your screw holes using a 1/8" drill bit. Install the brackets with the provided screws using the 1/4" hex head driver.




ALIGNMENT

Check to make sure your brackets are level and aligned.



TOP SHADE PIN END INSTALLATION

Swivel ball bearing to align with idler shaft for easy installation. Press idler shaft all the way to the bracket.



TOP MOTOR END INSTALLATION

Remove locking ring. Lineup to motor bracket. Push motor into motor bracket.



TOP LOCK RING INSTALLATION

Add locking ring to motor bracket. Check motor is secured correctly.




BOTTOM SHADE PIN END INSTALLATION

Swivel ball bearing to align with idler shaft for easy installation. Press idler shaft all the way to the bracket.




BOTTOM MOTOR END INSTALLATION

Remove locking ring. Lineup to motor bracket. Push motor into motor bracket.



BOTTOM LOCK RING & FASCIA INSTALLATION

Add locking ring to motor bracket. Check motor is secured correctly. Install bottom fascia.



PLUG IN MOTOR

- Run motor power cord to nearest power outlet.
- Install wire tie pads and secure with zip ties to hold wire down.
- The path of the wire should be parallel with mullions and/or drop ceiling tiles ensuring the cable is neatly organized.
- Any modifications to the power cable should be done by a certified electrician to meet your city/state code requirements.




ADJUSTING LIMITS (IF NECESSARY)

See programming instructions based on the motor used for your application.

SHADE ADJUSTING (IF NECESSARY)

- Roll shade up and down to confirm hembar is level and material rolls up straight on center tube.
- If the hembar is not level, lower shade until you see the metal tube.
- Add layers of masking tape to the metal tube to the end that is too low until hembar is straight.
- If the material tracks to one side, lower shade until you see the metal tube.
- Add layers of masking tape to the metal tube to the end that is opposite the direction of tracking, until shade rolls up straight.



FAQ

Q: How do I adjust the limits of the shade?

A: See programming instructions based on the motor used for your application to adjust the limits of the shade.

Q: What tools are required for installation?

A: The tools required for installation are a 3/8 Hex Head Phillips Head, a 1/8 Drill Bit, and a Drill.

Documents / Resources

	<p>ROLL-A-SHADE Contract Plus+ 7 Inch Dual Bottom Fascia [pdf] Installation Guide Contract Plus 7 Inch Dual Bottom Fascia, Contract Plus, 7 Inch Dual Bottom Fascia, Dual Bottom Fascia, Fascia</p>
--	---

References

- 🏠 [Roll-A-Shade - Commercial Window Shade Solutions](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.