




ROYAL KLUDGE RK-S70 Mechanical Wireless Keyboard User Manual

[Home](#) » [ROYAL KLUDGE](#) » ROYAL KLUDGE RK-S70 Mechanical Wireless Keyboard User Manual 

Contents

- 1 ROYAL KLUDGE RK-S70 Mechanical Wireless Keyboard
- 2 Product Information
- 3 Button Indicator Function
- 4 Product Usage Instructions
- 5 FCC Compliance Statement (USA only)
- 6 PRODUCT BASIC
- 7 WIRED MODE
- 8 BUTTON INDICATOR FUNCTION
- 9 HOW TO USE
- 10 HOW TO USE
- 11 BATTERY LEVEL REMINDER
- 12 BACKLIGHT CONTROL
- 13 SPECIAl FUNCTION KEYS
- 14 MULTIMEDIA KEY FOR WINDOWS
- 15 SYSTEM REQUIREMENTS
- 16 FCC COMPLIANCE STATEMENT
- 17 Documents / Resources
 - 17.1 References



ROYAL KLUDGE RK-S70 Mechanical Wireless Keyboard



Product Information

- **Product Name:** Home ScrLK Keyboard
- **Model Number:** 166-86801-02
- **Connection Type:** Wired (USB Type-C)
- **Power Rating:** It is recommended to use a 5V 1A rated power source to charge the keyboard.

Button Indicator Function

- **ON:** Indicates that a function is enabled.
- **OFF:** Indicates that a function is disabled.
- **Battery Status Indicator:** The indicator flashes when the battery voltage is low, remains on while charging, and turns off when fully charged.

Product Usage Instructions

- **Switch Power On:**
Press the “Home ScrLK” key to switch the power on.
- **Battery Level Reminder:**
 - In BT + 2.4G mode, press “FN+ENTER” to check the battery level.
 - When the backlight is on, it indicates the keyboard is charged at a certain percentage. For example, if the backlight is on, it means the keyboard is 10% charged; if the backlight is on and the keyboard is at 20% power, and so on. The backlight being on indicates the keyboard power is 100%.
- **Backlight Control:**
 - **Switch Backlight Mode:** Press the “Space Bar” key to switch between different backlight modes.
 - **Backlight Brightness +:** Increase the backlight brightness.
 - **Backlight Brightness -:** Decrease the backlight brightness.
 - Backlight Brightness Restore to Factory Settings.
- **Monochrome Switching:**
 - Switch between monochrome backlight modes.
 - **Backlight Speed +:** Increase the speed of backlight effects.
 - **Backlight Speed -:** Decrease the speed of backlight effects.
- **Windows Lock:**
Press the “Windows Lock” key to lock/unlock the Windows key functionality.

- **Special Function Keys:**

- PrtSc: Print Screen
- Insert
- Pause
- Ctrl + A: Select All
- Ctrl + C: Copy
- Ctrl + V: Paste
- Ctrl + X: Cut
- Ctrl + S: Save
- End

- **Multimedia Key for Windows:**

- In Windows mode (press “FN + A” to switch to Windows system):
- Computer
- Browser
- Mailbox
- Calculator
- Player Stop
- Last Song
- Play / Pause
- Next Song
- Mute
- Volume +
- Volume –

- **Multimedia Key for Mac:**


- In MAC mode (press “FN + S” to switch to MAC system):
- Screen Brightness –
- Screen Brightness +
- Keyboard Backlight Brightness
- Keyboard Backlight Brightness +
- Last Song
- Play / Pause
- Next Song
- Mute
- Volume +
- Volume –

FCC Compliance Statement (USA only)


- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference.
 2. This device must accept any interference received, including interference that may cause undesired operation.

- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 1. Reorient or relocate the receiving antenna.
 2. Increase the separation between the equipment and receiver.
 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 4. Consult the dealer or an experienced radio/TV technician for help.
- **WARNING:** This product can expose you to chemicals including {name of one or more chemicals}, which is/are [insert relevant warning if available].


PRODUCT BASIC




WIRED MODE




BUTTON INDICATOR FUNCTION



HOW TO USE








HOW TO USE




BATTERY LEVEL REMINDER


In BT + 2.4G mode, Press FN+ENTER to check the battery level

for example

-  When the backlight is on, it means the keyboard is 10% charged at this time.
-  ~  The backlight is on at the same time, indicating that the keyboard is at 20% power at this time.
-  ~  The backlight is on at the same time, indicating that the keyboard power is 100% at this time



BACKLIGHT CONTROL



Fn +	Switch Backling Mode	Fn +	(The same applies to RGB) Monochrome switching
Fn +	Backlight Brightness +	Fn +	Backlight Speed +
Fn +	Backlight Brightness -	Fn +	Backlight Speed -
Fn +	Restore to factory settings	Fn +	Windows Lock

SPECAAL FUNCTION KEYS

Fn +	PrtSc	Fn +	Home
Fn +	Insert	Fn +	ScrLk
Fn +	Pause	Fn +	End
M1 =	Ctrl + A(Unanimous)	M4 =	Ctrl+ X(Cut)
M2 =	Ctrl + C(Clone)	M5 =	Ctrl+ S(Save)
M3 =	Ctrl + V(Adhere)		

Fn	+	1	F1
Fn	+	2	F2
Fn	+	3	F3
Fn	+	4	F4
Fn	+	5	F5
Fn	+	6	F6

Fn	+	7	F7
Fn	+	8	F8
Fn	+	9	F9
Fn	+	0	F10
Fn	+	-_	F11
Fn	+	=+	F12





















MULTIMEDIA KEY FOR WINDOWS

- In Windows mode(FN + A: switch to Windows system)

Fn	+	F1	Computer
Fn	+	F2	Browser
Fn	+	F3	Mailbox
Fn	+	F4	Calculator
Fn	+	F5	Player
Fn	+	F6	Stop

Fn	+	F7	Last song
Fn	+	F8	Play / pause
Fn	+	F9	Next song
Fn	+	F10	Mute
Fn	+	F11	Volume-
Fn	+	F12	Volume+

- MAC mode (FN + s: switch to MAC system)

	+		Screen Brightness-		+		Play / pause
	+		Screen Brightness+		+		Next song
	+		Keyboard Backlight Brightness-		+		Mute
	+		Keyboard Backlight Brightness+		+		Volume-
	+		Last song		+		Volume+

SYSTEM REQUIREMENTS

• BT Mode

- Device With Bluetooth 5.1 or later
- **PC:** Windows 7 or Later
- **Mac:** macOS X 10.6 Snow Leopard or Later
- **iOS:** All iPads/iPhone 5 or Later
- **Android:** 5.0 Lollipop or Later

• Wired/2.4Ghz Mode

- Computer With Available USB port
- **PC:** Windows 7 or Later
- **Mac:** macOS X 10.6 Snow Leopard or Later

FCC COMPLIANCE STATEMENT

- This device complies with part 15 of the FCC Rules.
- Operation is subject to the following two conditions:
 1. This device may not cause harmful interference,
 2. this device must accept any interference received, including interference that may cause undesired operation.
- **Note:** This equipment has been tested and found to comply with the limits for a ClassB digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
- However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement


- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

Have an issue with one of our RK products?

- Feel free to contact us with any product issues or questions.
- We will reply as quickly as possible to ensure all your needs are handled.
- Please contact the seller

WARNING: This product can expose you to chemicals including {name of one or more chemicals}, which is (are) known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

Documents / Resources

	ROYAL KLUDGE RK-S70 Mechanical Wireless Keyboard [pdf] User Manual 2A4MQ-RK-S70, 2A4MQRKS70, rk s70, RK-S70, Mechanical Wireless Keyboard, RK-S70 Mechanical Wireless Keyboard, Wireless Keyboard, Keyboard
---	--

References

-  [RK royal kludge](#)