



SaberTec Firmware Update Configurator Instructions

[Home](#) » [SABERTEC](#) » SaberTec Firmware Update Configurator Instructions 

SaberTec Firmware Update Configurator



Contents

- [1 Downloading the new firmware update](#)
- [2 Elimination of clicking noise](#)
- [3 Fix ignition speed and retraction speed](#)
- [4 Fix randomized boot sounds](#)
- [5 Minor bug fixes](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Downloading the new firmware update

To install the new firmware update, make sure to perform the following steps:

1. Remove the SD card from your board and insert it into your computer.
2. Download the update.dat file and put it on the SD card:
https://sabertec.net/wp-content/uploads/2024/04/APP_24_04-23_54.zip
3. The firmware update will be automatically installed after rebooting the board.

Elimination of clicking noise

The new firmware update makes the board more robust against SD cards with less performance. Previously, when using a slow SD card, it could happen that there is a slight clicking noise when the hum loops. This is now fixed, effectively eliminating the clicking noise. As another effect of the increased robustness against SD cards with less performance, also any other sound transition has been further smoothened.

Fix ignition speed and retraction speed

Previously, it could happen that the change of the ignition speed and retraction speed of sound fonts different from the currently active one was not saved. This is fixed now.

Fix randomized boot sounds

With the previous firmware update, it could happen that the boot sound was not chosen randomly under certain circumstances. This is fixed by the new firmware update.

Minor bug fixes

The new firmware update fixes a series of minor bugs, enhancing the reliability and stability. These refinements, though subtle, contribute significantly to a smooth and consistent operation, ensuring an overall improved user experience.



Documents / Resources

<div><div><div>Download the new firmware update</div><div>1. Download the new firmware update</div><div>2. Connect the device to the computer</div><div>3. Install the new firmware update</div></div><div><div>Installation of the new firmware</div><div>1. Connect the device to the computer</div><div>2. Install the new firmware update</div><div>3. Connect the device to the computer</div><div>4. Install the new firmware update</div><div>5. Connect the device to the computer</div><div>6. Install the new firmware update</div><div>7. Connect the device to the computer</div><div>8. Install the new firmware update</div><div>9. Connect the device to the computer</div><div>10. Install the new firmware update</div></div></div>	<div><div><div>SaberTec Firmware Update Configurator [pdf] Instructions</div><div>Firmware Update Configurator, Update Configurator, Configurator</div></div></div>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.