



# Sainlogic QT-06 Zigbee Smart Water Valve User Manual

[Home](#) » [Sainlogic](#) » Sainlogic QT-06 Zigbee Smart Water Valve User Manual 

## Contents

- [1 Sainlogic QT-06 Zigbee Smart Water Valve](#)
- [2 Performance and instructions](#)
- [3 Instructions for use](#)
- [4 Product parameters](#)
- [5 Operation Guide](#)
  - [5.1 Gateway networking tutorial](#)
  - [5.2 Gateway adds and connects intelligent water valve](#)
- [6 Mobile APP Interface](#)
- [7 Warranty Regulations](#)
- [8 Product Warranty Card](#)
- [9 FCC Warning](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)

# Sainlogic

**Sainlogic QT-06 Zigbee Smart Water Valve**



## Performance and instructions

### Smart water valve

Remote operation: remote control of mobile APP anytime and anywhere, manual control of field devices, and timing control of APP


Signal distance: the open distance between gateway and smart water valve is  $\leq 50$  meters

Battery: 4\*AA alkaline dry batteries are used.


Protection grade: IP66. Smart water valve can be installed and used outdoors.

### Instructions for use

1. One gateway can be connected with 8 smart water valves.
2. The open distance from the gateway to the smart water valve is  $\leq 50$  meters, and the partition wall distance is  $\leq 20$  meters (determined according to the actual installation environment).
3. Zigbee signal cannot be relayed and jumped through smart water valve.
4. After setting the timing, if the smart water valve is offline, it will be watered according to the timing program.
5. Operational requirements of water flowmeter: the water flow rate is at least 2L/ min, and the water flow is too small to drive the flowmeter to work. There will be a false alarm of "water shortage warning".
6. Statistics will be recorded only when the smart water valve is online for historical records.
7. Water shortage reminder: When the water valve is opened and there is no water, the water shortage warning will be prompted after 15 seconds in the connected state.



## Product parameters



Product name	Smart water valve (Zigbee)
Caliber	1/2" or 3/4" & 1"
Waterproof level	IP66
Withstand water pressure	0.2~8bar
Power	4*AA alkaline dry battery

Product name	Smart gateway (Zigbee)
Operating temperature	-10°C ~ +50°C
Working humidity	0-90%RH No condensation
Power	DC5V/1A
Signal range	Open area ≤ 50 meters


## Operation Guide

1. Scan the QR code to download the "Smart Life" app,
2. Register a member account.
  - Input your mobile phone number or email address.
  - Receive the verification code SMS. Configure your own password.



## Gateway networking tutorial


1. Open the APP and click add device or “+” in the upper right corner,
2. Select gateway central control → wireless gateway (Zigbee),
3. Enter WiFi account and password (2.4Ghz),
4. Check to confirm that the indicator light is flashing, and EZ mode is in the upper right corner,
5. Next, enter the interface of adding equipment,
6. Wait a moment and add successfully.




①




②



③



④




⑤



⑥

## Gateway adds and connects intelligent water valve

1. Open the gateway interface and select “+Add Subdevice”.
2. Confirm whether the indicator light of the intelligent water valve flashes (press and hold the switch button of the intelligent water valve for 5 seconds, and the indicator light switches from long on to flash or extinguish).
3. Automatically search for equipment, and click Finish after searching for the equipment.
4. If the addition is successful, click the name of the brush to modify it.



## Mobile APP Interface

It's easy to understand and operate



## Warranty Regulations

1. The warranty period of this product is one year.
2. During the warranty period, any failure occurred under normal use according to the instruction manual (judged by the official staff of our company) shall be repaired free of charge.
3. During the warranty period, if one of the following situations occurs, it must be repaired as a charge:
  - This guarantee and valid purchase certificate cannot be provided.
  - Faults and damages caused by incorrect use and improper repair by oneself.
  - Failure or damage caused by transportation, moving and falling after receiving goods.
  - Damage caused by other inevitable bad factors.
  - Failure or damage caused by equipment soaking in water.
  - If the temperature is lower than 0°C, please disassemble and put it back indoors. If the equipment is damaged due to this problem, there is no warranty.
4. We only make the above warranties, and do not make any other express or implied warranties (including implied warranties of merchantability, rationality and adaptability to a specific application, etc.). Our company is not responsible for any special, accidental or indirect damages, whether in contract, civil negligence or other aspects.

## Product Warranty Card

Product name:		
Product model:		
Ex-factory number:		
Date of appearance:		
Customer name:		
Contact number:		
Customer address:		
Warranty contents:		After sale:
Client signature:	<input type="checkbox"/> Satisfied	<input type="checkbox"/> Dissatisfied
Warranty contents:		After sale:
Client signature:	<input type="checkbox"/> Satisfied	<input type="checkbox"/> Dissatisfied
Warranty contents:		After sale:
Client signature:	<input type="checkbox"/> Satisfied	<input type="checkbox"/> Dissatisfied

## FCC Warning



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

## Documents / Resources

<div>Smart Water Valve (Zigbee) User Manual</div> <div></div> <div>www.sainlogic.com</div>	<div><a href="#">Sainlogic QT-06 Zigbee Smart Water Valve</a> [pdf] User Manual</div> <div>S-W-1, SW1, 2A7KU-S-W-1, 2A7KUSW1, QT-06 Zigbee Smart Water Valve, QT-06, Zigbee Smart Water Valve</div>
---	---

## References

- S [Sainlogic High Tech Innovation Co.,LTD](#)