

samsara AG46 Unpowered Asset Tracker User Manual

Home » Samsara » samsara AG46 Unpowered Asset Tracker User Manual



Contents

- 1 samsara AG46 Unpowered Asset Tracker
- **2 OVERVIEW**
- **3 CONNECTIVITY**
- **4 LOCATION**
- **5 POWER**
- **6 ENCLOSURE**
- **7 SAMSARA CLOUD**
- **8 INSTALL ACCESSORIES**
- 9 IC REGULATIONS
- 10 FEDERAL COMMUNICATION COMMISSION INTERFERENCE
- **STATEMENT**
- 11 Documents / Resources
- **12 Related Posts**



samsara AG46 Unpowered Asset Tracker



OVERVIEW

The AG46 Unpowered Asset Tracker is a wallet-sized tracker ideal for monitoring assets like intermodal containers, construction equipment, dumpsters, light towers and other mobile assets etc. It features customizable GPS check-ins, a lithium battery that lasts up to 5 years and a waterproof and ruggedized enclosure. The AG46 enables increased asset utilization, theft recovery and optimized pool inventory management. It is part of Samsara's complete

sensor system that combines asset tracking, fleet management, safety, and compliance solutions in a single platform.

CONNECTIVITY

• Cellular: LTE-M Connectivity

• Offline Storage: Built-in flash memory logs data when Internet connectivity is unavailable

• Security: All Internet connectivity secured via SSL with 256-bit AES encryption (military-grade)

LOCATION

- **GPS**: Advanced positioning system simultaneously reads from multiple independent satellite systems including GPS and GLONASS global navigation satellite systems. Internal antenna for discreet installation. Industry-leading -146 dBm sensitivity with 1-second time-to-fix (hot start).
- Default Check-in: Twice per day

POWER

- Battery
 - 4 lithium batteries
 - Typical battery life 4-5 years (2 check-ins/day)
 - · Actual battery life may be affected by extreme cold or cellular signal strength

ENCLOSURE

· Material: Polycarbonate

Dimensions: 70x112x29 mm

· Weight: 180 gms

Operating Temperature: -20°C to 65°C

IP Rating: IP67 Certified (weatherproof and water resistant up to 1m submerged)

SAMSARA CLOUD

Features

- Map-based location tracking
- Ability to customize ping rates and switch to real-time for theft detection
- Developer APIs
- Alerts
- Geofence

INSTALL ACCESSORIES

· What's Included

- Anti-theft machine screws
- Anti-theft self taping screws
- · Anti-theft screw bit
- VHB strip
- Alcohol wipes

LITHIUM BATTERY PRECAUTIONS

Customers should NOT manually replace batteries in the AG46. Improper handling or installation of lithium batteries can cause significant heat and/or bursting. If AG46 batteries are low or dead, contact Samsara for replacement.

For questions about the safe use of lithium battery powered devices, please consult your company's safety department.

IC REGULATIONS

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- 1. This device may not cause interference; and
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with Innovation, Science and Economic Development Canada RF exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated to ensure a minimum of 20 cm spacing to any person at all times.

CAN ICES-3(B)/NMB-3(B)

IC Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. 4

Documents / Resources



<u>samsara AG46 Unpowered Asset Tracker</u> [pdf] User Manual 2046, 2AIHD2046, AG46, Unpowered Asset Tracker, AG46 Unpowered Asset Tracker, Asset Tracker, Tracker

Manuals+,