



samsara Unpowered Asset Gateway AG51 (AG51-EU) User Manual

[Home](#) » [Samsara](#) » samsara Unpowered Asset Gateway AG51 (AG51-EU) User Manual 

Contents

- [1 samsara Unpowered Asset Gateway AG51 \(AG51-EU\)](#)
- [2 OVERVIEW](#)
- [3 CONNECTIVITY](#)
- [4 Technical Specifications](#)
- [5 Regulations](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



samsara Unpowered Asset Gateway AG51 (AG51-EU)



OVERVIEW

The AG51 Unpowered Asset Tracker is a wallet-sized tracker ideal for monitoring assets like intermodal containers, construction equipment, dumpsters, light towers and other mobile assets etc. It features customizable GPS check-ins, user-replaceable AA batteries that lasts 3 years and a waterproof and ruggedized enclosure. The AG51 enables increased asset utilization, theft recovery and optimized pool inventory management. It is part of Samsara's Connected Operations Cloud, enabling you to capture data that helps you run your operations more efficiently, safely, and sustainably.

sales@samsara.com

CONNECTIVITY

Cellular LTE Cat M1

Operating area: United States, Canada, Mexico, EU (countries with LTE-M)

Offline Storage Built-in flash memory to store data when Internet connectivity is unavailable

Security All Internet connectivity secured via HTTPS with TLS encryption

Technical Specifications

LOCATION

- **GPS** Advanced positioning system simultaneously reads from multiple independent satellite systems including GPS. Internal antenna for discreet installation.
- **Default Check-in** 2 check-ins per day

POWER

Battery 3 Energizer L91 AA batteries

Typical battery life 3 to 5 years with 2 check-ins per day. Actual battery life may be affected by extreme temperature or cellular signal strength.

User-replaceable batteries

For questions about the safe use of AA battery powered devices, please consult your company's safety department

ENCLOSURE

- **Material** UV-stabilized polycarbonate
- **Dimensions** 110 x 81 x 31 mm
- **Weight** 168 g
- **Operating Temperature** -40°C to 60°C
- **IP Rating** IP67 (weatherproof and water resistant up to 1m submerged) IP69K (highest grade resistance to high pressure and high temperature washdown)

SAMSARA CLOUD SOFTWARE FEATURES

Features Map-based location tracking Approximate cell and WiFi based location Developer APIs Alerts Geofence

INSTALL ACCESSORIES

What's Included 2x Phillips screws

Regulations

IC REGULATIONS

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with Innovation, Science and Economic Development Canada RF exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated to ensure a minimum of 20 cm spacing to any person at all times.

IC Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Installation Statement:

This device requires professional installation and must be installed by a trained person.

	<p>samsara Unpowered Asset Gateway AG51 (AG51-EU) [pdf] User Manual</p> <p>2051, 2AIHD2051, Unpowered Asset Gateway AG51 AG51-EU, Unpowered Asset Gateway AG 51, Asset Gateway AG51, Asset Gateway, AG51, AG51-EU</p>
---	---