

Sandbox Smart Technology 384R2A Smart R2 Roaster User Guide

Home » Sandbox Smart Technology » Sandbox Smart Technology 384R2A Smart R2 Roaster User Guide 🖫



Safety and Regulatory Guidelines

Contents

- 1 Use and Cleaning Instructions
- 2 Documents / Resources
- **3 Related Posts**

Use and Cleaning Instructions

- 1. The user must be next to the product when using it. Do not roast beans for more than 20 minutes at a time.
- 2. Ensure that the roaster door and lower bean tray are tightly closed when roasting.
- 3. In the event of an abnormality during roasting, turn off the power immediately. Open the door once the outer shell of the machine is completely cooled down.
- 4. If the Bluetooth is disconnected during roasting and the temperature of the machine is higher than the safety mechanism, the roaster will automatically shut down if the Bluetooth connection is not resumed within 30 seconds.
- 5. Do not roast anything other than coffee beans in this product.
- 6. Do not use this product outdoors. This product must be placed in a dry and well-ventilated environment and should be placed in an area with at least 20cm of clearance around the product.
- 7. Do not place this product on an uneven surface. To avoid fire, do not place the roaster on or next to non-heatresistant, flammable materials, or next to flammables (such as curtains) or heat-generating appliances, electric heaters or gas stoves.
- 8. To avoid being burned, do not touch the machine's body and always wear gloves when using the roaster.
- 9. Please clear out the chaff after each use to avoid residual chaff from catching fire.
- 10. Unplug the machine before cleaning and wait for it to cool down to assemble or remove accessories.

- 11. Clean the coffee oil collection tank periodically.
- 12. Do not soak or splash water onto the product. Use water or neutral detergent when cleaning.
- 13. To have a clear view of the color change of coffee beans during roasting, please wipe the bean-viewing window on a regular basis.
- 14. To avoid danger, do not use an extension cable or share power sockets with another appliance.
- 15. Do not allow children to use this product unsupervised. Do not use it where infants can gain access.
- 16. To prevent electric shock, do not put the power cable, plug, or other parts in water.
- 17. Please ensure the power supply used is the same as the rated voltage marked on the product. Properly insert the plug into a power socket to avoid electric shock, short circuit, smoke, or fire.
- 18. Immediately stop using the power socket if it is damaged. Only resume use once it is repaired.
- 19. This product is for home use only.

ISED Statement:

This device contains license-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s).

Operation is subject to the following two conditions:

- 1. this device may not cause interference,
- 2. this device must accept any interference, including interference that may cause undesired operation of the device.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference In a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and a human body.

This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent, or a similarly qualified person in order to avoid a hazard.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

Children are being supervised not to play with the appliance.

appliances are not intended to be operated by means of an external timer or separate remote-control system. This appliance is intended to be used in household and similar applications such as:

- -staff kitchen areas in shops, offices, and other working environments;
- -farmhouses;
- -by clients in hotels, motels, and other residential type environments;
- -bed and breakfast type environments.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and a human body.

Documents / Resources



Sandbox Smart Technology 384R2A Smart R2 Roaster [pdf] User Guide 384R2A, 2AW85-384R2A, 2AW85384R2A, 384R2A Smart R2 Roaster, Smart R2 Roaster

Manuals+,