



Home » saxby lighting » Saxby lighting 114573 Bulkhead 2 In 1 MW Sensor Instruction Manual



### Contents [ hide ]

- 1 Saxby lighting 114573 Bulkhead 2 In 1 MW Sensor
- 2 Product Information
- 3 Product Usage Instructions
- 4 Dimensions
- 5 Installation Procedure
- 6 CONTACT
- 7 Frequently Asked Questions
- 8 Documents / Resources
  - 8.1 References



Saxby lighting 114573 Bulkhead 2 In 1 MW Sensor



### **Product Information**

### **Specifications:**

Product Name: Bulkhead 2-in-1 MW Sensor

• Model Number: 114573

Manufacturer: UK Manufacturer – BH17 7BY, EU Manufacturer – Brilliant AG,
 Brilliantstrasse 1, D-27442 Gnarrenburg

• Website: www.saxbylighting.com

# **Product Usage Instructions**

## **Unpacking and Inspection:**

Upon receiving the product, carefully unpack and inspect for any isible damage. If any damage is found, contact customer support immediately.

#### Installation:

Follow the installation instructions provided in the manual. Ensure the product is installed securely and according to the recommended guidelines to prevent any

accidents.

### Operation:

Before using the product, make sure to read the user manual thoroughly. Follow the operating instructions to ensure safe and satisfactory operation of the Bulkhead 2-in-1 MW Sensor.

#### Maintenance:

Regularly inspect the product for any signs of wear or damage.

Clean the sensor periodically to maintain its functionality. Refer to the manual for specific maintenance instructions.

#### **Bulkhead 2-in-1 MW Sensor**

#### 114573


Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please retain these instructions for future reference.

- Max Load 20W (LED)
- Operating Temp -20°C +40°C
- Connection Type Quick Connector
- Sensor Type Microwave
- Mounting Height 6m Max.
- Control Type ON/OFF/STEP-DIM



## **Dimensions**

Description	L (mm)	W (mm)	H (mm)	Weight
Plug & Play MW Sensor (For Bulkheads)	50	27	23	30g






WARNING: Risk of electric shock!

- Isolate the mains power before proceeding.
- Turn off the mains power before performing inspections, installation, or removal
- Verify that the supply voltage is correct by comparing it with the luminaire label information

- It is the responsibility of the installer to ensure installation is suitable for the total load of the product(s). The supply cable, fuses/circuit breakers must be correctly rated for the electrical load and considering for any transient inrush currents that may occur.
- Do not perform insulation strength or resistance tests on installed products. connected



### **Installation Procedure**



Dayl	ight S	ensor	Sensitivity			Times & Standby					
1	2	Lux Level	3	4	Detection area	5	6	7	Hold Time	Standby Time	Standby Dim-Level
-	-	Disable	-	-	100%	-	-	-	5s	0	0%
ON	-	50Lux	ON	-	75%	-	ON	ON	1min	0	0%
-	ON	25Lux	-	ON	50%	ON	ON	ON	10min	0	0%
ON	ON	2Lux	ON	ON	25%	-	-	ON	30s	1min	20%
						ON	-	-	30s	10min	20%
						ON	-	ON	1min	5min	20%
						1	ON	1	3min	10min	20%
						ON	ON	-	3min	Permanent	20%

Default Setting: Daylight sensor disabled; Sensitivity 100%; Hold time 5s; Standby 0%

### **CONTACT**

V1 26/08/2024

UK Manufacturer: BH17 7BY

EU Manufacturer: Briliant AG,

Brilliantstrasse 1, D-27442 Gnarrenburg

www.saxbylighting.com

# **Frequently Asked Questions**

- Q: Can the sensor be adjusted for sensitivity?
  - **A:** Yes, the sensor sensitivity can be adjusted according to your needs. Refer to the user manual for detailed instructions on adjusting the sensitivity settings.
- Q: Is the product suitable for outdoor use?
  - A: Yes, the Bulkhead 2-in-1 MW Sensor is designed for outdoor use. However, ensure it is installed in a suitable location protected from direct exposure to harsh weather conditions.
- Q: How can I reset the sensor if it malfunctions?
  - A: To reset the sensor, follow the reset procedure outlined in the user manual.
    Typically, this involves turning off the power source for a few seconds and then turning it back

# **Documents / Resources**



Saxby lighting 114573 Bulkhead 2 In 1 MW Sensor [pdf] Instruction Manu

al

114573 Bulkhead 2 In 1 MW Sensor, 114573, Bulkhead 2 In 1 MW Sensor, Sensor

### References

- User Manual
  - 114573, 114573 Bulkhead 2 In 1 MW Sensor, Bulkhead 2 In 1 MW Sensor, saxby lighting,
- saxby lighting Sensor

# Leave a comment

Tour email address will not be published. Required fields are marked							
omment *							
ame							
mail							
/ebsite							
ensite							

☐ Save my name, email, and website in this browser for the next time I comment.

### **Post Comment**

### Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.