

SCANCOOL KF 560 BE, KF 1006 E, KF 1563 BE Display Fryser **Instruction Manual**

Home » SCANCOOL » SCANCOOL KF 560 BE, KF 1006 E, KF 1563 BE Display Fryser Instruction Manual



Contents

- 1 SCANCOOL KF 560 BE, KF 1006 E, KF 1563 BE Display
- **2 Product Information**
- **3 OPERATING AND INSTRUCTION MANUAL**
- **4 CLEANING**
- 5 How to use
- 6 Checks
 - 6.1 SYMPTOMS
- **7 WARRANTY & SERVICE**
- **8 EU DECLARATION OF CONFORMITY**
- 9 Documents / Resources
 - 9.1 References
- 10 Related Posts



SCANCOOL KF 560 BE, KF 1006 E, KF 1563 BE Display Fryser



Product Information

The product is an upright glass door merchandiser designed for the storage and display of beer and beverages for sale. The product has different models, including KF 560 BE, KF 1006 E, and KF 1563 BE. The product comes with a user manual that contains safety precautions, installation instructions, and warranty information.

OPERATING AND INSTRUCTION MANUAL

Upright Glass Door Merchandisers

This user manual was originally written in English. Please read the instructions carefully before using.

SAFETY PRECAUTIONS

The purpose of the safety precautions in this manual is to ensure safe and correct use of the unit to minimize risks that could cause serious damage and injury to you or other persons. The safety precautions are divided into WARNINGS and CAUTIONS. Cases where improper handling of the unit could lead to death or serious injury are listed under the "WARNING" heading. However, the cases listed under the "CAUTION" heading could also lead to serious results. To ensure the safety, adhere strictly to both types of safety precautions.

Text set off by the exclamation mark contains information that should be strictly adhered to. After reading the instruction manual, store it an easily accessible place where the user(s) of this product can easily find it.

PRECAUTIONS FOR INSTALLATION

- Installation should be performed only by the dealer or a qualified expert. Attempting to install the unit yourself could result in water leakage, refrigerant leakage, electrical shock, or fire.
- Never put flammable or volatile substances into the unit as explosion and fire could result.
- Use a dedicated wall outlet. Do not use extension cords or convenience receptacles as this could result in electrical shock, over-heating and a fire
- Never splash water directly onto the product or wash with water as short circuit and electrical leakage could
 result.
- Do not damage, modify, excessively bend, strain, twist or bundle up the power cord.
- Also, placing heavy objects the power cord or squeezing it in a tight place could damage it, possible resulting
 in electrical shock or fire.

- Never use flammable spray cans or leave flammable substances near the unit.
- · Sparks from electrical switches could result in explosion and fire
- The cooler is intended for storage and dis-play of beer and beverage for sale. Do not use for other purpose than the intended as this could adversely affect items placed in the unit.
- For indoor use only. Using the unit in a location exposed to rain could result in electrical leakage and electrical shock.
- Install the unit in a location where the floor is sturdy enough to support the load of the unit, If the floor is not sturdy enough or in-stallation is incorrectly performed, the unit could tip over and falling shelves and products could cause personal injury.
- Store the unit in a location where it is not exposed to rain. Using a unit that has been exposed to rain could result in electrical leakage and electrical shock.
- · Leave disassembly and disposal of the unit to qualified experts.
- Never attempt to insert fingers, sticks, etc. fan is rotating at high speed inside the out-let. Injury, electrical shock and improper op-eration could result.
- Never place heavy objects or items containing water op top of the unit.
- Objects could fall down and cause injury and spilled water could deteriorate the insulation of electrical components and re-sult in electrical leakage.
- If you find gas leakage, please don't touch the cooler and close gas and open the door for ventilation. Gas leakage cause explosion, fire and fire injury.
- Away from hot air sources. Cooling performance is reduced if the unit is placed near heat sources such as hot plates and stoves and if it is exposed to direct sunlight.
- Should the unit need temporary storage, make sure not to store the unit in a location where children play and take precautions so that the door cannot be completely closed. This will minimize the risk that a child be-comes trapped inside the compartment.

WELL VENTILATED PLACE

- Please make more than 10 cm space be-tween cooler and wall. If there are no space, cooling capacity can drop down.
- Never hang from the door or climb onto the unit. The unit could tip over or fall and cause material damage or injury.
- Grasp the handle when closing the door.
- Holding at other positions could result in pinched fingers and Injury.
- When disconnecting the power cord plug from the wall outlet, hold at the plug main body close to the outlet. Pulling the cord could cause wire breakage, possible resulting in overheating and fire.
- Do not throw items onto the shelves and do not place items more than total 30 kg on each shell. The shelf could fall down, possibly cause Injury.
- If installation in a damp location is unavoidable, also Install an electrical leakage circuit breaker. If no electrical leakage circuit breaker is installed, electrical shock could result.
- Disconnect the power cord plug from the wall outlet before moving the unit and make sure that the power cord is not damaged during transport. A damaged power cord could result in electrical shock and/or fire.
- Do not push hand against or apply excessive force to glass surfaces as the glass could break and cause Injury.
- Make sure that the unit does not tip over or fall when it Is moved. A falling unit could cause serious injury.
- Be sure attach and secure shelves correctly. An improperly attached shelf could fall down and cause Injury.

PLACING ITEMS IN THE SHOWCASE

This showcase employs a forced circulation of cold air system. If circulation of cold air is obstructed, the items will not be adequately refrigerated. Pay attention to the following points:

- Do not let items obstruct the cold air in-let and suction outlet.
- Place items so that they do not protrude from the shelves, the gap between the shelves and the door is used for circulation of cold air.
- · Place items evenly on all shelves,
- Please do not display goods on the bottom, Please put goods on the shelf.

CLEANING

WARNING: To prevent any electrical shock hazards or injury by rotating circulation fan, always dis-connect the power cord plug from the wall outlet before cleaning.

EXTERIOR AND COOLER COMPARTMENT

Wipe with a soft, dry cloth. If very soiled, wipe with a cloth that has been moistened with a detergent. Then wipe with a cloth that has been dipped in water.

WARNING

- Do not splash water directly onto the cooler and do not wash with water. Short-circuit and electrical shock could result.
- Clean the cooler regularly to keep it clean at times.
- Never use polishing powder, soap powder, benzene, Oil or hot water as these will dam-age the painting and Plastic components

CHECKS

- To ensure the safety, perform the following checks after cleaning.
- Is the power cord plug firmly inserted into a dedicated wall outlet? Confirm that the plug is not abnormally hot.
- Check the power cord for cracks and damage. Should the slightest irregularity be observed, contact the dealer from whom you purchased this unit or our customer's service.

This marking indicates that this product should not be d is posed with other house-hold wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable re use of material resources. To re-turn your used device, please use the return and collection systems or contact there tailer where the product was purchased. They can take this product for environmental safe recycling.

How to use

BEFORE USE

- Remove shipping package, tape, ate and leave doors open ventilation for a while.
- The unit is cleaned before shipment. How-ever, clean the compartment interior once after delivery

- Please insert power supply plug into the wall outlet.
- Allow the unit to operate for about 1 hour to cool the compartment before placing items in the cooler

WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the circuit-breaker, the com-pressor may be overloaded, and/or other damage may occur.

TEMPERATURE ADJUSTMENT

For glass door freezer, the interior temperature will be kept at -1s~-22°C under+ 25°C ambient temperature. If the ambient temperature is extremely high or the stuffing food inside is too much, that might cause the interior temperature a little bit higher. So, it would be better to adjust the digital controller by setting a lower temperature so as to maintain the right temperature. On the opposite, if the ambient temperature is very low or empty loaded, or in less food storage, the interior temperature. might be able to reach minus 30°C, and in re tum to cause the evaporator ice up; Thus, it would be better to re-adjust the digital controller by setting a higher temperature.

DRAIN TRAY

- Defrosting is performed automatically and drain water is collected in the drain tray.
- Water is in the drain tray is evaporated automatically. In humidity, large amount of water in the drain tray, so please throw away drain water once a day.

EFFICIENT USE

- Please follow the below instruction, you could save energy.
- To prevent cold air from escaping, open and close the door quickly and keep the door opened for as short a time as possible.
- Please install the unit in the place which is well-ventilated.

SHELF HEIGTH ADJUSTMENT

The shelf height can be adjusted. Arrange the shelves in accordance with the dimensions of the items to be placed in the cooler.

Checks

In case the unit shows operating problems, check the following prior to calling the authorized service company:

SYMPTOMS

The unit is not operating

- · Faulty electrical contact
- Poor electrical power
- Thermostat setting II O"
 - Verify electrical connections
 - Check the power connection and electrical outlet
 - · Change the thermostat setting to a higher number

Not reaching desired temperature

- · Unit is exposed to direct sunlight
- Thermostat is not properly adjusted
- · Clogger condenser
- · Blocked grills
- · Door not properly closed
- · Products poorly distributed or excess product load
- · For Models with electronic
 - · Relocate the unit to a shaded area
 - · Adjust the thermostat setting to a higher number
 - Review Maintenance instructions listed in them annual
 - · Clean the grills of any debris collected
 - · Check the leveling of the unit and door seal
 - Redistribute the product load according start instructions
 - Unplug the unit from the outlet. If the error continues, contact an authorized service temperature controller, indicates EO or EI technician

Water on the floor

- · The unit is not properly level
- Friction with other objects
- Drain hose is outside of the d rain pan
 - · Level the unit following the installation instructions
 - Move the unit and avoid contact with other objects
 - Locate the hose in the drain pan

Abnormal noises

- · The unit is not properly level
- · Friction with other objects
 - · Level the unit following the installation instructions
 - · Move the unit and avoid contact with other objects
 - Locate the hose in the drain pan

WARRANTY & SERVICE

Warranty is valid for one year from the date of purchase.

The warranty covers d elective parts and work manship. The following items are not covered under warranty:

- 1. Loss of products.
- 2. Damages caused by transportation.
- 3. Damages caused by modifications made by unauthorized individuals.

- 4. Flourescent lights, glass parts or plastic component parts.
- 5. Worn out plugs or defective electrical components.
- 6. Maintenance of the unit.
 - Warranty is valid s having the purchase receipt.

We offer a professional service network which offers then necessary technical support for your unit.

WARNING

- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Don't use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- · Don't damage the refrigerant circuit.
- Don't use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in as ate w ay and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Equipment is only allowed to transport and place in the normal way, during transportation, we need to ensure heat from sun radiation to equipment is not more than 60°C, so as to protect refrigeration unit.
- Equipment should be installed in a well-ventilated place, avoid larger thermal radiation. (Prohibit in front of a heater or heating equipment)
- For any types of maintenance and well-keeping, need to stop power supply first, and professional personnels required.
- R290 discharge is only allowed to operate in we 11-ventilated room or out-door, open flame is prohibit.
- LED light is not allowed to re-place by oneself, but by professional maintenance personnel.
 - · Lamp type: LED light.
 - Energy efficiency level: N/A
- Do not store explosive sub-stances such as aerosol cans with a flammable propellant in this appliance.

Access to professional repair, such as internet webpages, addresses, contact details.

Model no: KF 1006 E

Aftersales service station list:

Address	Scandomestic A/S
Contact Number	7242 5571
Website	Scandomestic.dk
QR code	977972
Relevant information for ordering spare parts, directly or through other channels provided by the manufacturer, importer or authorised representative;	Scandomestic A/S
The minimum period during which spare parts, necessary for the repair of the appliance, are available;	8 years
Instruction on how to find the model information in the product database, as defined in Regulation (EU) 2019/2019 by means of a weblink that links to the model information as stored in the product database or a link to the product database and information on how to find the model identifier on the product.)	www.scandomestic.dk

Note: The address or contact phone number of the service site is subject to change without prior notice. Please confirm whether the service station is a directly affiliated one of our company when requiring services.

EU DECLARATION OF CONFORMITY

Ref. Ares In accordance with EN ISO 17050-1:2004

Model number (unique identification of the product):	KF 560 BE
Name and address of the manufacturer or his authorised representative:	Scandomestic A/S Linåvej 20
	8600 Silkeborg Denmark
This declaration of conformity is issued under the sole responsibility of the manufacturer (or installer):	Scandomestic A/S Linåvej 20
	8600 Silkeborg Denmark

Object of the declaration (identification of product allowing traceab ility. It may include a colour image of sufficient clarity to enable the identification of the product, where appropriate.) Product: Commercial freezer Brand: Scancool Colour: Black Model name: KF 560 BE The object of the declaration described in point 4 is in conformity EN 61000-3-2 with the relevant Union harmonisation legislation: EN 55014-1:2017, EN 55014-2:2015, EN I EC 61000-3-2:2019, EN 61000-3-3:2013+A1:2 019. 2014/30/EU, 2019/2018, 2019/2024, EN IS References to the relevant harmonised standards used, or references to the specifications in relation to which conformity is d 23953-1:2015, EN ISO 23953-2:2015, EN eclared: 60335-2-89:2010+A1:2016+A2:2017, EN 60335-1:2012+A11:2014+A13:2017+A1:2019+ A 14_2019+A2:2019, EN 62233:2008, MD 2 006/42/EC Where applicable: the notified body ... (name, number)... perform RoHS 2011/65/EU ed ... (description of intervention)... and issued the certificate:

Ref. Ares In accordance with EN ISO 17050-1:2004

Additional information:

Model number (unique identification of the product):	KF 1006 E
Name and address of the manufacturer or his authorised representative:	Scandomestic A/S Linåvej 20 8600 Silkeborg Denmark
This declaration of conformity is issued under the sole responsibility of the manufacturer (or installer):	Scandomestic A/S Linåvej 20 8600 Silkeborg Denmark

The appliance is intended exclusively for st

oring ice and packaged food

Object of the declaration (identification of product allowing traceab ility. It may include a colour image of sufficient clarity to enable the identification of the product, where appropriate.)

Product: Commercial freezer Brand: Scancool

Colour: Black

Model name: KF 1006 E



The object of the declaration described in point 4 is in conformity with the relevant Union harmonisation legislation:	EN 61000-3-2
References to the relevant harmonised standards used, or references to the specifications in relation to which conformity is d eclared:	IEC 60335-2-89:2019, IEC 60335-1:2010, COR1:2010, COR2:2010, AMD1:2013, CO R1:2014, AMD2:2016, COR1:2016, 2014/30/EU, EN 55014-1:2017+A11:2020, EN
	55014-2:2015, EN IEC 61000-3-2:2019, E N 6100-
	3-3:2013+A1:2019, 2019/2018, 2019/2024, EN ISO 23953-1:2015, EN IS O 23953-2:2015, 2014/35/EU, EN 60335-2 -89:2010+A1:2016+ A2:2017, EN 60335-1: 2012+A11: 2014+A13:2017
	+A1:2019+A2:2019+A14:2019, EN 62233: 2008,
	2011/65/EU, 2015/863, Machinery Directiv e 2006/42/EC
Where applicable: the notified body (name, number) perform ed (description of intervention) and issued the certificate:	RoHS 2011/65/EU
Additional information:	The appliance is intended exclusively for st oring ice and packaged food

Ref. Ares In accordance with EN ISO 17050-1:2004

KF 1563 BE
Scandomestic A/S Linåvej 20 8600 Silkeborg Denmark
Scandomestic A/S Linåvej 20 8600 Silkeborg Denmark
EN 61000-3-2
EN 55014-1:2017+A11:2020, EN 55014-2: 2015, EN IEC 61000-3-2:2019, EN 61000- 3- 3:2013+A1:2019, 2014/30/EU, 2019/2018, 2019/2024, EN ISO 23953-1:2015, EN IS O 23953-
2:2015, MD 2006/42/EC, EN 60335-2-
89:2010+A1:2016+A2:2017, EN 60335-
1:2012+A11:2014+A13:2017+A1:2019 +A2:2019+A14:2019, EN 62233:2008, IEC 60335-
2-89:2019, IEC 60335-1:2010, COR1_201 0, COR2:2010, AMD1:2013, COR1:2014, AMD2:2016, COR1:2016
RoHS 2011/65/EU

Documents / Resources

KF 560 BE KF 1006 E KF 1563 BE

> Brugermanual User manual Bedienungsanleitun Användarmanual

SCONCOOL

SCANCOOL KF 560 BE, KF 1006 E, KF 1563 BE Display Fryser [pdf] Instruction Manual KF 560 BE, KF 1006 E, KF 1563 BE, KF 560 BE KF 1006 E KF 1563 BE Display Fryser, KF 560 BE Display Fryser, KF 1006 E Display Fryser, KF 1563 BE Display Fryser, Display Fryser, Fryser

References

- O Scandomestic | Scandomestic.dk
- O Scandomestic | scandomestic.dk

Manuals+,