

SCHWAIGER 658668 6 Way Multiple Socket Power Strip User Guide

Home » Schwaiger » SCHWAIGER 658668 6 Way Multiple Socket Power Strip User Guide



Contents

- 1 SCHWAIGER 658668 6 Way Multiple Socket Power **Strip**
- **2 Product Usage Instructions**
- 3 General safety and maintenance instructions
- 4 Connecting electrical appliances
- 5 Technical data
- 6 Cleaning and maintenance
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**



SCHWAIGER 658668 6 Way Multiple Socket Power Strip



Specifications:

• Supply Voltage: Standard voltage

Output Current: Up to 16 A
 Output Power: 3,680 W

Protection Class: Indoor use only
 Cable Length: Standard length

• **Dimensions:** Standard dimensions

• Color: Standard color

· Weight: Standard weight

Product Usage Instructions

General Safety and Maintenance Instructions:

WARNING: Risk of Electric Shock! Ensure the product is used in dry indoor areas only.

WARNING: Fire Hazard! Do not connect devices with a total current consumption exceeding 16 A.

Package Contents:

The product includes the power strip with six protective contact sockets.

Connecting Electrical Appliances:

- 1. Ensure the Power On/Off Button is switched off.
- 2. Unwrap the connection cable completely.
- 3. Insert the mains plug into an easily accessible socket outlet with earthing contact.

Maintenance and Cleaning:

Regularly check for any damage or defects. Do not use the product if it is damaged. Keep the product clean and free from dust.

Storage:

Store the power strip in a dry and safe place, away from moisture and extreme temperatures.

Disposal:

Dispose of the product in accordance with local regulations for electronic waste disposal.

FAQ:

1. Q: Can I use this power strip outdoors?

A: No, this power strip is designed for indoor use only in dry areas.

2. Q: What should I do if the product is damaged?

A: Do not use the product if it is damaged. Contact customer support for assistance.

3. Q: Is it safe to connect multiple high-power devices to this power strip?

A: No, ensure that the total current consumption of all connected devices does not exceed 16 A to prevent overheating and potential hazards.

Würzburger Straße 17 90579 Langenzenn

Hotline: +49 (0) 9101 702-299

www.schwaiger.de info@schwaiger.de

Disclaimer

Schwaiger GmbH does not accept any liability or warranty for damages that are sustained due to improper installation or mounting, improper use of the product or non-compliance with the safety instructions.

Manufacturer's information

Dear Customer, please contact our Technical Support if you need technical advice and your retailer is unable to help you.

Office Hours (Technical Support in German) Monday to Thursday: 8:00 a.m. – 5:00 p.m.

Friday: 8:00 a.m. – 2:30 p.m.

Congratulations and thank you for purchasing this Schwaiger product. This user guide is designed to help you use and operate the device. Read through the instructions for use carefully. Store this guide safely throughout the product's entire service life and pass it on to any subsequent users or owners. Check that the supplied package is complete and ensure that none of the parts are defective or damaged.

Intended use

This power strip is designed exclusively for extending a socket in dry indoor areas. The product has six protective contact sockets with a maximum output power of 3,680 W.

It is meant for private use only and not for commercial purposes. Please follow these instructions carefully. Any other use is considered improper use and may cause damage.

General safety and maintenance instructions



Risk of Electric Shock!

Faulty electrical installation or excessive mains voltage can lead to electric shock!

- Do not use the product if it is visibly damaged.
- Check the product and the electrical devices to be connected for integrity before each use. Damaged electrical appliances as well as kinked mains cables or bare wires increase the risk of electric shock.
- The mains plug of the appliance must fit into the socket. The mains plug must not be modified in any way. Do
 not use adapter plugs together with protective earthed electrical appliances. Unmodified mains plugs and
 matching sockets reduce the risk of electric shock.
- Avoid physical contact with earthed surfaces such as pipes, heaters, cookers and refrigerators. There is an
 increased risk of electric shock if your body is earthed.
- Do not open the casing. Leave repairs to qualified persons.
- Do not immerse the product in water.
- Never handle the product or the power cord or plug with wet hands.
- Never disconnect the mains plug from the socket by pulling on the connecting cable, but always pull on the mains plug.
- Keep the product away from open flames and hot surfaces.
- Position the product and the connecting cable so that it does not become a trip hazard.

- Do not bend the connecting cable and do not lay it over sharp edges.
- Never operate the product in damp rooms or in the rain.
- Never position the product so that it can fall into water.
- Never take hold of an electrical device which has fallen into the water.
- Ensure that no fluids get into the product; dry the product thoroughly if necessary before using it again.
- Ensure that children do not insert any objects into the product.
- Devices that have another connection in addition to the power connection (e.g. antenna line, telephone line, etc.) must have their own overvoltage protection for this input. Plugged-in power supply units must not exceed a temperature of 50°C.
- The prerequisite for proper functioning of the product is a functioning protective conductor connection of the wall socket (protective contact socket) at which the product is operated.
- Do not expose the product to rain or extreme weather conditions, e.g. minus temperatures, hail, extreme heat.
- Despite the high energy dissipation capacity, there is no absolute safety of the connected devices in case of direct lightning strike.
- Always switch the product off and disconnect it from the mains when you are not using the product, when you
 clean it or if it has a fault.
- Never plug in several power strips in series.
- The product is only deenergized when the mains plug is pulled out.

WARNING

There are dangers for children and persons with reduced physical, sensory or mental abilities (e.g. partially disabled persons, elderly persons with limited physical and mental abilities) or lack of experience and knowledge (e.g. older children).

- Children above the age of eight and people with reduced physical, sensory or mental capabilities or lacking in experience and knowledge may only use the product under supervision or if they undergo a suitable briefing on the safe use of the product and they are aware of the associated risks and hazards. Do not allow children to play with the product. Do not allow children to clean or maintain the product without supervision.
- Keep children under eight years of age away from the product and the connecting cable.
- Do not leave the product unattended while it is in operation.
- Do not let children play with the packaging film. Children can get caught in the film and suffocate while playing.

WARNING

Fire hazard!

- Keep the product away from water, other liquids, open fires and hot surfaces.
- Do not cover the product with objects or clothing.
- Keep the product at a distance of at least 5 cm from easily inflammable materials.
- Never operate the multiple sockets while covered.
- Make sure that neither clothing nor other objects are on the multiple socket.
- Place the multiple sockets in such a way that no heat can build up through adjacent objects or furniture.
- Keep the multiple sockets away from easily flammable materials and objects.
- Do not use the multiple sockets in areas where there is a risk of explosion or fire.
- Do not connect devices with a total power rating greater than 3,680 W or a total current consumption greater than 16 A to the product.

Package Contents

- · Socket strip individually switchable, 6-way
- Instruction Manual

Basic function



Please check if the product is damaged before putting it into operation. If it is damaged, do not use the product!

Connecting electrical appliances

The product has 6x protective contact sockets and a connection cable with a mains plug.

- 1. Make sure that the Power On/Off Button is switched off.
- 2. Unwrap the connection cable completely.
- 3. Insert the mains plug into an easily accessible socket outlet with earthing contact that has been installed in accordance with the regulations. Position the product on a suitable surface and make sure that the connecting cable is properly laid.
- 4. Insert the plugs (protective contact type F CEE 7/4 or Euro plug type C CEE 7/17) of up to six electrical appliances into the protective contact sockets.
- 5. Press the on/off button. The LED indicator then lights up red and the power strip is ready for operation.
- 6. You can now switch each grounding-contact outlet of the power strip on and off individually using the corresponding switch. To do this, set each switch to position "0" (off) or "1" (on).

Technical data

Order code	658668
Model description	SDLS6
Connectors	6x Earthing contact sockets (type F) 1x Earthing contact plug (type F)
Supply voltage	230 V∕ , 50 Hz
Output current	16 A
Output	max. 3.680 W
Protection class	IP20
Connection cable	1.40 m, H05VV-F 3G 1.5 mm ²
Dimension	328 x 41 x 82 mm
Weight	630 g
Color	White

Cleaning and maintenance

Risk of electric shock!

Always unplug the power cord before cleaning the product.

Also disconnect all power plugs of the connected electrical devices from the product.

Short circuit hazard!

Water or other liquids entering the housing can cause a short circuit.

- Never immerse the product in water or other liquids.
- Make sure that no water or other liquids get into the housing.

Risk of damage!

Improper handling of the product may result in damage to the product.

- Do not use aggressive cleaning agents, brushes with metal or nylon bristles, or sharp or metallic cleaning objects such as knives, hard spatulas, and the like. These can damage the surfaces.
- Disconnect the power plug before cleaning the product.
- Clean the product with a soft, dry cloth.
- If the product is stubbornly dirty, use a slightly damp cloth and a little mild detergent if necessary.
- Allow all parts to dry completely afterwards.

Storage

All parts must be completely dry before storing.

- Always store the product in a dry place.
- Store the product out of children's reach in a securely locked place and at a storage temperature between 5 °C and 20 °C (room temperature).

Disposal

The product is delivered in packaging made of recyclable materials to protect against damage during transport. Sort and dispose of these materials in the designated containers. Ask your local disposal company or local council about how to dispose of the product in an environmentally correct way.



Do not dispose of batteries or electric and electronic devices in the normal household waste. The consumer is legally obliged to return electrical and electronic devices, and batteries that are at the end of their useful life to the point of sale or public collection points that have been set up for this purpose. Legislation in the country of use stipulate the specific requirements regarding disposal. The symbol on the product, the user guide or the packaging indicates this legal requirement.



Schwaiger GmbH | Würzburger Straße 17 | 90579 Langenzenn | Hotline: +49 (0) 9101 702-299 | www.schwaiger.de | info@schwaiger.de Geschäftszeiten: Montag bis Donnerstag: 08:00 – 17:00 Uhr, Freitag: 08:00 – 14:30 Uhr

Irrtümer, Abweichungen und Änderungen bei den technischen Angaben und Abbildungen vorbehalten.



SCHWAIGER 658668 6 Way Multiple Socket Power Strip [pdf] User Guide 658668 6 Way Multiple Socket Power Strip, 658668, 6 Way Multiple Socket Power Strip, Multiple Socket Power Strip, Strip, Strip

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.