



SCHWAIGER SDW33USB 3-Way Socket Cube User Guide

[Home](#) » [Schwaiger](#) » SCHWAIGER SDW33USB 3-Way Socket Cube User Guide 

*SCHWAIGER SDW33USB 3-Way Socket
Cube User Guide*

USER GUIDE

Congratulations and thank you for purchasing this Schwinger product. This user guide is designed to help you use and operate the device.

Read through the instructions for use carefully. Store this manual safely throughout the product's entire service life and pass it on to any subsequent users or owners.

Check that the supplied package is complete and ensure that none of the parts are defective or damaged.

Contents

- [1 Intended use](#)
- [2 General safety and maintenance instructions](#)
- [3 Product details](#)
- [4 Package Contents](#)
- [5 Basic functions](#)
- [6 Technical data](#)
- [7 Cleaning and maintenance](#)
- [8 Disposal](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

Intended use

This socket cube is intended exclusively for use as a multiple socket for mobile end devices and electrical appliances in dry indoor areas. The socket cube is suitable for the power supply of up to 3 devices with a

maximum total output of 3680 watts. The maximum load capacity of the USB sockets is 2.4 A. The product is not intended for commercial or other use.

General safety and maintenance instructions



WARNING

- This product is intended for private, non-commercial household use.
- This product is an electronic product that must be kept away from children.
- This product is not a toy! Therefore, keep it out of the reach of children.
- The safety light can become damaged if handled incorrectly.
- Do not drop the product or expose it to strong shocks.
- Never expose the product to high temperatures or extreme cold.
- Only connect the product if the mains voltage of the socket matches the information on the type plate.
- Never exceed the permissible maximum load capacity of the socket cube (max. 3680 W).
- Only plug IT devices into the USB sockets.
- Stop using the socket cube if plastic components become cracked, broken or warped.
- Protect the product from moisture, water, rain, snow or drizzle and use the product only in dry environments.
- Do not disassemble the product into its individual parts. Incorrect assembly can cause electric shocks or malfunctions.
- Do not place burning candles or other open flames on or near the product.
- Do not use the product near heat sources such as radiators or other heat emitting devices.
- Never store the socket cube in such a way that it can fall into a bathtub or washbasin.
- Never disconnect the mains plug from the socket by pulling on the connecting cable, but always pull on the mains plug.
- Do not bend the connecting cable and do not lay it over sharp edges.
- When not using the product, unplug the power cord from the outlet.



Warning

There are dangers for children and persons with reduced physical, sensory or mental abilities (e.g. partially disabled persons, elderly persons with limited physical and mental abilities) or lack of experience and knowledge (e.g. older children).

Fire hazard!


Faulty electrical installation or excessive mains voltage can lead to electric shock.

- Never operate the socket cube covered.
- Make sure that there are no clothes or other objects on the cube.
- Place the socket cube in such a way that no heat can build up through adjacent objects or furniture.
- Keep the socket cube away from easily flammable materials and objects.
- Do not use the socket cube in areas where there is a risk of explosion or fire.

i NOTE

Only disconnect the mains plug when it is not live!

Product details



1	On/off button
2	3x USB connector socket
3	3x earthed socket

Package Contents

- socket cube
- user guide

Basic functions

i NOTE

Please check if the product is damaged before putting it into operation.
If it is damaged, do not use the product!

- Plug the mains plug into an Electrical outlet. Make sure that the device is switched off and that the connecting cable cannot become a tripping hazard.
- Press the rocker switch on the front of the socket cube to switch on the device. The control lamplights orange.
- Connect the desired devices to the sockets of the socket cube provided for this purpose.

- Socket with earthing contact: max. 16 A
- USB sockets: d max. 2,4 A
- When the product is not in use, press the on/off switch to turn the device off.

Technical data

Model description	SDW33USB
Connections	3x USB 2.0 A port 3x Schuko socket (Typ F) 1x Schuko plug (Typ F)
Power Supply	230 V AC, 50 Hz
Output current	16 A
Output power	max. 3.680 W
Average active efficiency	82,50%
Efficiency at low load (10 %)	69,10%
No-load power consumption	0,086 W
USB power supply	5 V DC
USB output current	2,4 A (total)
USB output power	12 W
Cable length	1,4 m
Housing material	PC (fire resistant)
Dimension	93 x 93 x 72 mm
Weight	416 g
Color	white

Cleaning and maintenance



You must disconnect the device from the mains socket before cleaning. Ensure that no liquids get into the product while you are cleaning it. The use of solvent-containing or aggressive cleaning agents as well as alcohol or thinners is prohibited as it could damage the coating or the surface of the product. You should therefore clean the product with a lint-free, ever so slightly damp soft cloth only.

Disposal

The product is delivered in packaging made of recyclable materials to protect against damage during transport. Sort and dispose of these materials in the designated containers. Ask your local disposal company or local council about how to dispose of the product in an environmentally correct way.



Do not dispose of batteries or electric and electronic devices in the normal household waste. The consumer is legally obliged to return electrical and electronic devices, and batteries that are at the end of their useful life to the point of sale or public collection points that have been set up for this purpose. Legislation in the country of use stipulate the specific requirements regarding disposal. The symbol on the product, the user guide or the packaging indicates this legal requirement.

Disclaimer

Schwinger GmbH does not accept any liability or warranty for damages that are sustained due to improper installation or mounting, improper use of the product or non-compliance with the safety instructions.

Manufacturer's information

Dear Customer, Please contact our Technical Support if you need technical advice and your retailer is unable to help you. Our technical support is available in English or German.

Information on warranty

The warranty period starts when the device is purchased. The purchase receipt serves as proof of this date. Keep these documents in a safe place. Our warranty is based on our warranty conditions valid at the time of purchase.




661507 Schwaiger GmbH | Würzburger Straße 17 | 90579 Langenzenn | Hotline: +49 (0) 9101 702-299 |

www.schwaiger.de | info@schwaiger.de

Geschäftszeiten: Montag bis Freitag: 08:00 – 17:00 Uhr | Office Hours: Monday to Friday: 8:00 a.m. – 5:00 p.m.
661507_BDA

Documents / Resources

	<p>SCHWAIGER SDW33USB 3-Way Socket Cube [pdf] User Guide SDW33USB, 3-Way Socket Cube</p>
---	--

[Manuals+](#).