



[Home](#) » [SeenDa](#) » **SEENDA COE203 3 Device Wireless Bluetooth Keyboard and Mouse Combo**
User Manual 

Contents [[hide](#)]

- [1 SEENDA COE203 3 Device Wireless Bluetooth Keyboard and Mouse Combo](#)
- [2 Product Warranty](#)
- [3 Product Features](#)
- [4 USB Connection](#)
- [5 Keyboard Bluetooth Connection](#)
- [6 Keyboard Low Battery Instructions](#)
- [7 Product Specifications](#)
- [8 Package Content](#)
- [9 Safety Warning](#)
- [10 FAQ](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)

SEENDA

SEENDA COE203 3 Device Wireless Bluetooth Keyboard and Mouse Combo



User Manual

- 3-Device Wireless Bluetooth Keyboard and Mouse Combo



2.4G+ Dual BT
Connection



Compact and
Portable Design




Adjustable DPI
1000-1600-2400

Product Warranty

- All Seenda products come with a 24-month warranty policy.
- Please do not hesitate to contact us if you have any questions.
- Our support team will try our best to provide you with a pleasant shopping experience.
- Our email: support@seenda.com
- Our website: www.seenda.com
- Phone: +1844-968-2543
- Mon-Fri: 10 AM – 2 PM; 3 PM – 7 PM ET

- Closed during Holidays

Product Features





- **A:** Left Button
- **B:** Right Button
- **C:** Scroll Wheel
- **D:** DPI Button
- **E:** 2.4G Indicator / DPI Indicator
- **F:** BT2 Indicator / DPI Indicator
- **G:** BT Indicator / DPI Indicator
- **H:** Channel Switch Button
- **I:** Battery Compartment
- **J:** Power Switch
- **K:** USB Receiver

USB Connection

2.4G USB Connection



1. Place 2 AAA batteries into the battery compartment on the underside of the keyboard and 1 AA battery into the battery compartment on the bottom of the mouse. (Ensure correct polarity: positive and negative terminals must match.)

1





2. Turn the Power Switch of both the keyboard and the mouse to ON.

2




3. Press  on the keyboard until the 2.4G Indicator lights up, confirming the keyboard


is in 2.4G mode. (If the 2.4G USB indicator doesn't light up, try pressing FN + ).




4. Press the channel switch button on the bottom of the mouse. The 2.4G Indicator will light up, indicating the mouse is in 2.4G mode.



5. Take out the USB receiver from the mouse's battery compartment.
(Note: The keyboard and mouse share one USB receiver.)




6. Plug the USB receiver into the USB port of the computer, and then the keyboard and mouse can work normally.








Keyboard Bluetooth Connection


1. Place 2 AAA batteries into the battery compartment on the underside of the keyboard.
(Ensure correct polarity: positive and negative terminals must match.)




2. Turn the power switch to ON.



3. Press the Channel Switch Button  /  until the corresponding channel indicator is on. (If the indicator does not light up, try to press FN +  / . Long-press the channel switch button for 3-5 seconds until the corresponding channel indicator flashes quickly, and the keyboard enters Bluetooth pairing mode.




4. Turn on the Bluetooth settings on your device, search or select “SEENDA COE203 KB”, and start Bluetooth pairing until the connection is completed.




Mouse Bluetooth Connection

1. Place 1 AA battery into the battery compartment on the bottom of the mouse. (Ensure correct polarity: positive and negative terminals must match.)




2. Turn the power switch to ON.




3. Press the Channel Switch Button at the bottom of the mouse until $\ast 1 / \ast 2$ it lights up, the mouse enters Bluetooth mode.


Long press Channel Switch Button for 3-5 seconds, flashes $\ast 1 / \ast 2$ quickly, the mouse enters pairing mode.






4. Turn on the Bluetooth settings on your device, search or select “SEENDA COE203 MS”, and start Bluetooth pairing until the connection is completed.




Keyboard Channel Switching






- After  |  |  they are connected, single-press the channel button on the keyboard, and easily switch between multiple devices.

NOTE: If FN lock is enabled, please press FN +  |  |  to switch between connected devices.

Mouse Channel Switching




- After  |  |  are connected, single-press the channel switch button on the bottom of the mouse, and easily switch between multiple devices.















Keyboard Low Battery Instructions

- When the low battery indicator flashes red, it indicates that the keyboard is entering a low battery state.

- If the batteries are not replaced, the keyboard will automatically shut down.
- The keyboard requires two AAA batteries. When installing the batteries, please ensure that the positive and negative poles are correctly aligned.



Keyboard Multimedia Function Keys

Keys	Windows	Android	iOS	Mac OS
 F1	2.4G Channel	2.4G Channel	2.4G Channel	2.4G Channel
 F2	Bluetooth 1 Channel	Bluetooth 1 Channel	Bluetooth 1 Channel	Bluetooth 1 Channel
 F3	Bluetooth 2 Channel	Bluetooth 2 Channel	Bluetooth 2 Channel	Bluetooth 2 Channel
 F4	Light -	Light -	Light -	Light -
 F5	Light +	Light +	Light +	Light +
 F6	Application Switch	Application Switch	Window Switch	Window Switch
 F7	Window Switch	Window Switch	Application Switch	Application Switch
 F8	Display Desktop	Go Home	Go Home	Go Home
 F9	Search	Search	Search	Search
 F10	Mute	Mute	Mute	Mute
 F11	Volume -	Volume -	Volume -	Volume -
 F12	Volume +	Volume +	Volume +	Volume +
	Screenshot	Screenshot	Screenshot	Screenshot
Esc 	FN+ESC (FN lock) button to turn on or turn off the FN function			

Note: The FN function is a cyclic mode (F1-F12 and multimedia functions are cyclically used).

Product Specifications

Keyboard Parameters

Working voltage	3.0V
Working current	≤3mA
Standby current	≤0.4mA
Sleeping current	≤0.04mA
Standby time	300 Days
Working time	200 Hours
Wake up way	Press any key
Keyboard Size	314x124x22mm / 12.4*4.9*0.9in
Keyboard Weight	371g / 0.82lb

Mouse Parameters

Engine	Optical
DPI	1000-1600-2400
Working voltage	1.5V
Working current	≤10mA
Standby current	≤0.6mA
Sleeping current	≤0.05mA
Standby time	300 Days
Working time	100 Hours
Wake up way	Press any key
Mouse Size	110*60*31mm / 4.3*2.4*1.2in
Mouse Weight	60g / 0.13lb

System Compatibility

2.4G USB Channel	An available USB port; Windows 7 to 11 or above.
Bluetooth 1/2 Channel	Bluetooth receiving device; Windows 8/10 or above, macOS 10.12 or above, iOS 8.0 or above, Android 4.4 or above.

Sleep Mode

1. When the keyboard/mouse stops working for 60 minutes, it will automatically enter sleep mode for energy saving.
2. When you use the keyboard/mouse again, you only need to press any key, and the keyboard/mouse will wake up within 3-5 seconds.
3. The channel indicator light will turn on again and start working.

Memory Function

- The keyboard/mouse has a memory function.
- When a channel is connected normally, the keyboard/mouse defaults to this channel after turning off the device and turning it back on, and the channel indicator lights up.

Package Content

- 1* Wireless Keyboard
- 1* Wireless Mouse (The receiver is on the bottom of the mouse)
- 1* User Manual

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

- Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
- Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until

thoroughly dried.

- **Damage and Leakage:** Cease usage and consult customer service if the item is damaged or the battery leaks.
- **Correct Disposal:** Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
- **Radio Frequency Interference:** This device may cause interference with other electronics. Keep a safe distance from sensitive devices.
- **Child Safety:** Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.
- **CAUTION:** Non-compliance with the above warnings can lead to serious injury or property damage.

EU Declaration of Conformity

Declared Object: 3-Device Wireless Bluetooth Keyboard and Mouse Combo

Model: COE203

Rating: Keyboard: 3V \approx 10mA
Mouse: 1.5V \approx 10mA

Place of Production: Made in China

Manufacturer: Dongguan Lingjie Electronics& Technology Co., Ltd

E-mail: andymo@szforter.com

Address: Building 3, No.23, Zhenxing North Road, Taiyuan,
Xiegang Town, Dongguan City, Guangdong Province,
China, 523590

**European
Representative:**



Business name: g.L.L. GmbH
Business address: Bauernvogtkoppel, 55c, 22393, Hamburg, Germany
Email: g.L.L.DE@outlook.com



Business name: AMANTO INTERNATIONAL TRADE LIMITED
Business address: The Imperial, 31-33 St Stephens Gardens,
Notting Hill, London, United Kingdom, W2 5NA
Email: AmantoUK@outlook.com

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

Position:

Managing Director

Signature:

Andy Mo

Date of Sign:

2022.1.5

EU agent name:

Tang Jia

Date of Sign:

2022.1.5



andymo@szforter.com

FAQ

How to deal with disconnection issues, keys repeating or typing & clicking delay?

- Low Battery: Please replace new batteries in time. A low battery can affect the performance of the keyboard mouse.
- 2.4G Wireless Connection: If using a USB to connect the keyboard mouse to the device, unplug and replug the USB receiver. Try using a different USB port if needed.
- Bluetooth Connection: If connecting the keyboard mouse to the device via Bluetooth, delete the Bluetooth name from your device's Bluetooth connection list, restart your device, and re-pair the keyboard/mouse by following the steps in the user manual.
- Distance Limit: Keep a distance of within 10 meters 33 feet for optimal signal strength.
- Try Other Devices: If the issues persist, try to connect the keyboard mouse to other devices to check if the same issues occur and don't hesitate to contact our customer service for assistance.


How to deal with keyboard/mouse won't turn on or stops working?

- Please note the positive and negative poles when installing the batteries.
- Try to change another new batteries to confirm whether it is a battery issue or a fault with the keyboard and mouse.
- If the power indicator of the keyboard does not light up at all, please do not hesitate to contact our customer service for assistance.

What should I do if keys/ mouse buttons stop working or feel sticky?



- Basic Fixes: Clean debris with compressed air for keys or a cotton swab dipped in isopropyl alcohol for buttons.
- Pro Tip: Avoid water or debris entering the keyboard, as these are the main causes of unresponsive keys.

Documents / Resources

	SEENDA COE203 3 Device Wireless Bluetooth Keyboard and Mouse Combo [pdf] User Manual COE203, COE203 3 Device Wireless Bluetooth Keyboard and Mouse Combo, 3 Device Wireless Bluetooth Keyboard and Mouse Combo, Wireless Bluetooth Keyboard and Mouse Combo, Bluetooth Keyboard and Mouse Combo, Keyboard and Mouse Combo
---	--

References

- [User Manual](#)

 SeenDa
 3 Device Wireless Bluetooth Keyboard and Mouse Combo, Bluetooth Keyboard and Mouse Combo, COE203, COE203 3 Device Wireless Bluetooth Keyboard and Mouse Combo, Keyboard and Mouse Combo, SeenDa, Wireless Bluetooth Keyboard and Mouse Combo

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.