



# SENA 50C Intercom with 4K Camera User Manual

[Home](#) » [Sena](#) » SENA 50C Intercom with 4K Camera User Manual 

## Contents

- [1 SENA 50C Intercom with 4K Camera](#)
- [2 OVERVIEW](#)
- [3 Charging](#)
- [4 Music Operation](#)
- [5 Intercom](#)
- [6 Setting](#)
- [7 Troubleshooting](#)
- [8 Certification and Safety Approvals FCC Compliance Statement](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

# SENA

**SENA 50C Intercom with 4K Camera**



## OVERVIEW



## Charging

- Red LED: Charging
- Blue LED: Fully charged

## Power On

Press and hold the Jog Dial and Phone Button for 1 second


## Power Off

Tap the Jog Dial and Phone Button

## Volume Adjustment

Increase/Decrease the volume : Rotate the Jog Dial clockwise or counterclockwise

## Battery Check



## Phone, Music Pairing

Initially Pairing the 50C The headset will automatically enter the phone pairing mode when you initially turn on the headset or in the following situation:

1. Rebooting after executing Factory Reset
2. Press and hold the Jog Dial and Phone Button for 1 second.
3. Search for Bluetooth devices on your mobile phone. Select the 50C in the list of the devices detected on the mobile phone.
4. Enter 0000 for the PIN. Some mobile phones may not ask for the PIN.

## Music Operation

1. Play or pause music: Press and hold the Jog Dial for 1 second.
2. Track forward/ back: Rotate while pressing the Jog Dial clockwise or counterclockwise.

## Mobile Phone Call Making and Answering

1. Answering a call: Tap the Phone Button Ending a call:
2. Tap the Phone Button Voice dial:
3. Tap the Phone Button
4. Rejecting a call: Press and hold the Jog Dial for 2 seconds.

## **Mesh Intercom**

Mesh Intercom On/Off : Tap the Mesh Intercom Button

## **Intercom**

### **Intercom Pairing**

1. Press and hold the Jog Dial of two headsets for 5 seconds until red LEDs of both units start to flash rapidly.  
Intercom Start/End : Tap the Jog Dial.

### **Turning On/Off the Camera**

- Turn on : Tap the Camera Button.
- Turn off : Tap the Camera Button and the Phone Button.

### **Recording Videos**

Start/Stop recording : Press and hold the Camera Button for 1 second

### **Radio On/Off**

Turn on the FM radio: Press the Phone Button for 1 second. Turn off the FM radio: Press the Phone Button for 1 second.

### **Radio Scan Up FM Band**

- Start scanning: Double tap the Phone Button
- Stop scanning: Double tap the Phone Button

### **Radio Move to Preset Station**

Move to next preset: Press the Jog Dial for 1 second (1 → 2 → ... → 10)

### **Radio Seek Stations**

Seek up/down stations: Rotate while pressing the Jog Dial clockwise or counterclockwise.

## **Setting**

Configuration Menu: Press the Center Button for 10 seconds.

### **Using the Sena Device Manager**

Connect the headset to your computer via a USB cable. Launch the Sena Device Manager and click DEVICE SETTING to configure the headset settings.

## **Troubleshooting**

### **Factory Reset**

If you want to restore the headset to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

### **Certification and Safety Approvals FCC Compliance Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antennae
2. Increase the separation between the equipment and the receiver
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

### **FCC RF Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. The antenna used for this transmitter must not transmit simultaneously with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures. When equipped, the distance between antenna and one's head surface is 64mm.

### **FCC Caution**

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

### **Industry Canada(IC) Statement**

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device.

