

SENA SRL-Mesh Bluetooth Communication System User Manual

Home » Sena » SENA SRL-Mesh Bluetooth Communication System User Manual

Contents


- 1 SENA SRL-Mesh Bluetooth Communication System
- 2 SRL-Mesh Manual
- 3 Charging
- 4 Power On/Off
- 5 Phone, Music Pairing
- **6 Music Operation**
- 7 Mobile Phone Call Making and Answering
- 8 Intercom
- 9 Mesh Intercom
- 10 Radio On/Off
- 11 Radio Scan Up FM Band
- 12 Radio Move to Preset Station
- 13 Radio Seek Stations
- 14 Setting
- 15 Troubleshooting
- 16 Certification and Safety Approvals FCC Compliance

Statement


- 17 FCC RF Exposure Statement
- **18 FCC Caution**
- 19 Documents / Resources
- **20 Related Posts**



SENA SRL-Mesh Bluetooth Communication System



SRL-Mesh Manual



- Red LED: Charging
- · Blue LED: Fully charged

Bluetooth and Mesh functions are not supported while charging.


Power On/Off

Press and hold the (+) Button and Center Button for 1 second Tap the (+) Button and Center Button.

Volume Adjustment

- (+) Button Increase the volume
- (-) Button Decrease the volume

Battery Check



Phone, Music Pairing

Initially Pairing the Impulse The headset will automatically enter the phone pairing mode when you initially turn on the headset or in the following situation:

- Rebooting after executing Factory Reset
 - 1. Press and hold the Center Button and (+) Button for 1 second.
 - 2. Search for Bluetooth devices on your mobile phone. Select the SRL-Mesh in the list of the devices detected on the mobile phone.
 - 3. Enter 0000 for the PIN. Some mobile phones may not ask for the PIN.

Music Operation

- Play or pause music: Press the Center Button for 1 second.
- Track back: Press the (-) Button for 1 second.
- Track forward: Press the (+) Button for 1 second.

Mobile Phone Call Making and Answering

- Answering a call: Tap the Center Button
- Ending a call: Press the Center Button for 2 seconds.
- Voice dial: Press the Center Button for 3 seconds.
- Speed dial: Press the (+) Button for 3 seconds.
- Rejecting a call: Press the (+) Button for 2 seconds.

Intercom

Intercom Pairing

- 1. Press and hold the Center Button of two headsets for 5 seconds until red LEDs of both units start to flash rapidly.
- 2. The two headsets will be automatically paired.

Intercom Start/End: Tap the Center Button

Mesh Intercom

• Mesh Intercom On/Off: Tap the Mesh Button

Radio On/Off

- Turn on the FM radio: Press the (-) Button for 1 second.
- Turn off the FM radio: Press the (-) Button for 1 second.

Radio Scan Up FM Band

- Start scanning: Press (+) Button for 1 second.
- Stop scanning: Press (+) Button for 1 second.

Save presets while scanning

• Save presets: Tap the Center Button

Radio Move to Preset Station

Move to next preset: Press the Center Button for 1 second $(1 \rightarrow 2 \rightarrow ... \rightarrow 10)$

Radio Seek Stations

- Seek up stations: Double tap the (+) Button.
- Seek down stations: Double tap the (-) Button.

Setting

Configuration Menu: Press the Center Button for 10 seconds.

Troubleshooting

Factory Reset

If you want to restore the headset to factory default settings, use the Factory Reset The headset automatically restores the default settings and turns off.

- 1. Press the Center Button for 10 second.
- 2. Tap the (-) Button twice.
- 3. Tap the Center Button.

Certification and Safety Approvals FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antennae
- Increase the separation between the equipment and the receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. When equipped, the distance between the antenna and one's head surface is 33.2mm.

FCC Caution

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Documents / Resources



<u>SENA SRL-Mesh Bluetooth Communication System</u> [pdf] User Manual SP116, S7A-SP116, S7ASP116, SRL-Mesh Bluetooth Communication System, SRL-Mesh, Bluetooth Communication System, Communication System

Manuals+,