



## SENA U-COM 4 Motorbike Intercom User Manual

[Home](#) » [Sena](#) » SENA U-COM 4 Motorbike Intercom User Manual 

### Contents

- [1 SENA U-COM 4 Motorbike Intercom](#)
- [2 Music Operation](#)
- [3 Troubleshooting](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

# SENA

### SENA U-COM 4 Motorbike Intercom



U-COM 4(U-COM 2) Manual



### Charging

Red LED: Charging

Blue LED: Fully charged

### Power On/Off


Music Button + Center Button for 1 sec

### Volume Adjustment

Music Button – Increase the volume

Phone Button – Decrease the volume

### Battery Check



### Phone, Music Pairing

1. To access Configuration Menu, press and hold the Center Button for 10 second.
2. To enter Phone Pairing, tap the Music Button for 1 second.
3. Search for Bluetooth devices on your mobile phone. Select the headset in the list of the devices detected on the mobile phone.
4. Enter 0000 for the PIN. Some mobile phones may not ask for the PIN.

### Music Operation

Play music: Press the Music Button for 1 second.

Pause music: Press the Music Button for 2 second.

Track back: Press the Music Button for 1 second.

Track forward: Press the Phone Button for 1 second.

## **Mobile Phone Call Making and Answering**

Answering a call: Tap the Phone Button

Ending a call: Press the Phone Button for 2 seconds.

Speed dial: Press the Phone Button for 3 seconds.

Rejecting a call: Press the Phone Button for 2 seconds.

## **Intercom Pairing**

1. Press and hold the Center Button of two Bluetooth systems for 5 seconds until red LEDs of both units start to flash rapidly.
2. The two headsets will be automatically paired.

## **Intercom Start/End**

1st Friend: Tap the Center Button once.

2nd Friend: Tap the Center Button twice.

3rd Friend: Tap the Center Button triple times

## **Radio On/Off**

Turn on the FM radio: Press the Music Button for 3 second.

Turn off the FM radio: Press the Music Button for 3 second.

## **Radio Scan Up FM Band**

Start scanning: Press Music Button for 5 second.

Stop scanning: Press Music Button for 5 second.

Save presets while scanning

Save presets: Tap the Center Button

## **Radio Move to Preset Station**

Move to next preset: Press the Center Button for 1 second (1 → 2 → ... → 10)

## **Radio Seek Stations**

Seek up stations: Press the Music Button for 1 second.

Seek down stations: Press the Phone Button for 1 second.

## **Setting**

Configuration Menu: Press the Center Button for 10 seconds.

## **Troubleshooting**

### **Factory Reset**

If you want to restore the headset to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

## **Certification and Safety Approvals FCC Compliance Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antennae
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. The antenna used for this transmitter must not transmit simultaneously with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.

When equipped, the distance between antenna and one's head surface is 35mm.

## FCC Caution


Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

## IC RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. The antenna used for this transmitter must not transmit simultaneously with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.

When equipped, the distance between antenna and one's head surface is 35mm.

## Documents / Resources

 <p><b>U-COM 4 MOTORBIKE INTERCOM</b></p> <p><b>SENA</b></p> <p><b>U-COM 4 MOTORBIKE INTERCOM</b></p> <p><b>SP91, S7A-SP91, S7ASP91, U-COM 4 Motorbike Intercom, Motorbike Intercom, Intercom</b></p>	<h1>SENA U-COM 4 Motorbike Intercom [pdf] User Manual</h1> <h2>SP91, S7A-SP91, S7ASP91, U-COM 4 Motorbike Intercom, Motorbike Intercom, Intercom</h2>
--	---