

Sengeer
M88 Rotating Gyroscope
Illuminated Bluetooth Speaker



Sengeer M88 Rotating Gyroscope Illuminated Bluetooth Speaker Instructions

[Home](#) » [Sengeer](#) » Sengeer M88 Rotating Gyroscope Illuminated Bluetooth Speaker Instructions 

Contents

- [1 Sengeer M88 Rotating Gyroscope Illuminated Bluetooth Speaker](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Product Operation Instructions](#)
- [6 Product Function Description](#)
- [7 Bluetooth pairing](#)
- [8 Product Accessories](#)
- [9 Warranty Card](#)
- [10 FCC Warning](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)

Sengeer

Sengeer M88 Rotating Gyroscope Illuminated Bluetooth Speaker



Product Information

Specifications:

- **Compliance:** FCC Part 15
- **Radiation Exposure Limits:** FCC approved
- **Minimum Distance:** 0cm between radiator and body

Product Usage Instructions

Safety Precautions:

1. Ensure the device is operated as per the manufacturer's instructions.
2. Maintain a minimum distance of 0cm between the radiator and your body.
3. Do not attempt to make any changes or modifications to the device without explicit approval from the manufacturer.

Installation:

1. Place the device on a stable surface.
2. Connect the necessary cables as per the provided diagram.
3. Ensure proper ventilation around the device.

Operation:

1. Power on the device using the designated button.
2. Follow the on-screen instructions for setup and configuration.
3. Use the device within the specified temperature and humidity ranges.

Maintenance:

1. Regularly clean the device using a soft, dry cloth.
2. Avoid exposing the device to liquids or extreme temperatures.

3. Contact authorized service centers for any repairs or servicing needs.

FAQ


- **Can I modify the device on my own?**

No, any changes or modifications not approved by the manufacturer may void your warranty and authority to operate.

- **What should I do if I experience interference?**

Ensure the device is placed in an optimal position and check for any nearby sources of interference. Contact customer support if issues persist.

Product Operation Instructions




Product Function Description

1. RGB lighting
2. TF card insertion playback
3. Bluetooth playback
4. Start up TWS with two automatic couplings
5. Gyroscope

Bluetooth pairing

1. Upon the first startup, automatically enter Bluetooth pairing mode, search for “M88” in the connected devices, and select and connect.



2. If successfully paired, the audio system will automatically reconnect to the previous device. If there is no successful reconnection within 5 seconds, enter pairing mode. If pairing is unsuccessful, it will automatically shut down after 15 minutes. When turned off, long press for 5 seconds to force pairing again.

Product Accessories



Charging line



Lanyard



Manual&Warranty Card

Attention: The graphics in this manual are only schematic diagrams, and due to technological and system upgrades, the information and parameters marked may deviate from the actual product. Please refer to the actual product for accuracy.

Warranty Card

Product name		Stamp Office
Product model		
Purchase date		
User name		
User address		
Contact number		
Maintenance man		
Fault description		

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However,

there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 0 cm between the radiator and your body

Documents / Resources

	Sengeer M88 Rotating Gyroscope Illuminated Bluetooth Speaker [pdf] Instructions 2BMLQ-M88, 2BMLQM88, m88, M88 Rotating Gyroscope Illuminated Bluetooth Speaker, M88, Rotating Gyroscope Illuminated Bluetooth Speaker, Gyroscope Illuminated Bluetooth Speaker, Illuminated Bluetooth Speaker, Bluetooth Speaker, Speaker
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.