



## **sensorswitch Time Delay Programming Instructions**

[Home](#) » [sensorswitch](#) » sensorswitch Time Delay Programming Instructions

### **Contents** [ [hide](#) ]

- [1 sensor switch Time Delay Programming](#)
- [2 Time Delay Programming Instructions](#)
- [3 Time Delay Settings Table](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

**sensorswitch**

### **sensor switch Time Delay Programming**



### **Time Delay Programming Instructions**

- ### Time Delay Settings Table

1 ~ 30 Sec 4 ~ 7.5 Min 7 ~ 15.0 Min  
2 ~ 2.5 Min 5 ~ 10.0 Min\* 8 ~ 17.5 Min  
3 ~ 5.0 Min 6 ~ 12.5 Min 9 ~ 20.0 Min

- ## Documents / Resources

[Manuals+](#), [home](#) [privacy](#)