




## SHARPER IMAGE 208747 Multi-Function Electric Kettle User Manual

[Home](#) » [Sharper Image](#) » SHARPER IMAGE 208747 Multi-Function Electric Kettle User Manual 

# SHARPER IMAGE

### Multi-function Electric Kettle USER MANUAL



Thank you for buying our kettle! Please read the instructions carefully before using the kettle! And keep it properly for reference when necessary!


## Contents

- [1 Kettle Description & Parts](#)
- [2 Operating Instructions](#)
- [3 IMPORTANT SAFEGUARDS](#)
- [4 CLEANING & CARE](#)
- [5 CIRCUIT DIAGRAM](#)
- [6 Food grade material](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)


## Kettle Description & Parts

Subject to the actual product

### • Parts



Product Name	Type	Capacity	Rated Watts	Rated Voltage
Liquid Heater (Electric Water Heater)	Sy-616 SY-617 SY-618A	380mL	300W	120V—

-  Products vary in the appearance, the pictures above are for reference only. All products are subject to the actual ones.
- New updates on the products are subject to be shown in the latest manual, without prior notice.

## Operating Instructions

### Before Use

- Remove the cover, add water and make sure water within the max level. When water is boiled, empty the kettle and clean the pot with clean water. For a better cleaning, please repeat the whole process.
- Make sure water below the max level of the pot or it may spill out of the kettle when boiled.

3. If the kettle is powered on without water in the pot, its service life will be reduced.
4. Switch on, the buzzer ticks, the kettle is ready to use when the indicator display lights up for a second and displays “- - -” Touch “TOUCH SWITCH” button: first press, it shows 212°F, second press, it shows 195°F, third press, it shows 175°F, and fourth press, it shows 140°F. When the temperature is set, the figure will flash 3 times, and the kettle starts to heat water. The temperature rises to the set one, the buzzer will tick 3 times, and the kettle starts automatic insulation (The actual temperature will be displayed), the temperature can be maintained for 12 hours.
5. If continuous heating or reheating is needed, switch on when the kettle cools down.
6. The unit is designed for water draining and steam venting
7. The kettle can be covered when heating water. Remove the cover when stewing, or the vent holes on the cover will be obstructed

## **IMPORTANT SAFEGUARDS**

### **• Warning**

Please read the following instructions carefully before you use to avoid any injuries or damages.

1. Never immerse the unit in water or other liquids.
2. Keep close eyes when the kettle is used near a child
3. The kettle is not intended to use by persons with mental disabilities or children
4. Do not leave the kettle running without close supervision
5. Unplug the power cord before cleaning
6. leave the kettle cool before cleaning or storing
7. When any part is damaged directly return the kettle to the service center for inspection and maintenance.
8. Keep the kettle away from electric stove or microwave.
9. Leave it on a flat surface
10. Do not heat other stuff rather than water
11. Do not overfill the kettle or boiled water may spill out.
12. Do not switch the kettle on without water inside.
13. Make sure the kettle is on a flat surface when water is filled
14. Power cord replacement must be conducted by the manufacturer or the service center
15. Plug the cord into an outlet. Switch on the kettle. Power indicator lights up. The kettle starts to heat
16. When not in use, switch off, unplug the power cord.

## **CLEANING & CARE**

Always turn the kettle off and remove the plug from the outlet before cleaning



### **IMPORTANT SAFEGUARDS**


1. Switch the kettle off and remove the plug from the outlet before cleaning. Wipe the kettle body with a damp mop.
2. When scale is spotted use vinegar to dissolve it. Put 1 teaspoon of vinegar and 2 teaspoons of water into the

kettle. Switch on the power. Boil the vinegar and water. Leave it cool. Unplug and rinse several times with clean water. The removal of built-up scale from the inner pot will help extend the life of the kettle.

3. Empty the kettle after each use and put it in a cool place,keeping away from sunshine

CIRCUIT DIAGRAM

For reference only, subject to change without prior notice!



Food grade material

Components	Material	Testing Results
Stainless Steel Inner Pot NTC Stainless Steel Case	Stainless Steel 06Cr19Ni10(304)	Compliance with the standard Requirements
Cover	PP(polypropylene)	Compliance with the standard Requirements
NTC seal ring	PDMS (Silica gel)	Complies with the standard Requirements

Notice:


1. The components and materials used for different types of kettles may vary, all are subject to the actual products.
2. Please keep the stainless steel parts away from the food stuff

Environmental Protection Material

The information listed in the table below is based on the requirements of SJ/T113664 and GB/T 26572.

Product Name: Electric kettle						
Components	Hazardous materials					
	Pb	Hg	Cd	(Cr (vi))	(P1113)	(PBDE)
Plastic Parts	0	0	0	0	0	0
Circuit Board	X	0	0	0	0	0
Heating Unit	0	0	0	0	0	0
Hardware	0	0	0	0	0	0
Power Cord	0	0	0	0	0	0
rewewiseSens cr	X	0	0	0	0	0
Screw	0	0	0	0	0	0
Paling Matera l	0	0	0	0	0	0
<p>NI the Information listed in the table is based on the regulations of Si/T 11364.</p> <p>0 means the amount of the hazardous material contained In the associated part is below the max limit specified In the requirements of GB 26572.</p> <p>X: means the amount of the hazardous material contained In the associated part Is above the max limit specifie d In the requirement of GB/126572 due to the restriction of the current technology, and should be Improved whe n the new technology is available.</p>						

## Documents / Resources

	<p><b><a href="#">SHARPER IMAGE 208747 Multi-Function Electric Kettle</a></b> [pdf] User Manual</p> <p>208747 Multi-Function Electric Kettle, 208747, Multi-Function Electric Kettle, Function Electric Kettle, Electric Kettle, Kettle</p>
---	---