



ShenZhen Exploter Electronics AI-996 ApplePie Mini CarPlay AI Box Instruction Manual

[Home](#) » [Shenzhen Exploter Electronics](#) » [ShenZhen Exploter Electronics AI-996 ApplePie Mini CarPlay AI Box Instruction Manual](#) 

Contents

- 1 [ShenZhen Exploter Electronics AI-996 ApplePie Mini CarPlay AI Box](#)
- 2 [Description](#)
- 3 [Features](#)
- 4 [Specification](#)
- 5 [Unit Picture](#)
- 6 [Compare with Other AI Android Box](#)
- 7 [Operation](#)
 - 7.1 [How to Connect ApplePie's Bluetooth Phone](#)
 - 7.2 [How to Use Wireless CarPlay?](#)
 - 7.3 [How to Use Wireless Android Auto](#)
 - 7.4 [About ApplePie's Setting Options](#)
 - 7.5 [About Floating Ball](#)
- 8 [Restore APPS](#)
- 9 [Resolution Choosing](#)
- 10 [Firmware Update](#)
- 11 [Documents / Resources](#)
- 12 [Related Posts](#)





Warning:

- In order to protect the driving safety and avoid break the traffic law; please DO NOT watch videos while driving.
- Please DO NOT put the product in the damp environment or water, in order to avoid electric shock, damaged and fire accident caused by a short circuit.

Description

ApplePie Mini is the 2nd version of our ApplePie Series CarPlay Android Car Smart Box, which streaming video,audio and control data Such as touch ,the buttons on the steering wheel, the knob operation and so on, Through the OEM CarPlay USB OTG interface in the car, and mirroring the whole Android system to the OEM screen. User can control and operate Apple Pie on the OEM screen, powerful video decoding and playing ability, fully open software application environment.

Features

- ApplePie AI Android CarPlay MMB box with 4G built-in
- Android 9.0 system, wireless CarPlay ,Wireless Android Auto into one module
- Provide Google Play store. Free download and install different APP software
- Full free and open system to DIY own ApplePie and different launch
- Dual Bluetooth built-in for hand free calling, Music and connect all kinds of Bluetooth TPMS, OBDII etc.
- Mirroring whole Android system to OEM Car screen via OTG plug
- HD Video display ,Watch YouTube, online navigation, online radio multimedia system
- Slip screen display and picture in picture
- OEM Touchscreen or OEM Buttons knob control
- Keep OEM Function ,not impact OEM features
- Easy to connect, power supply by OEM CarPlay USB port
- Built-in 4G/3G/2G, ApplePie can be used as a mobile Wi-Fi route to be a hotspot to other device
- Strong specification to offer a stable performance

- 4G Wi-Fi, GPS Antenna all built-in the unit



Specification

| ITEMS | SPECIFITION |
|-----------------------|--|
| OS Version | Android 9 . 0 (GSM Available) |
| CPU | QualComm 8 Core Processor |
| Memory | 4G LP DDR3 + 64G eMMC Flash |
| Network | 2G/3G/4G LTE |
| 2G Frequency | GSM/EDGE 850/900/1800/1900MHz |
| 3G Frequency | UMTS B1/B2/B5/B8 |
| WIFI | 802.11a/b/g/n/AC,2.4G+5G |
| 4G Frequency | LTE-FDD B1/B3/B5/B7/B8/B28 LTE-TDD B38/B40/B41" |
| 4G Coverage area | Asia Pacific (including mainland China , Hongkong,Macao and Taiwan,Southeast Asian countries),thewhole of Europe , Australia , New Zealand , South America . Middle East and Mediterranean countries. |
| USB input | OTG*1 Port USB2.0 |
| TF Card | Support 128GB TF Card |
| Bluetooth | Dual BT Master BLE4 2 & Slave BT5.0 |
| GNSS | GPS/GLONASS/Beidou |
| Power | 5V-12V 2A. |
| Operation temperature | -10°C-70°C |
| Storage Temperature | -20°C-80°C |

Unit Picture

No need install, just connect USB to Car OEM CarPlay OTG Interface port



P.S: Insert 4G Sim card as above photo

Attention: ApplePie Mini accessories are only a USB cable and a Type C adapter as above photo


Compare with Other AI Android Box

| Compare Items | ApplePie(Mini) | Competitor(R) | Competitor(A) |
|----------------------------------|---|---|--|
| CPU Brand | Gualcomm | Rockchip | All Winner |
| CPU Cores | 8Core 1.8GHz | 6Core 1.8GHz | 4Core 1.5GHz |
| DDR | 4G | 4G | 2G or 4G |
| EMMC Flash | 64G | 32G | 16G or 32G |
| WiFi | 802.11a/b/g/n/AC,2.4G+5G | 802.11a/b/g/n/AC,2.4G | 802.11a/b/g/n/AC,2.4G |
| Mobile WiFi | Support | No | No |
| 4G LTE High Speed Network | Support | No | No |
| Master Bluetooth (Master) | BLE 4.2 | No | No |
| Slave Bluetooth (Slave) | BT 5.0 | BT 5.0 | BT 4.2 |
| GPS,Glonass,Beidou | Support | Support | No |
| Mobile Phone AGPS | Support | No | No |
| USB OTG Interface | Support | Support | Support |
| TF Card(Micro SD Card) | Maxmum to 128G | No | No |
| SIM Card | Support | No | No |
| Android System | 9.0 | 9.0 | 7.1 |
| Android System Openness | All Open | Half Open | Half Open |
| Wireless CarPlay | Support | No | No |
| Wireless Android Auto | Support | No | No |
| Mirror Link | Support | Support | Support |
| Duel Screen Picture-in-Picture | Support | Support | No |
| Sound logic of the Oiriginal Car | Same sound as CarPlay logic,Watching Video and Navigation sound Can be mixed or suppressed. | Not in accordance with CarPlay's standard sound logic to handle | No sound logic,processing one size fits all,not mixed tone and depress |
| Power Supply | USB 5V | 12V from Car Fuse | USB 5V |


Operation

How to Connect ApplePie's Bluetooth Phone

You can search for ApplePie from the mobile phone, or search for mobile phones from ApplePie.
From the mobile phone, you can find the Bluetooth device name “ApplePie”, then complete the Bluetooth pairing connection.
From ApplePie, Click the “BT phone” icon:




Search the mobile phone, Click to select the mobile phone to be connected, Click the pairing connection button to complete the pairing and connection



How to Use Wireless CarPlay?


Click the “BT phone” icon to connect the iPhone with the Bluetooth module (slave Bluetooth, BT5.0) on the ApplePie. After one connection, every time the ApplePie starts, it will automatically connect with the Bluetooth of the iPhone.



Click the “SpeedPlay” icon to enter the wireless CarPlay connection.

Then ApplePie will automatically switch to the hotspot sharing mode (at this time, the Wi-Fi switch is automatically turned off), share a hotspot, and send the hotspot name and password to the iPhone via Bluetooth. The iPhone establishes a wireless CarPlay connection with ApplePie through the hotspot shared by ApplePie.

After the connection is completed, ApplePie’s slave Bluetooth will be automatically turned off, and Wi-Fi will also be automatically turned off (because it has been switched to hotspot sharing mode). Then, you will enter the CarPlay UI.




At the CarPlay UI, click the car icon, or click the suspension ball, expand, click the HOME icon, you can return to the launcher of ApplePie.

If you completely close the SpeedPlay app, ApplePie’s slave Bluetooth will automatically turn on and reconnect to your iPhone. But ApplePie is still in hotspot sharing mode and will not automatically switch back to Wi-Fi mode. If you need to use Wi-Fi now, you can pull down the status bar and turn it on directly through the Wi-Fi switch in the status bar.

How to Use Wireless Android Auto

Android 11 mobile phone with local 5G to support wireless Android Auto function


Click the “BT phone” icon to connect the Android mobile phone with the Bluetooth module (slave Bluetooth, BT5.0) on the ApplePie. After one connection, every time the ApplePie starts, it will automatically connect with the Bluetooth of the Android mobile phone.



Click the “speedPlay” icon to enter the wireless Android Auto connection.

Then ApplePie will automatically switch to the hotspot sharing mode (at this time, the Wi-Fi switch is automatically turned off), share a hotspot, and send the hotspot name and password to the Android Phone via Bluetooth. The Android Phone establishes a wireless Android Auto connection with ApplePie through the hotspot shared by ApplePie.

After the connection is completed, ApplePie’s slave Bluetooth will be automatically turned off, and Wi-Fi will also be automatically turned off (because it has been switched to hotspot sharing mode). Then, you will enter the Android Auto UI.




At the Android Auto UI, click the car icon, or click the floating ball, expand, click the HOME icon, you can return to the launcher of ApplePie.

If you completely close the speedPlay app, ApplePie’s slave Bluetooth will automatically turn on and reconnect to your Android Phone. But ApplePie is still in hotspot sharing mode and will not automatically switch back to Wi-Fi mode. If you need to use Wi-Fi now, you can pull down the status bar and turn it on directly through the Wi-Fi


switch in the status bar.

About ApplePie's Setting Options




- **Navigation app setup:** Allows you to specify an APP to join our navigation software whitelist, and the system handles the sound type of this APP in accordance with the navigation software.
- **Voice assist:** Allows you to specify an APP to use the original car's voice button (long press for 3 seconds) or the voice button on the floating ball to wake up.
- **Use the OEM GPS data:** If this option is checked, the GPS data output from the OEM navigation hardware can be used. If the test is OK, the GPS antenna can not be plugged in. The vehicle does not have navigation hardware, or has navigation hardware, but does not implement GPS data transmission function specified in CarPlay standard protocol, then you can't check this option, you can only connect the GPS antenna to obtain GPS data.
- **Copy log file to SD Card:** Copy the log of startup and system operation to TF card, mainly for R&D and debugging. Simple insert TF card and it will make Log automatically.

About Floating Ball









The functions of the row of buttons after clicking on the floating ball to expand are: Home, Return, Recently, Voice, Return to the original car UI, Clear memory and one button split screen display



Restore APPS


ApplePie pre-install many applications. If you updated new version of the APPS, and found it not works properly, You can install the pre-install APP again by Install Manager in ApkInstaller.



| | | | |
|---|----------|-------------------|---------|
| < | | | |
|  | KKBOX | Already installed | install |
|  | Gboard | Already installed | install |
|  | YouTube | Already installed | install |
|  | Spotify | Already installed | install |
|  | u-center | Already installed | install |

Resolution Choosing


The ApplePie Mini resolution support the highest 1920*1080 and lowest 800*480 , Please Drag the green bar below photo to choose the right resolution according to the OEM headunit. Which will ensure the video play smoothly.



Firmware Update

1. Download the firmware and copy file update.zip to empty TF card directly without unzip.
2. Insert it to TF Card slot, turn on the unit it will copy the file to the smart box.
3. After it finishing copy , it takes 6mins to update. wait till it reboot and take out TF card.

Documents / Resources

| | |
|---|--|
|  | ShenZhen Exploter Electronics AI-996 ApplePie Mini CarPlay AI Box [pdf] Instruction Manual AI-996, ApplePie Mini CarPlay AI Box |
|---|--|