



Shenzhen Jos Technology JOSLG9DS Personal Transmitter Code Instructions

[Home](#) » [Shenzhen Jos Technology](#) » Shenzhen Jos Technology JOSLG9DS Personal Transmitter Code Instructions 

Contents

- [1 Shenzhen Jos Technology JOSLG9DS Personal Transmitter Code](#)
- [2 Setting Your Personal Transmitter Code](#)
- [3 FCC Statement](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

SHENZHEN


Shenzhen Jos Technology JOSLG9DS Personal Transmitter Code



Setting Your Personal Transmitter Code


1. Remove the Transmitter Cover

- On the back of the transmitter use a small phillips head serew driver to remove the two screws on the sides of the visor clip and separate the front cover from the transmitter. With the front cover removed, the battery and the DIP switches will be exposed. To set a new code, use a small screwdriver to move the switches.




2. Set the transmitter DIP Switches

- There are nine (9) transmitter DIP switches; each can be placed in three different positions (+, 0,-). DO NOT set all the switches in the same position, such as all + all 0, or all – Once the DIP switches have been set to a personal code, replace front cover. **WARNING:** No other adjustments should be made inside the transmitter.



3. “Teach” the New Code to Control Board Memory

- A. Press LEARN REMOTE BUTTON for 1 second on the Control board then release.
- B. Press transmitter button, the status led flashes once.
- C. The new code is stored in control board memory.



4. Delete transmitter code from control board memory

- Press and hold LEARN REMOTE BUTTON on control board until STATUS led goes off (about 3 seconds), the code is deleted.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement


This device complies with RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Documents / Resources

Setting Your Personal Transmitter Code


1. Remove the Transmitter Cover

Remove the transmitter cover by pulling it off the back of the transmitter. The cover is attached to the back of the transmitter by a small tab. The cover is shown in the diagram below.




2. Set the transmitter DIP Switches

Set the transmitter DIP switches to the correct position. The transmitter has four DIP switches. The switches are labeled 1, 2, 3, and 4. The switches are shown in the diagram below.




3. "Load" the New Code to Control Board Memory

Load the new code to the control board memory. The transmitter has a control board with a memory slot. The code is loaded into the memory slot. The code is shown in the diagram below.



4. Delete transmitter code from control board memory

Delete the transmitter code from the control board memory. The transmitter has a control board with a memory slot. The code is deleted from the memory slot. The code is shown in the diagram below.



[Shenzhen Jos Technology JOSLG9DS Personal Transmitter Code](#) [pdf] Instructions
JOSLG9DS, 2A5Z8-JOSLG9DS, 2A5Z8JOSLG9DS, JOSLG9DS Personal Transmitter Code, P
ersonal Transmitter Code