

# **Shenzhen Kexuntong Technology S1 General Programmable Sensor Instructions**


Home » Shenzhen Kexuntong Technology » Shenzhen Kexuntong Technology S1 General Programmable Sensor Instructions ™

#### **Contents**

- 1 Shenzhen Kexuntong Technology S1 General Programmable Sensor
- 2 General programmable sensor instructions
- 3 Installation precautions
- **4 FCC Statement**
- **5 Documents / Resources**
- **6 Related Posts**

## Shenzhen

**Shenzhen Kexuntong Technology S1 General Programmable Sensor** 



General programmable sensor instructions

#### Model: S1 FCC ID: 2AYYJ-S1


Before installing the sensor, be sure to read the installation instructions carefully and operate according to the requirements:


- 1. Do not use sensors with damaged appearance;
- 2. The installation process should be operated by trained professionals according to the guidance requirements;
- 3. The warranty period is 12 months or 20000 km, whichever comes first Screw




- Product Name: built in sensor
- · working voltage:3V
- Emission current:6.7MA
- Air pressure range:0-5.8Bar
- Air pressure accuracy:±0.1Bar
- Temperature accuracy:±3°C
- working temperature:-40°C-105°C
- working frequency:315MHZ
- Product weight:21.8g
- · Operation steps:
- 1. Before the sensor is installed, it should be programmed with ateq tool according to the model year;
- 2. Install it on the wheel hub according to the following figure

Select the direction suitable for the angle and screw on the air nozzle nut Keep the white surface of the sensor parallel to the wheel hub surface, and tighten the air nozzle nut with 8nm torque Tire power balance







### Installation precautions

- 1. The valve should not extend out of the rim
- 2. The sensor shell shall not interfere with the wheel rim
- 3. The white surface of the sensor shall be parallel to the rim surface
- 4. The sensor housing must not extend beyond the rim flange

#### **FCC Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two cond itions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital de vice, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee th at interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

#### **Documents / Resources**



Shenzhen Kexuntong Technology S1 General Programmable Sensor [pdf] Instructions S1, 2AYYJ-S1, 2AYYJS1, S1 General Programmable Sensor, S1, General Programmable Sensor

