Manuals+ — User Manuals Simplified.

Shenzhen Snd Electronics YZC-01 5 In 1 Wireless Controller Instruction Manual

Contents

SHENZHEN

Shenzhen Snd Electronics YZC-01 5 In 1 Wireless Controller

BUTTON INSTRUCTION

HOME — Screenshot
L1 — R1
Select — START
Left Stick — A/B/X/Y Buttons
D-Pad — Right Stick
LED Indicators
TURBO
Type-C Port
R2 — L2
Reset button

Reset button function: When the controller is out of order, which can be reset by poking the reset key at the back of it

How to connect

1. **Connect to the Switch console via Bluetooth**
   - **A.Connect the controller to the console for the first time:** Turn on Switch console, click"Controllers Change Grip/Order on" the HOME Menu, Enter the console pairing mode.ignore " Press L+ R on the controller"on display screen:;just Press'HOME"button for 5 seconds to turn on the controller and enter pairing mode, 4LEDs of the controller starts to flash cyclically and quickly, When one or more LEDs solid on, the controller is successfully paired with the console, then press "A" button to return and start to operate the controller.
   - **B.Connect the controller to the console again:** In controller sleeping mode,Press and hold the "HOME" button for 3 seconds to wake up the controller, the controller will automatically connect to the console, and then press the A button to operate.
2. **Connect Android devices via Bluetooth:** When the controller is off, press and hold the "Y + HOME" buttons together for 2 seconds to turn on, and the connected indicator LED1 flashes. At the same time, open the Bluetooth of an Android device, and click "Bluetooth" to search for the Bluetooth device. In the "Available Devices" list, find and click "Gamepad (6325' to pair. After the pairing successful, LED1 solid on. the controller enter Android mode.

3. **Connect to the P3 console via Type C cable:** When the controller is off, press and hold the "L1" button, and connect Type C cable to P3 console, and press "Home"button to pair,after the pairing successful, the corresponding LED solid on and the controller enters the P3 mode.
4. **Connect PC device via Type C cable:** When the controller is off, connect the controller to the PC device with Type-C cable, after it is successfully connected, the LED2 light solid on (X-Input mode will be the default mode on the PC side; you may switch from X-Input mode to D-Hnput mode by pressing and holding the "O"(screenshot) button for 2 seconds. LED3 will solid on once you switch to D-Input mode.

OPERATIONAL MODE

Working Mode	SWITCH Mode	Android Mode	P3 Mode	PC Mode
Mode pair	Press and hold "Home" button for 5 seconds	Press and hold "Y+Home" button for 2 seconds	Type-C cable conntection	
Indicators	LED1-4 (one of four LEDs)	LED1	LED1-4 (one of four LEDs)	LED2 or LED3
Remark	Bluetooth connect	Bluetooth connect	Type-C cable conntection	

Turbo function

Turbo function setting

- First press and hold the function button you want to accelerate, for example Press "A" button, Then press the TURBO button, A will have a Continuous shooting function;
- **Cancel turbo function:**
  First press and hold the function button that has been set to accelerate, for example, A button, then press the TURBO button again, a continuous shooting function will be canceled.

Controller charge/sleep/wake up function

- Charging when the controller off, (Press HOME to tum on/of), LED1-LED4 indicators flash slowly. LED lights off after fully charged. When charging in the connection state, the LED4 indicator light flashes slowly, LED lights off after fully charged!
- Sleep/Wake-up: The controller goes to sleep mode when not in use for 5 minutes. When you need to use it again, you need to press the HOME button for 3 seconds to wake up and you can connect back when the battery is low, the corresponding indicator flashes quickly to remind you.

Specifications

- Working voltage: Dc3.7V-4.2V
- working current: 20-30mA
- Using time: 8-10H
- Sleep current: <80uA
- Charging voltage current: DC5V/1A

- Using distance: s8M
- Battery capacity: 600mAh
- Standby time: about 3 months after fully charged

How to upgrade the controller

This wireless controller is compatible with the latest version of the Switch When N-Switch updates the system in the future,if you cannot connect the controller to the console, you may need to upgrade the controller! Connect the controller to the computer via USB cable and upgrade the controller with an upgrading program. We will also provide an upgrading program.

Precautions:

- Please do not store this product in a humid or hot place
- Please do not strike, beat, hit, pierce, or attempt to disassemble the product to avoid unnecessary damage
- Built-in battery, do not throw away with the garbage.
- Please do not charge the controller near fire or other heat sources places.
- Non-professionals should not disassemble this product, otherwise it will not be included in the after-sales warranty service.

FCC RULES

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference,
- this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- onsult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction

Documents / Resources

Shenzhen Snd Electronics YZC-01 5 In 1 Wireless Controller [pdf] Instruction Manual
YZC-01, YZC01, 2A5W7YZC-01, 2A5W7YZC01, YZC-01 5 In 1 Wireless Controller, YZC-01, 5 In 1 Wireless Controller