

**SierraTeck**  
**B09SQBMFNG**  
**Talking PIR**  
**Motion Sensor**



# SierraTeck B09SQBMFNG Talking PIR Motion Sensor User Guide

[Home](#) » [SierraTeck](#) » SierraTeck B09SQBMFNG Talking PIR Motion Sensor User Guide 

## Contents

- [1 SierraTeck B09SQBMFNG Talking PIR Motion Sensor](#)
- [2 Specifications](#)
- [3 STEP 1: Insert batteries \(not included\)](#)
- [4 STEP 2: Turn on](#)
- [5 STEP 3: Record Audio](#)
- [6 STEP 4: Attach to Wall](#)
- [7 FAQs](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

**SierraTeck**

**SierraTeck B09SQBMFNG Talking PIR Motion Sensor**



## Specifications

- Power Source: 3x AAA 1.5V alkaline batteries (not included)
- Recording Duration: Up to 2 minutes
- Power/Volume Settings: High Volume, Low Volume, Power off

This guide will help you hit the ground running in no time!



Name	Function
<b>Indicator Light</b>	When motion is detected, light turns on and stays on for duration of playback. Light will also turn on when recording audio
<b>Button A (Recording button)</b>	Press and hold for 3 seconds until you hear a beep, then start recording while keeping button pressed. Release to stop recording
<b>Button B (Playback Button)</b>	Press once to start playback, press again to stop playback
<b>Power/Volume Switch</b>	<b>High Volume:</b> Set to top position <b>Low Volume:</b> Set to middle position <b>Power off:</b> Set to lowest position

#### STEP 1: Insert batteries (not included)

- Remove the battery cover and insert 3x AAA 1.5V alkaline batteries, noting the correct polarity.
- Use new alkaline batteries only. Used and/or other battery types may cause the unit to not function properly.

#### STEP 2: Turn on

- Turn on the device by sliding the power/volume switch to the middle or upper setting (low or high volume)
- When the device is turned on, it may take a few seconds for the sensor to warm up and start responding.
- During this time, it is normal for the device not to detect motion and/or double trigger.

### **STEP 3: Record Audio**

- Press button “A” and hold for 3 seconds until you hear a beep. Start recording after the beep and keep the button pressed. Release the button to stop recording.
- If you hear another beep while recording, it means time is up. Up to 2 minutes of audio can be recorded. Button “A” must be kept pressed while recording, releasing the button will stop the recording.
- To hear back recorded audio, press button “B”. To stop playback, press button “B” again.
- If you hear a crackling sound, which indicates that your batteries are low, please replace them with new batteries.
- We test all units after manufacturing by pre-recording a human voice, this is normal and does not indicate unit is used.

### **STEP 4: Attach to Wall**

- Using the 2 screws provided, attach the unit to the wall directly or use the ball mount parts supplied.
- Regardless of the method chosen, only the bottom 2 screw holes at the back of the unit are used, upper one is unused.

### **TIPS**

- For indoor use. External use may result in moisture damaging the internals of the device and voiding the warranty.
- The top right corner of the device may have an opening that resembles a microSD card slot. This opening is for a different variation of this product and has no function or use on this unit.
- If there is any way we can assist you if you’ve encountered any issues whatsoever, please email us, we are here to help and make sure you are 100% satisfied.

### **FAQs**

#### **Q: Can I use rechargeable batteries with this device?**

A: It is recommended to use new alkaline batteries only. Rechargeable or other battery types may cause functionality issues.

#### **Q: How long does the indicator light stay on when motion is detected?**

A: The indicator light turns on and stays on for the duration of playback when motion is detected.

### **Documents / Resources**



**[SierraTeck B09SQBMFNG Talking PIR Motion Sensor](#) [pdf] User Guide**  
B09SQBMFNG Talking PIR Motion Sensor, B09SQBMFNG, Talking PIR Motion Sensor, PIR Motion Sensor, Motion Sensor, Sensor

**References**

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.