Sixfab B92 5G Modem Kit for Raspberry Pi Instruction Manual

Contents

Sixfab B92 5G Modem Kit for Raspberry Pi



BOX CONTENTS

Sixfab 5G Modem Kit



5V 3A Sixfab USB-C Power Adapter with Universal Plugs

Extra tall 40-pin GPIO Stacking Header

USB 3.0 Bridge Connector

Plastic Spacer Kit

Purchased separately

Raspberry Pi 5, power adapter and Nano SIM card with 5G support.

ASSEMBLY





1. Attach the 40-pin header to the HAT.
2. Stack with Raspberry Pi 5 as shown using a spacer kit.





3. Connect USB 3.0 Bridge Connector.
4. Plug in the Nano SIM card (4FF) with 5G support.



5. Power the kit plugging in the adapters (Pi and HAT).

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile devices
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning for Mobile devices
This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

	Sixfab B92 5G Modem Kit for Raspberry Pi [pdf] Instruction Manual B92 5G Modem Kit for Raspberry Pi, B92, 5G Modem Kit for Raspberry Pi, Modem Kit for Raspberry Pi, Kit for Raspberry Pi, Raspberry Pi, Pi

References

- User Manual