


SKYLOONG SK64S USB Bluetooth 2 Mode Keyboard Instructions

Home » SKYLOONG » SKYLOONG SK64S USB Bluetooth 2 Mode Keyboard Instructions



USB+Bluetooth 2 mode Keyboard Item: SK64S



* **NOTE: Press** Fn with the function keys.

one of the blues LEDs is flashing, The keyboard is connecting the BT equipment.

Bluetooth ON/OFF switch, Link to USB mode.

FN function description (Double-click FN to light FN's white LED, FN function is held, click F

FN function description (Double-click FN to light FN's white LED, FN function is held, click FN again to escape from holding status).

Midea key (Standard mode settings)

Key	Function	Key	Function
FN +A	►II Play/Pause	FN + F	Mute
FN + S	H◀Previous	FN + G	◄- Volume-
FN + D	▶►Next	FN + H	◀+ Volume+

Contents [hide

- 1 BT&System settings(BT model only, can not modify)
- 2 FN + function(Standard mode settings)
- 3 Backlight settings(Can not modify)
- 4 Define mode
- 5 Dongguan Jizhi Electronic Technology Co., Ltd
- 6 Documents / Resources
- **7 Related Posts**

BT&System settings(BT model only, can not modify)

Key	Function	
FN + Space	*	Bluetooth ON/OFF switch
		Link to USB mode or the last BT equipment.
FN + Z	∦ 1	Long press: The red&green LED of 2 keycaps will flash. The *1 Bluetooth equipm ent can be paired.
		Press: The keyboard will con the \$1 BT equipment or disconnect.
FN + X	\$ 2	Long press: The red&green LED of X keycap will flash, Tbe*2bluetooth equipmen t can be paired.
		Press: The keyboard will connect the*2 BT equipment or disconnect
FN + C	* 3	Long press: The red&green LED of the C keycap will flash, The \$3bluetoolh equipment can be paired.
		Press: The keyboard will con the\$3 BT equipment or disconnect

Note: If the Bluetooth pairing is dined out or failed, please re-pair. If the Bluetooth pairing is successful on the equipment, but the keyboard can not work still, please delete the keyboard in the Bluetooth list of the equipment and pair again.

FN + Tabe	GK 8T model series-long press for 3 seconds to one off the keyboard
(6)	SK BT model series long-press thee' key in the label under the keyboard for 3 seconds to on/off the keyboard
FN + Win	Lock/Unlock Win key
FN + L – Alt	Low vo itage&chargIng status Indicator ON/OFF Logo LED&back side LED
FN + L – Ctrl	Keyboard's sleep time setting, white LED onO: never sleep, 1:5minutes, 2:10minutes9:45mlnutes to sleep.

FN + function(Standard mode settings)

Function	Key	Function
F1	FN + 7	F7
F2	FN + 8	F8
F3	FN + 9	F9
F4	FN + 0	F10
F5	FN + -	F11
F6	FN + +	F12
PS	FN +J	Ins
SL	FN + K	НМ
РВ	FN + L	PU
End	FN + M	Del
PD	FN + Esc	•
~		•
	F1 F2 F3 F4 F5 F6 PS SL PB End PD	F1 FN + 7 F2 FN + 8 F3 FN + 9 F4 FN + 0 F5 FN + - F6 FN + + PS FN + J SL FN + K PB FN + L End FN + M PD FN + Esc

Backlight settings(Can not modify)

Key	Function
FN + backspace←	Backlight ON/OFF
FN + D	Backlight mode 1-5 (Can modify)
FN + [{	Backlight mode 6-9
FN + 1I	Light effect pause/play
FN + ↓	CI- Backlight brightness —
FN + ↑	Backlight brightness +
FN + ←	Backlight Effect Speed —
FN +→	Backlight Effect Speed +

Define mode

Key	Function
Standard mode	In standard mode, all buttons can not be user-defined. User can customize their own personali modes. On-board model 1/2/3 is strongly recommended,(Note: In the custom mode, except FN ey values, some of the FN + " x " function can be also modified, except the backlight, Bluetooth n can not be moved, but the user can define their own FN1/FN2/FN3 at any key on the keyboard.
FN + Q Driver mode	FN + Q is the driver mode layer, "Q" lights white LED, some special function (For exampl than 32 bytes to a key in the driver mode while it's unavailable in those onboard mode layer) at de. You must keep the driver running and the keyboard connected with the driver. Press FN + 0
FN + W Onboard model Layer' I FnI	1. FN + W, onboard mode layer 1, "W" lights white LED, no need to run and connect the drive m key functions and the user can modify the key functions and macro Settings by the driver an d and saved to the keyboard. The reference Setting: the multifunctional reuse Settings of the s space function, Space + other key combination to achieve the onboard mode layer3 call function e standard model.
FN +E Onboard m ode2 Layer2 / Fn2 MAC OS mode	2. FN + E, onboard mode layer 2, "E" lights white LED. The reference Setting: keyboard command "key will be in the original position, user can modify the Settings by the drive oard, no need to run and connect the driver when using Mac's function settings. Press I d model.
FN +R Onboard m ode3 Layer3 / Fn3	3. FN + R, onboard mode layer 3, "R" lights white LED. The reference Setting: Some special macro keys, these settings of this model can be called by the key FN3 in layerl&layer2, All Sett and saved to the keyboard. Press FN+R again, back to the standard model.

More function and LED backlight settings, please download or update the driver from the following website: http://www.jikedingzhi.com/downloadlist?driverlD=41

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Documents / Resources



SKYLOONG SK64S USB Bluetooth 2 Mode Keyboard [pdf] Instructions SK64S, 2AXE4-SK64S, 2AXE4SK64S, SK64S USB Bluetooth 2 Mode Keyboard, USB Bluetooth 2 Mode Keyboard, 2 Mode Keyboard, Keyboard

Manuals+, home privacy