



Sonoff BASIC/RF Wi-Fi Smart Switch User Guide

[Home](#) » [SonOFF](#) » Sonoff BASIC/RF Wi-Fi Smart Switch User Guide 

Contents


- [1 Sonoff BASIC/RF Wi-Fi Smart Switch](#)
- [2 Equipment Installation](#)
- [3 FCC compliance statement](#)
- [4 ISED Notice](#)
- [5 Important Safety Instructions](#)
- [6 SAR Warning](#)
- [7 EU Declaration of Conformity](#)
- [8 WEEE Disposal and Recycling](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)



Sonoff BASIC/RF Wi-Fi Smart Switch




Power off




- To avoid electric shocks, please consult the dealer or a qualified professional for help when installing and repairing! Please do not touch the switch during use.

Equipment Installation



Wiring instruction




- **Wiring:** 16-18AWG SOL/STR copper conductor only, Tightening torque: 3.5 lb-in.
- Make sure all wires are connected correctly.


Download the eWeLink App



POWER ON



- The device will exit the Pairing Mode if not paired within 3mins. If you want to enter this mode, please long press button for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.
- After powering on, the device will enter the Pairing Mode during the first use. The Wi-Fi LED indicator changes in a cycle of two short and one long flash and release



- Tap “+” and select “Add Device”, then operate following the prompt on the App.

USER MANUAL



- Scan the QR code or visit the website to learn about the detailed user manual and help.

FCC compliance statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. FCC Radiation

Exposure statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Notice

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
 2. This device must accept any interference, including interference that may cause undesired operation of the device. This Class B digital apparatus complies with Canadian ICES-003(B). This device complies with RSS-247 of Industry Canada. Operation is subject to the condition that this device does not cause harmful interference.
- ISED Radiation Exposure Statement This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.
 - This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

Important Safety Instructions

1. **CAUTION:** Risk of electric shock, This product is not a toy and not intended for use by children. For adult use only.
 2. The maximum ambient temperature during use of the appliance must not exceed 40°C.
 3. The appliance is suitable for moderate climates only.
 4. The ventilation must not be impaired by covering the appliance with items such as newspapers, table cloths, curtains, etc.
 5. Naked flame sources, such as candles, must not be placed on the appliance.
- To ensure the safety of your electrical installation, it's essential either a Miniature Circuit Breaker (MCB) or a Residual Current Operated Circuit Breaker (RCBO) with an electrical rating of 10A has been installed before the BASICR2, RFR2.

SAR Warning

- Under normal use of condition, this equipment should be kept a separation distance of at least 20 cm between the antenna and the body of the user.

EU Declaration of Conformity


- Hereby, Shenzhen Sonoff Technologies Co., Ltd. declares that the radio equipment type BASICR2/RFR2 is in compliance with Directive 2014/53/EU. The full text of the EU declaration – of conformity is available at the following internet address: <https://sonoff.tech/compliance/>

For CE Frequency

- **EU Operating Frequency Range Wi-Fi:** 802.11 b/g/n20 2412-2472 MHz 802.11 n40: 2422-2462 MHz SRD: 433.92MHz (RFR2, Receive Only) EU Output Power

WEEE Disposal and Recycling



-  Information All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012 /19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

Shenzhen Sonoff Technologies Co., Ltd. 3F & 6F, Bldg A, No. 663, Bulong Rd, Shenzhen, Guangdong, China

- **ZIP code:** 518000
- **Website:** sonoff.tech Service
- **email:** support@itead.cc MADE IN CHINA

Documents / Resources



[Sonoff BASIC/RF Wi-Fi Smart Switch](#) [pdf] User Guide
BASIC RF Wi-Fi Smart Switch, BASIC RF, Wi-Fi Smart Switch, Smart Switch, Switch

References

- [User Manual](#)

Manuals+.