


SONOFF iFan03 Wi-Fi Ceiling Fan and Light Controller Installation Guide

Home » SonOFF » SONOFF iFan03 Wi-Fi Ceiling Fan and Light Controller Installation Guide ™






Wi-Fi Fan & Light Controller Model: iFan03

Contents


- 1 Poweroff
- 2 Wiring instruction
- 3 Download APP
- 4 Power on
- 5 Add the device
- **6 User Manual**
- 7 FCC Warning
- 8 Documents /
- Resources
- 9 Related Posts

Poweroff



To avoid electric shocks, please consult the dealer or a qualified professional for help when installing and repairing

Wiring instruction




Please install protection devices before connecting the live wire (e.g. fuses or air switches)

Make sure the neutral wire and live wire connection is correct


Download APP



http://app.coolkit.cc/dl.html



Power on



After powering on, the device will enter the quick pairing mode (Touch) during the first use, then the fan makes two short beeps and one long beep.

LIKE IT!

Glad to know you are satisfied with SONOFF products.

It would mean a lot to us if you can take a minute to share your buying experience.



Get the latest news by following us:

New arrival Promotion How-to videos HAVE A PROBLEM?

We are so sorry for the inconvenience caused by the product. Please contact us for help via the email address below.




support@itead.cc

We will get back to you as soon as possible.




If not paired within 3mins, the device will exit the quick pairing mode (Touch). If you need to enter again, long-press the "configuration button" on the controller or "Wi-Fi pairing button" on the RM433 remote controller and hold 5s until the fan makes two short and one long "bi" sound and release.

Add the device



Tap"+an select ·quick Pairing, then operate following the prompt on the APP. Pairing method for the device and SONOFF RM433 remote controller:



Please press any button within 5s after powering on again until the ceiling fan makes a sound "di, and pairing is successful.

User Manual

Scan the QR code or visit the website to learn about the detailed user manual and help.



FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Hereby, Shenzhen Sonoff Technologies Co., Ltd. declares that the radio equipment type iFan03 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address https://www.sonoff.tech/usermanuals

TX Frequency: WiFi: 2412-2472MHz

RX Frequency: WiFi: 2412-2472MHz SRD: 433.92MHz

Output Power: 14.35dBm(802.11b), 13.61dBm(802.11g), 13.37dBm(802.11n20)



Shenzhen SonoffTechnologies Co., Ltd.

1001, BLDG8, Lianhua Industrial Park, shenzhen, GD. China ZIP code: 518000

> Website: sonoff.tech MADE IN CHINA















Documents / Resources



SONOFF iFan03 Wi-Fi Ceiling Fan and Light Controller [pdf] Installation Guide iFan03, Wi-Fi Ceiling Fan and Light Controller