



Space Tech EPS03 Portable Wireless Speaker Instruction Manual

[Home](#) » [Space Tech](#) » Space Tech EPS03 Portable Wireless Speaker Instruction Manual 



Space Tech EPS03 Portable Wireless Speaker



Contents

- [1 OVERVIEW](#)
- [2 CHARGING](#)
- [3 FCC Statement](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

OVERVIEW



1. /7.Short press to increase or decrease the volume, long press to switch songs/switch stations
2. Mode It to toggle between USB/TF/Bluetooth/AUX
3. Short press for the mode change of sound Press and hold for TWS
4. Short press Play/Pause
5. Long press: Power on/off
6. Light Mode Transition
7. 3.5mm headphone jack
8. USB interface
9. TF card interface
10. 5V 2.5A Type_C charging port
11. Reset key
12. Microphone connector

CHARGING

Plug the charging cable into the speaker and connect to another USB power source such as a PC, MAC, USB power adapter, etc.



The symbol above and on the product means that the product is classed as equipment and should not be disposed with other household or commercial waste at the end of its useful life.

The Waste of Electrical and Electronic Equipment (WEEE) Directive has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment,

Contact local authorities for information on the correct disposal of Electrical or Electronic equipment.

FCC Statement



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Portable

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

 <p>1. Power button 2. Volume up button 3. Volume down button 4. Play/Pause button 5. Previous button 6. Next button 7. Microphone 8. Charging port 9. USB port 10. Headset jack</p>	<p>Space Tech EPS03 Portable Wireless Speaker [pdf] Instruction Manual</p> <p>EPS03 Portable Wireless Speaker, EPS03, Portable Wireless Speaker, Wireless Speaker, Speaker</p>
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.