



spy tools SP81492 Cob LED Motion Sensor Headlamp User Manual

[Home](#) » [spy tools](#) » spy tools SP81492 Cob LED Motion Sensor Headlamp User Manual 



USER MANUAL



SP81492
COB-LED MOTION SENSOR (ON/OFF)
HEADLAMP

RETAIN THESE INSTRUCTIONS AND ATTACH THE RECEIPT TO THE MANUAL FOR FUTURE REFERENCE

NOTE: Proof of purchase must be retained by the customer as it will be required in the event of a claim under warranty.



AFTER-SALES SUPPORT: WWW.SPTOOLS.COM

AUSTRALIA: Visit the website's **contact page** to get in touch with your local service department.

INTERNATIONAL: Use the county selector to get in touch with your service department in your country or region.



IMPORTANT

ALL PERSONS WHO ARE TO USE THIS EQUIPMENT MUST THOROUGHLY READ AND UNDERSTAND THIS INSTRUCTION MANUAL PRIOR TO OPERATION.

Contents

- 1 INTRODUCTION**
- 2 Intended Use**
- 3 Scope of Delivery**
- 4 Safety Symbols**
- 5 ⚠️! WARNING**
- 6 Technical data**
- 7 Charging process**
- 8 Maintenance**
- 9 LIMITED WARRANTY**
- 10 Documents / Resources**
 - 10.1 References**
- 11 Related Posts**

INTRODUCTION

Thank you for buying this SP Tools product.

Please read the instructions completely with care and observe the advice given. The operating instructions are

part of the workshop flashlight and should be kept intact. The manufacturer is not liable for personal injuries and material damages which result from improper use.

Intended Use

Tools may in principle only be used for the purpose intended, under the conditions envisaged, and within the limitations as to their use.

- For domestic and commercial use
- Non-flammable environment
- Operating temperature -10°C to +40°C

Scope of Delivery

- 1 x LED Head Lamp Work Light
- 1 x Micro USB Cable (for charging).
- 1 x Owner's Manual
- 1 x Head Strap

Safety Symbols



RECYCLE — Recycle




— Use Indoors



— Do Not Throw in Garbage

mA — Milliamps

lm — Lumen



— Read Manual

V — Volts

A — Amps

⚠️⚠️ WARNING

Only plug the cable into an appropriate USB outlet for charging.

Before re-charging, read all instructions.

Do not operate in direct sunlight or extreme temperature conditions.

The use of an attachment, not recommended or sold by the charger manufacturer may result in a risk of fire, electric shock, or injury to persons.

While recharging, make sure the cord is located so that it will not be stepped on, tripped on, tripped over, or otherwise subjected to damage or stress.

Do not attempt to recharge with a damaged cord or plug, replace them immediately.

Do not wipe plastic parts with solvent. Solvents such as gasoline, thinner, benzene, carbon tetrachloride, alcohol, ammonia, and oil containing chloric annex may damage and crack plastic parts. Cleaning must be done when the charger is unplugged – Wipe plastic parts with a soft cloth lightly dampened with soapy water

Do not disassemble the charger or battery pack, take it to a qualified service center when a repair is required.

Incorrect reassembling may result in a risk of electric shock or fire.

Operating temperature, -10°C to +40°C

Completely charge the light before using it for the first time.

Do not look directly into the light.

Technical data

Operating Time	6hr — Low 2hr — High 2hr — Sensor
Light Source	High power LED — Main light
Luminous Power	100lm — Low 300lm — High 300lm — Sensor
Charging Time	4 hours
Battery	3.7v 1500 mAh
Battery Type	Lithium-ion
Input Voltage	Micro USB 5v/1000mA
USB Charging Cable	100cm
Splash Water Protection	IP65
Impact Resistance Level	IK07
Operating Temperature	-10°C – +40°C

Operation


The work light has 3 modes of operation. High, low, and sensor modes.

Push the on/off switch once to illuminate the light on low

Push the on/off switch twice to illuminate the light on high

Push the on/off switch three times to switch the light off

Push the sensor button and simply wave your hand in front of the light to turn it off and on



Light Pivot

The light can pivot down 45° for close inspection of parts



Charging process

The micro USB charging socket is located on the bottom below the rubberized protective cover. Plug the micro USB cable into the light and the USB end into an appropriate USB port (e.g. Computer / Phone Charger). The charging process is symbolized by a single red LED on the front of the light. When fully charged the red light will go green.



Maintenance

After longer periods of use, the battery must be fully charged.
Incorrect or defective replacement parts can lead to damage.

Warning

The lamp must not be switched on whilst being charged.

Disposal & Recycling Information

When the tool reaches its end of life, take it to a collection point designated by local Authorities for E-wast.
The separate collection and recycling of your product at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects humans, health, and the environment.

LIMITED WARRANTY

This Limited Warranty applies only to new products* distributed by SP Tools Pty Ltd ("SP Tools"). It is a condition of this Limited Warranty Policy that the purchaser read the owner's manual for the product and only use the product to the extent or for the purposes stated therein. The purchaser must also ensure that all servicing requirements are completed as listed in the owner's manual (said servicing is at the owner's expense). We recommend that all servicing is completed by an authorized service agent and that records of said servicing are retained by the purchaser as proof in the event of a warranty claim.

Whilst the owner's manual, packaging, and/or other documentation supplied with SP Tools' products may provide details in respect of a Limited Warranty, the terms set out herein supersede these matters, and this Limited Warranty applies in their place. This warranty is no less advantageous than otherwise described in such other documentation.

SP Tools agrees, subject to the terms and conditions specified below, to repair or replace at SP Tools' cost, the product purchased by you when the product does not perform in accordance with its specifications during the limited warranty period, due to any fault in manufacturing, materials and/or workmanship. SP Tools is not liable to repair or replace products that the purchaser uses in a manner that is inconsistent with the owner's manual or in

the circumstances set out in paragraphs 1.1 – 1.7 below. The benefits to the purchaser under this warranty are in addition to other rights and remedies under the Competition and Consumer Act 2010 (Cth). The limited warranty period, within which a defect in the product must appear, commences from the date of purchase and ceases on the expiration of the specified term below.

THE LIMITED WARRANTY PERIOD

- SP Speciality Tools – 12 Months



THE PURCHASER'S ATTENTION IS DRAWN TO THE FOLLOWING

To the extent permitted by law and subject to this Limited Warranty, and as part of the terms of the sale of the equipment or part thereof: SP Tools shall not be liable for any form of loss, damage, cost, injury, or harm of any kind (whether direct, indirect, special or consequential) howsoever arising from the use or supply of the equipment to the purchaser.

EXCLUSIONS TO LIMITED WARRANTY POLICY

This Limited Warranty will not apply where the equipment or any part thereof:

- 1.1 Fails due to an accident (including liquid spillage), abuse, misuse, neglect, or normal wear and tear;
- 1.2 Has been used in a manner other than for which it was originally designed;
- 1.3 Has been tampered with or is otherwise than as supplied by SP Tools;
- 1.4 Where any damage, malfunction, or another failure of the equipment or any part thereof resulted directly or indirectly from unauthorized persons, adjusting or failing to adjust any part requiring normal maintenance and service (examples include adjustment of tappets, air filter maintenance, lubrication, and tightening of screws nuts, and bolts);
- 1.5 Malfunctions due to the use of defective or incompatible accessories;
- 1.6 Is damaged by lightning or thunderstorm activity; or
- 1.7 Has been transported to a country where no authorized Service Agents exist.

CLAIMING WARRANTY

This Limited Warranty may be claimed in the following manner:

2.1 In order to make a claim under this Limited Warranty, the purchaser must deliver the equipment or any part thereof to an SP Tools authorized repair agent and pay all costs of transportation and all costs incidental to making a claim under this Limited Warranty. The purchaser must first contact SP Tools (contact details described above) and request the delivery address of an SP Tools authorized repair agent.

2.2 The purchaser must deliver to the repair agent written reasons why the purchaser considers that the purchaser has a claim under this Limited Warranty and must provide all necessary details, including:

- The place, date, and from whom the unit or part was purchased.
- The unit or part involved Model and Serial Number.
- The defect, malfunction, or failure in respect of which the claim is being made.
- Proof of service of the unit or part (if applicable)
- Proof of purchase in respect of the unit or part.

2.3 If the Limited Warranty claim is valid, the repair agent will carry out repairs and return the product at no charge to the purchaser. These repairs are limited to the Limited Warranty fault identified and as such will not include any


other faults due to misuse, abuse, failure to maintain, fair wear and tear, or the replacement of serviceable items such as oil, spark plugs, air filters, fuel, etc.

Our goods come with guarantees that cannot be excluded under Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Note: Units which are failing to perform in accordance with specifications due to non-warrantable causes will be subject to freight, repair, and or quote charge.



Documents / Resources

	<p>spy tools SP81492 Cob LED Motion Sensor Headlamp [pdf] User Manual</p> <p>SP81492 Cob LED Motion Sensor Headlamp, SP81492, Cob LED Motion Sensor Headlamp, Motion Sensor Headlamp, Sensor Headlamp, Headlamp</p>
---	---

References

-  [SP Tools USA](#)