



SGM DL-112T Remote Control Instructions

[Home](#) » [SGM](#) » SGM DL-112T Remote Control Instructions 

Contents

- [1 SGM DL-112T Remote Control](#)
- [2 OVERVIEW](#)
- [3 FCC Statement](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



SGM DL-112T Remote Control





OVERVIEW




1. " **LOW**, **MED**, **HI**" buttons:

These three buttons are used to set the fan speed as follows:

1. **LOW** or  = Low speed

2.  or  = Medium speed

3.  or  = High speed

2.  button: This button turns the fan off.



3. button : This button will make forward or reverse the fan.

4. The  button turns the light ON or OFF . Press and release the button to turn the light ON or OFF

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

1. This device may not cause harmful interference,
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.


IC Caution

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the

device.

Documents / Resources

	<p>SQM DL-112T Remote Control [pdf] Instructions</p> <p>DL-4112T-01, DL4112T01, 2A767-DL-4112T-01, 2A767DL4112T01, DL-112T, Remote Control, DL-112T Remote Control</p>
---	--