




SQT SK-680AG RF2.4GHz Auto Link Keyboard Instruction Manual

[Home](#) » [SQT](#) » SQT SK-680AG RF2.4GHz Auto Link Keyboard Instruction Manual 



**RF2.4GHz Auto Link Keyboard
Instruction Manual**



Model:SK-680AG

CAUTION: To use this device properly, please read the user's guide before installation.

Contents

- [1 Installing the Batteries](#)
- [2 Connecting the Receiver](#)
- [3 Multimedia Hotkeys functions:](#)
- [4 FCC Warning Statement](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Installing the Batteries


The RF2.4GHz Optical keyboard use two AAA alkaline battery.

Install the batteries in the keyboard

Step 1: Remove the battery compartment cover on the bottom of the keyboard by squeezing the cover in from the tab to release it


Step 2: Insert the batteries as shown inside the battery compartment

Step 3: Replace the cover



Connecting the Receiver

The receiver is insert to USB port immediate, or by a extra USB cable.



Connect the USB plug to USB port of your computer

Multimedia Hotkeys functions:

FN+ESC=F1toF12 key switch is the default the Multimedia or default of F1toF12 keyswitch

F1:Previous Track

F2:Play/Pause

F3:Next Track

F4:Mute
F5:Volume Down
F6:Volume Up
F7:Web home
F8:Search
F9:Email
F10:My Favorite
F11: save
F12: computer settings



: Reduced display brightness



: Display brightness increase



: calculator

I received the keyboard does not work:

1. Plug the receiver again.
2. Please check the keyboard batteries for electric, watch battery compartments are negative right into the new battery.
3. Make the keyboard close to plug USB receiver within 30 centimeters, if I found the power indicator light flash, keyboard to match.

FCC Warning Statement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources



[SQT SK-680AG RF2.4GHz Auto Link Keyboard](#) [pdf] Instruction Manual

SK-680AG, SK680AG, WOX-SK-680AG, WOXSK680AG, SK-680AG RF2.4GHz Auto Link Keyboard, SK-680AG Auto Link Keyboard, SK-680AG, RF2.4GHz Auto Link Keyboard, Auto Link Keyboard, Keyboard