



230-SWTS-DEF Tango2 Vehicle Specific Turn- Signal Kit



SSV WORKS 230-SWTS-DEF Tango2 Vehicle Specific Turn-Signal Kit Owner's Manual

[Home](#) » [SSV WORKS](#) » SSV WORKS 230-SWTS-DEF Tango2 Vehicle Specific Turn-Signal Kit Owner's Manual 

Contents

- [1 SSV WORKS 230-SWTS-DEF Tango2 Vehicle Specific Turn-Signal Kit](#)
- [2 Product Usage Instructions](#)
- [3 FEATURES & BENEFITS](#)
- [4 SWITCH Works Tango2 Parts List](#)
- [5 SWITCH Works TANGO2 Can Am Defender Turn Signal Kit Wiring Diagram](#)
- [6 TOOLS NEEDED FOR INSTALLATION](#)
- [7 TURN SIGNAL ROCKER SWITCH FUNCTIONS](#)
- [8 LED BACK LIGHT COLOR CHANGE](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



SSV WORKS 230-SWTS-DEF Tango2 Vehicle Specific Turn-Signal Kit



Product Specifications:

- **Product Name:** Can-Am Defender Turn Signal Kit with Horn
- **Model Number:** 230-SWTS-DEF
- **Compatibility:** 2016-2024 Can-Am Defender
- **Manufacturer:** SSV WORKS
- **Warranty:** 1 year limited warranty against defects in material or workmanship

Product Usage Instructions

Features & Benefits:

- Left/Right Turn Signal with Automatic Canceling Feature
- Dedicated Horn Output
- License Plate Light Output
- Emergency Hazard Light Switch
- Direct plug into factory tail light connectors
- RGB Backlight Buttons
- Weather-Proof for Offroad Use
- Built-In Circuit Protection
- Programmable RGB Backlight Colors to Match the Dash Lights

Product Parts List:

- Tango2 Turn Signal Module
- Tango2 Turn Signal Rocker Switch
- Tango2 Turn Signal Main Harness

Tools Needed for Installation:

- Phillips Screw Driver
- Drill
- 3/4 Hole Saw

Installation Steps:

1. Mount the TANGO2 Turn Signal kit module under the dashboard or in the hood area.
2. Secure the module to a panel using screws or zip tie it to a harness.
3. Insert the TANGO2 turn signal rocker switch into a suitable mounting location.

WARRANTY INFORMATION:

ALL SWITCH Works Electronics are covered by a limited 1 year warranty against defects in material or workmanship. Contact SSV Works for further warranty information.

Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

FEATURES & BENEFITS

- Left/Right Turn Signal with Automatic Canceling Feature
- Dedicated Horn Output
- License Plate Light Output
- Emergency Hazard Light Switch
- Direct plug in to the factory tail light connectors
- RGB Backlight Buttons
- Weather-Proof for Offroad Use
- Built-In Circuit Protection Detects Any Short Circuits, Over Current, Under Current and Low Voltage
- Programmable RGB Backlight Colors to Match the Dash Lights



SWITCH Works Tango2 Parts List



Tango2 Turn Signal Module



Tango2 Turn Signal Rocker Switch



Tango2 Turn Signal Main Harness [B-H3271]



Defender Rear Turn Signal Harness [B-H3112]



Defender Tail light/Turn Signal Adapter Kit [B-H3115]



Front Turn Signal Extension Harness (x2) [B-S2959]



Tango2 Front Turn Signal LED Lamps (x2) [B-H2813]



Horn Assembly, 500hz [A-SW-HRN]




Zip Ties (x10)




Defender Dummy Plug

SWITCH Works TANGO2 Can Am Defender Turn Signal Kit Wiring Diagram




	Description	Part #
1	Tango2 Turn Signal Module	
2	Tango2 Turn Signal Rocker Switch	
3	Tango2 Turn Signal Main Harness	B-H3271
4	Power Connector to Busbar Pulse Connector	
5	Power Input Harness, 3 ft.	B-H3413
6	Front Turn Signal Extension Harness (x2)	B-H2959
7	LED Lamp (Front Right)	B-H2813
8	Tango2 Horn, 500 hz	B-SW-HRN-500
9	LED Lamp (Front Left)	B-H2813
10	Tango2 Defender Harness (to Rear)	B-H3112
11	Defender Tail Light Adapter "PASS INPUT"	B-H3115
12	Defender Tail Light/Turn Signal Adapter "PASS OUTPUT"	B-H3115
13	To License Plate Light	
14	Defender Tail Light/Turn Signal Adapter "DRIVER OUTPUT"	B-H3115



TOOLS NEEDED FOR INSTALLATION

- Phillips Screw Driver
- Drill
- 3/4" Hole Saw


1. The TANGO2 Turn Signal kit module can be mounted under the dashboard or in the hood area.
2. Locate a suitable mounting location for the TANGO2 Turn Signal module. Secure the module to a panel using screws or zip tie it to a harness.




3. Use a vacant rocker switch mounting slot and insert the TANGO2 turn signal rocker switch. Run the cable towards the TANGO2 brain module.



4. Plug in the controller cable, front turn signal extension cables (B-H2959) and rear turn signal harness (B-H3112) to the TANGO2 main harness (B-H3271).



5. Route the front left and right turn signal extension cables to the front of the vehicle. Make sure to route the correct cable connector end that will plug to the LED lamp. Run the Horn power wires to the desired horn location.
6. Run the TANGO2 rear turn signal harness (B-H3205) to the rear of the vehicle. Use zip ties to secure the cable away from any moving parts or exhaust pipes.



7. Drill a 3/4" hole in the front of the vehicle for the front turn signal LED lamp. Refer to the viewing angle diagram



on page 7 for proper turn signal LED lamp placement.

8. Insert the LED turn signal lamp into the hole and push in to lock in place. Repeat steps G and H for the other side.



9. Connect the front turn signal extension harness to the LED lamp.

10. Mount the supplied bracket to the horn. Run the horn cable towards the desired horn mounting location.



11. **Horn mounting recommendations:**


1. Mount away from moving parts;
2. Mount as high as possible;
3. Mount with the horn facing downward to protect from water damage.

Plug in the horn power wires. Either wire can connect to either terminal.

12.




Run the Defender Rear Turn Signal Harness (B-H3112) to the rear of the vehicle. Begin installation on the passenger side tail light. Unplug the passenger tail light connector. See wiring image below for the passenger-side connections.





1. Unplug the factory Defender tail light connector and plug it in to the Defender TS Adapter (B-H3122) "PASS INPUT".
2. Plug the Defender TS Adapter (B-H3122) "PASS INPUT" to the "PASS INPUT" connector of the B-H3112 harness.
3. Plug the B-H3112 harness "PASS OUTPUT" connector to the other Defender TS Adapter (B-H3122) "PASS OUTPUT".
4. Plug the Defender TS Adapter (B-H3122) "PASS OUTPUT" connector to the tail light.
13. Run the "LIC. PLATE" connector towards the license plate location. Use zip ties to secure the cable away from any moving parts or the exhaust pipe.
14. Run the "DRIVER OUTPUT" of the B-H3112 harness to the driver side tail light. Unplug the factory tail light connector and plug in the provided dummy plug to protect it from the elements.




15. Plug in the Defender TS Adapter (B-H3122) to the B-H3112 "DRIVER OUTPUT" connector and plug the other end to the tail light. Use zip ties to secure the harnesses.
16. Crimp the ring terminals to the Power Input Harness (B-H3413).




17. Plug the 3-pin connector of the Power Input Harness (B-H3413) to the Defender Turn Signal Main harness (B-H3271).
18. Run the BATT, ACC and GND wires of the Power Input Harness (B-H3413) to the factory busbar and screw in the ring terminals to the corresponding battery, accessory and ground studs.



Turn Signal 180 Degree Viewing Angle



TURN SIGNAL ROCKER SWITCH FUNCTIONS



- **1 Momentary Press** = Horn Button
- **2 Momentary Press** = Left turn signal with 8-flash auto turn off
Press and Hold (1 sec) = Left turn signal continuous flashing / Press again to turn off
- **3 Momentary Press** = Right turn signal with 8-flash auto turn off
Press and Hold (1 sec) = Right turn signal continuous flashing / Press again to turn off
- **2+3 Press and Hold** = Hazard lights (also works with ACC off)

LED BACK LIGHT COLOR CHANGE



With ACC off, press and hold either the left or right button for 4 seconds until the rocker switch backlight turns bright. Use the left and right buttons to select the color. Press the horn button to save the color.

SWITCH Works is a product by SSV Works. We are committed to your satisfaction and we know you will enjoy our products. If you have questions or need any assistance, please let us know.

- SSVWORKS.COM
- 1-818-991-1778 EXT 2
- SUPPORT@SSVWORKS.COM

SCAN THE QR CODE



Returns must be made within 30 days of the purchase date. Claims for missing items or items damaged in transit must be received within five business days of receipt of merchandise. All returns must be in original packaging and in re-sellable condition. Shipping fees are not refundable.

FAQ

Q: How do I program the RGB Backlight Colors?

A: The RGB Backlight Colors can be programmed to match the dash lights by following the instructions provided in the user manual. Typically, a combination of button presses on the RGB Backlight Buttons will allow you to cycle through and select different colors.

Q: Can the Turn Signal Kit be used in extreme weather conditions?

A: Yes, the Turn Signal Kit is weather-proof for off-road use, making it suitable for extreme weather conditions. However, it is recommended to follow proper installation procedures to ensure optimal performance.

Q: What is the warranty coverage for this product?

A: The product is covered by a limited 1-year warranty against defects in material or workmanship. For further warranty information, please contact SSV Works.

Documents / Resources

	<p>SSV WORKS 230-SWTS-DEF Tango2 Vehicle Specific Turn-Signal Kit [pdf] Owner's Manual 230-SWTS-DEF, 230-SWTS-DEF Tango2 Vehicle Specific Turn-Signal Kit, Tango2 Vehicle Specific Turn-Signal Kit, Vehicle Specific Turn-Signal Kit, Specific Turn-Signal Kit, Turn-Signal Kit, Kit</p>
---	--

References

- [SSV Works](#)
- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.