



# STRX LINE DSP4 Digital Audio Processor User Manual

[Home](#) » [STRX LINE](#) » STRX LINE DSP4 Digital Audio Processor User Manual 

## STRX LINE DSP4 Digital Audio Processor User Manual



## Contents


- 1 INTRODUCTION
- 2 DESCRIPTION
- 3 FUNCTIONAL DIAGRAM
- 4 DESCRIPTION OF ELEMENTS
- 5 BLUETOOTH INTERFACE
- 6 FUNCTIONS
- 7 PAIRING
- 8 TECHNICAL SPECIFICATIONS
- 9 TECHNICAL SPECIFICATIONS
- 10 DIMENSIONS (H x W x D)
- 11 WARRANTY TERM
- 12 Documents / Resources
  - 12.1 References
- 13 Related Posts

## INTRODUCTION

**Congratulations!** You have just purchased a product with the Expert Electronics quality. Developed by qualified engineers and in a high-tech laboratory.

To ensure optimal operation, please read this manual carefully before using the product. Keep the manual in a safe and accessible place for future reference.


## DESCRIPTION



- 2 digital inputs
- 4 independent outputs
- Input sensibility adjustment
- Bluetooth audio with wireless LINK
- Channel routing
- 11-band input equalizer
- Parametrical equalizer with 1 independent band per channel


- Crossover with Butterworth, Lackwits-Riley, and Expert type filters, with attenuations ranging from 6 to 48dB/8°
- Independent delay per channel
- Limiter with configurable Threshold, Attack and Release
- Peak limiter with Threshold adjustment
- Polarity inversion
- Input gain
- Independent mute per channel
- Frequency and scan generator
- User password
- 3 100% configurable memories
- Independent gain per channel
- Remote 300mA output
- Power supply tolerance from 9 to 15Vdc
- Bluetooth communication interface
- Language

## FUNCTIONAL DIAGRAM



## DESCRIPTION OF ELEMENTS


### HOW TO PERFORM THE WIRELESS LINK?




It is necessary to leave a DSP4 as Master and the other as Slave to establish a Bluetooth link. After that, press the LINK key on both devices to associate one with the other. That's it! Shortly, the Slave unit

receives the signal via Bluetooth from the Master, and the Master can receive the signal via RCA or Bluetooth.

1. LCD display for setup and monitoring
2. Rotary encoder responsible for selecting and changing parameters
3. Use these keys to select the channel to configured. If kept pressed, it mutes the selected channel
4. **Player Mode** – Bluetooth audio mode. Just connect the smartphone via Bluetooth  
**Master Mode** – It sends the signal via Bluetooth to another DSP4  
**Slave Mode** – It receives the signal via Bluetooth from another DSP4
5. Use ESC to return to parameter or previous menu



6. Processor output channels, connect to amplifiers
7. Input sensitivity adjustment (MIN 6Vrms/MAX 1Vrms)
8. Signal inputs shall be connected to the player or table output
9. Bluetooth audio antenna



10. The power supply connector shall be powered with 12Vdc. The REM needs to be connected to player's remote, and REM OUT is sent to amplifiers
11. Configuration Bluetooth antenna

## BLUETOOTH INTERFACE

- It is possible to set the Expert Electronics processors via Smartphone or Tablet using a didactic and intuitive interface. It makes the system alignment easier, which can be done in front of the system and in real time.
- The "Expert DSP STARX" app can be downloaded free from Google Play Store or Apple Store.



## FUNCTIONS

- Bluetooth audio
- Bluetooth link
- Channel routing
- Overall gain
- Output gain
- RMS limiter
- Peak limiter
- Delay
- Input equalizer
- Output equalizer
- Polarity inversion
- 100% configurable memories
- Protection password
- Signal generator

## PAIRING

## APP CONTROL | iOS AND ANDROID



1. Download the app at Google Play Store or Apple Store.
2. ☒ Enable Smartphone Bluetooth.
3. ☒ Enable Smartphone location.
  1. Open the Expert DSP STARX app and it will display the processor model to be connected.
  2. Select the processor and enter the factory password **0000**. To set a new password just enter a password other than **0000**.



### ATTENTION

If you want to reset your password, you need to reset the processor to factory settings.

TECHNICAL SPECIFICATIONS

INPUTS

Type	Balanced
Connection	RCA
Max. input level	6 a 1Vrms
Input impedance	100K

OUTPUTS

Type	Unbalanced
Connection	RCA
Max. output level	3.5Vrms
Output impedance	470R

TECHNICAL DATA

Resolution	24 Bits
Sampling frequency	48KHz
Processing latency	1,08ms
Frequency response	10Hz-22KHz (-1dB)
THD+N max	0,01%
Signal-to-noise ratio	100dB

POWER

Voltage	10~15Vdc
Consumption	300mA (5w
Fuse	1A

TECHNICAL SPECIFICATIONS

DIMENSIONS (H x W x D)






**Whatsapp:** +55 19 99838 2338

Expert Electronics reserves this right to change the product characteristics without prior notice.


#### **NOTE: PERMANENT SERVICE**

After the warranty expires, Expert electronics provides full technical service directly or via its network of Authorized Services, thus charging the corresponding component repair and replacement services .


 /Expert-Electronics    
accesses [www.expertelectronics.com.br](http://www.expertelectronics.com.br)



#### **Documents / Resources**

	<p><a href="#">STRX LINE DSP4 Digital Audio Processor</a> [pdf] User Manual DSP4, DSP4 Digital Audio Processor, DSP4, Digital Audio Processor, Audio Processor, Processor</p>
--	---

#### **References**

-  [One moment, please...](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.