

styletech  
Styletech MK520  
Mini Wireless  
Keyboard and Mouse



# Styletech MK520 Mini Wireless Keyboard and Mouse User Manual

[Home](#) » [Styletech](#) » Styletech MK520 Mini Wireless Keyboard and Mouse User Manual 

## Contents

- [1 Styletech MK520 Mini Wireless Keyboard and Mouse](#)
- [2 Product Usage Instructions](#)
- [3 Wireless Keyboard & Mouse Set-Up](#)
- [4 LEGAL INFORMATION](#)
- [5 WARRANTY](#)
- [6 IMPORTANT SAFEGUARDS & PRECAUTIONS](#)
- [7 BATTERY CARE](#)
- [8 FCC RADIATION EXPOSURE STATEMENT](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)

styletech

## Styletech MK520 Mini Wireless Keyboard and Mouse



## **Product Specifications:**

- Wireless Keyboard & Mouse Set
- DPI Settings: 800/1200/1600
- Class 1 Laser Product

## **Product Usage Instructions**

### **1. Battery Installation:**

Insert AAA batteries into the keyboard and mouse. The battery compartments are located on the base.

### **2. USB Dongle Connection:**

Insert the USB dongle stored in the mouse cavity next to the battery compartment into a spare USB port on your PC or laptop.

### **3. Power On:**

Switch the Power button ON on both the mouse and keyboard. They will connect instantly. Your PC/Laptop may prompt for a keyboard setup; follow the on-screen instructions. Adjust your preferred settings within the keyboard settings.

### **4. DPI Sensitivity Adjustment:**

To adjust the DPI sensitivity on your mouse, press the circular button until you reach your desired setting (800/1200/1600).

### **5. Power Off:**

Switch off the power for both the keyboard and mouse when not in use

### **6. Low Battery Alert:**

Both the keyboard and mouse will flash red when the batteries are running low.

## **FAQ:**

### **1. What do I do if my batteries are running low?**

If the batteries are low, both the keyboard and mouse will flash red. Replace the batteries with new ones to continue usage.

### **2. How can I claim warranty service?**

If you encounter any defects covered under warranty, contact the helpline or visit [styletech.net](http://styletech.net) with your proof of purchase for a replacement within the warranty period.

### **3. Are the batteries replaceable?**

Yes, ensure to follow the provided instructions for battery replacement to avoid any risk of leakage or explosion.

## **HAVING TROUBLE**

## **SETTING UP?**


## **WE CAN HELP!**

[help@abptech.co.uk](mailto:help@abptech.co.uk)

[Styletech.net](http://Styletech.net)

## **How can we help?**

Our support team will answer your questions



UK version for illustration purposes only.

- A: Mini Wireless Keyboard I
- B: Wireless Mouse+ USB Dongle I
- C: 3x AAA Batteries

## Wireless Keyboard & Mouse Set-Up

1. Insert the AAA batteries into the and mouse. The battery compartments for the keyboard and mouse are situated on the base
2. Insert the USB Dongle (stored in the mouse cover next to battery compartment) into a spare USB port on your PC or laptop
3. On the Mouse and Keyboard, switch the Power to ON. The keyboard and mouse will connect instantly and be ready for use  
Your PC/Laptop may ask for a keyboard set-up, just follow the on-screen instructions. You can adjust any of your favoured requirements/set-up within your  
**keyboard settings**
4. To Adjust the dpi sensitivity on your mouse, press the circular button until you reach your desired setting. There are three settings in total – 800/1200/1600 Switch off power to your keyboard and mouse when not in use.  
**Low battery:** Both the and mouse will flash red when batteries are running low.

## LEGAL INFORMATION

Please keep this manual for futi-re reference If you require any help or assistance, please contact the heWine or visit sMetech.net.

## WARRANTY

This product is guaranteed for a period of one year from the date of purchase. During this penod, if there is a

defect due to faulty materials or workmanship the retailer from whom you purchased it will repair it with wit the sarr.e or a similar model on production af your purchase receipt or proof of purchase. This guarantee does not cover defects arising from accidental damage, misuse, or wear and tear and is only to the original purchaser of the This does not affect Statutory rights.

## **BATTERY WARNING**

Improperly replaced batteries may present a risk of leakage, explosion, and personal injury. There is a risk of fire or explosion if the battery is replaced by an incorrect type. Ensure the batteries are installed correctly by following the instructions provided. Missing use of all types of batteries may present a risk of fire or chemical burn. Do not expose batteries to moisture, liquids, or extreme heat. A battery subjected to extremely low air pressure may result in the explosion or leaking of flammable liquid or gas.

Do not charge or use the battery if it appears to be leaking or is discolored and deformed. Do not leave your batteries unused for extended periods of time. Do not short-circuit. Your device may contain a built-in rechargeable battery that is not replaceable. Battery life varies with the device and other varying factors. All non-operating batteries must be discarded in the correct manner, according to your local laws If no laws or regulations govern, dispose of your device in a waste bin for electronics. Keep all batteries away from children.

## **CLASS 1 LASER PRODUCT. INVISIBLE LASER RADIATION**

This product contains a Class 1 LED. A Class 1 laser is safe under all conditions of normal use. This means the maximum permissible exposure (MPE) cannot be exceeded when viewing a laser with the naked eye or with the aid of typical magnifying optics.

**WARNING:** Use of controls, adjustments, or performance of procedures beyond those specified may result in hazardous radiation exposure. Avoid prolonged direct eye/skin contact with the laser may result in burn Injury

## **IMPORTANT SAFEGUARDS & PRECAUTIONS**

- Never expose to direct sunlight or wet weather conditions
- Do not expose the product to splashing, dripping, rain or moisture. Do not immerse in liquid
- Do not expose to dust, high humidity, high temperatures or mechanical shock
- Do not use if the equipment is damaged
- Do not disassemble; there are no serviceable parts inside
- For external cleaning, use a soft, clean, damp cloth only. use of detergents may damage the cabinet finish and leak inside
- Do not direct the infrared/laser beam from the mouse to anyone's eye or a reflective object that could injure you
- If the product is trying to operate at out-of-temperature ranges, power off until the temperature is stabalised  
Long periods of use may result in neck, arm, shoulder, wrist pain and stiffness. Take regular breaks and seek health  
advice from professionals for any discomfort

## **BATTERY CARE**

**For full battery care, please see battery warning section**

- If the battery has a charging function it should be under adult supervision
- Once fully charged disconnect the USB charging cable
- Do not attempt to charge any other battery pack or device using the USB charaing cable

- Do not leave on charge for longer than 6 hours
- We do not recommend leaving on charge overnight or while unattended
- Never dispose of batteries in fire, as this can cause them to explode
- Do not attempt to remove the product-built battery pack, it is not replaceable
- Power off device when not in use
- Do not leave unused batteries for extended periods

## **RECYCLING**

Where you see this symbol on any of our electrical batteries or packaging, it indicates that the relevant electrical product or should not be disposed of as general household waste in the 10K, EIJ or Turkey. To ensure the correct waste treatment of the product and please dispose of them in accordance with any applicable local laws or requirements for disposal of electrical equipment/batteries. In so doing, you will help to conserve natural resources and standards of environmental in treatment and disposal of electrical waste.

## **FEDERAL COMMUNICATION COMMISSION CLASS B INTERFERENCE STATEMENT**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna,
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC RADIATION EXPOSURE STATEMENT**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

## **CANADIAN ICES STATEMENTS CANADIAN DEPARTMENT OF COMMUNICATIONS RADIO INTERFERENCE REGULATIONS**


This digital apparatus does not exceed the Class B limits for radio-noise emissions from a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-003.


All other trademarks are the property of their respective owners. Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies Not recommended for children under 6 years of age. Please retain this packaging for future reference. Due to the company's policy of constant improvement and

technical refinement, the company reserve the right to alter the specification.

Styletechtu is a registered trademark of ABP Technology Ltd.



- **Manufactured By:** abp Technology LTD, Bolton, I-JK, BL2 IBX.
- **EU AR:** ABP Technology Europe Ltd. Dublin, ROI, K78 X5W6. MADE IN CHINA

 Marking of this symbol indicates this product has been tested and is compliant with the EMC Directive of the European Union 2014/30/EU.

 Marking of this symbol indicates this product conforms to Electromagnetic Compatibility Regulations 2016 issued by the I-JK.

Documents / Resources

	<a href="#">Styletech MK520 Mini Wireless Keyboard and Mouse</a> [pdf] User Manual MK520 Mini Wireless Keyboard and Mouse, MK520, Mini Wireless Keyboard and Mouse, Wireless Keyboard and Mouse, Keyboard and Mouse, and Mouse, Mouse
	<a href="#">styletech MK520 Mini Wireless Keyboard and Mouse</a> [pdf] User Manual STYMK520-02, 2BKH8-STYMK520-02, 2BKH8STYMK52002, MK520 Mini Wireless Keyboard and Mouse, MK520, Mini Wireless Keyboard and Mouse, Wireless Keyboard and Mouse, Keyboard and Mouse, Mouse, Keyboard

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.