



# styro Hansa LED lamp LED 4you Instruction Manual

[Home](#) » [styro](#) » styro Hansa LED lamp LED 4you Instruction Manual 

## Contents

- [1 styro Hansa LED lamp LED 4you](#)
- [2 Check to be sure](#)
- [3 For your safety](#)
- [4 Symbols](#)
- [5 Safety notes](#)
- [6 Assembly](#)
- [7 Care and cleaning](#)
- [8 Technical data](#)
- [9 Distribution](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)

# Hansa

styro Hansa LED lamp LED 4you



### **Check to be sure**

1. Check that the delivery is complete and that the light does not exhibit any transport damage.
2. If the delivery is incomplete or exhibits transport damages, do not use the light. Contact the vendor, where you purchase the light.

### **Proper use**

This light is only suitable for lighting dry in-door areas (home/office).

### **Before you use the light**

Before you use the device, please first carefully read through the safety notes and operating in-structions. Keep all safety notes and instructions for future use. Pass on all safety notes and instructions to any subsequent user of the light.

### **For your safety**

#### **WARNING**

Failure to observe the warning may result in injury to life and limb.

#### **CAUTION**

Indicates a hazard with a low risk that could result in a minor or moderate physical injury.

## Symbols



- Only suitable for indoor spaces!
- Do not use any sprays when cleaning!
- Double insulation
- The light is suitable for installation on surfaces with normal flammability.

## Safety notes

### WARNING

Hazardous grid voltage! Risk of electric shock! Deficient electrical installation or excessive mains voltage may result in an electric shock.


- Do not use the light if it exhibits visible damage.
- Check the device and cable for damages on a regular basis.
- Have repairs performed by a qualified workshop.— For repairs, only parts may be used that correspond to the original device specifications. There are electrical and mechanical parts in this unit that are essential in order to avoid exposure to sources of danger.
- Immerse neither the light nor the mains cord or plug-in water.
- Never take hold of the main cord with wet hands.
- Keep the light, mains plug, and mains cord away from open flames, and hot surfaces.
- Never attempt to grasp an electric appliance once it has fallen in the water. In such a case, immediately disconnect the mains plug.
- If you are not using the light, cleaning it or in the event of a malfunction, turn the light off and always pull the plug out of the socket.
- Never pull the mains cord out of the socket by the cord, instead, always take hold of the mains plug.
- Never use the connector cord as a carrying strap.
- If the main cord of this device is damaged, it must be replaced by the manufacturer or its customer service department or a person with similar qualifications in order to avoid risks.
- Render the device, which has outlived its purpose, is unusable. Pull the mains cord out of the socket and cut the mains cord in half.

### WARNING

Danger to children and other persons! Children often do not recognize the risks of handling electric appliances or underestimate them. Children can become trapped in the packing film when playing and suffocating.


- Do not allow children to play with the packing film and never allow them to use electric appliances without supervision.
- CAUTION Fire hazard! Do not use any sprays or the like to clean the light.
- Do not cover the light head with clothes or the like. The heat radiated from the light could cause them to catch fire.
- Set up the light on a solid, level surface (e. g. table or sideboard) close to a socket.
- Make sure that there is no risk of it tipping and that the cord does not pose a trip hazard.

## Assembly




1. Insert the pin on the light arm into the bracket on the base.
2. Secure the arm with screw A.

## Changing the lamp headcover



## Turning the light on/off



1. Insert the plug in a socket.
2. Arrange the light in the desired position.
3. Touch the button to switch the lamp on/off.

### **Lighting source**

- Lighting source service life: 30 000 hours lighting source cannot be replaced.
- The construction of the luminaire does not allow the lighting source to be replaced, as there is a risk of damaging the luminaire.

### **Care and cleaning**

#### **• WARNING**

Hazardous grid voltage! Risk of electric shock! Improper use could result in electric shock.

- When cleaning the light, always pull the mains plug out of the socket. When doing so, always take hold of the plug and not the cord.
- Make sure that no water penetrates the inside of the light or other parts carrying a current.
- Carefully wipe off the light with a damp cloth or a dry dust cloth.


### **Technical data**

- Voltage: 220 – 240 V AC / 50 Hz
- Power: 6.5 W
- Luminous flux: 350 lm (90°)
- Colour temperature: 5000 K
- Beam angle: 80°
- Protection class: II
- Model number: 41-5010.608
- This product contains a light source of energy efficiency class F.

### **Distribution**

- styro GmbH
- Industriestrasse 2
- D-91583 Schillingsfürst
- Tel. +49 9868 98949-0 [www.styro.de](http://www.styro.de)
- styroag Frauholzstrasse 27
- CH-6422 Steinen
- Tel. +41 (0)41 833 80 10 [www.styro.ch](http://www.styro.ch)

### **Documents / Resources**



- [!\[\]\(27c3f183a8911a7dac26d53c513f13df\_img.jpg\) Home | styro ag | dufco | Hansa](#)